

A Graphical-User Interface for the U.S. Geological Survey Modular Three-Dimensional Finite-Difference Ground-Water Flow Model (MODFLOW-96) Using Argus Numerical Environments

U.S. GEOLOGICAL SURVEY
Open-File Report 97-121

MODFLOW DataSets

Project | **Geology** | Misc. Controls | Stresses/Solvers | Time | Output Files | Output Controls | DE4

Geologic Units
Number of Geologic Units: 1

N.	Name	Sim...	Interblock Transmissi...	Aquifer type	Anisotro...	V. Discr...
1	Aquifer	Yes	Harmonic mean	Confined	1	4

Name: Aquifer ☒ Simulated


Interblock Transmissivity: Harmonic mean (0)

Aquifer type: Confined (0) (LAYCON)


Anisotropy factor (K_y/K_x): 1 (TRPY)

Vertical discretization: 1

Elevation of Aquifer Top



Surface Map of Hydraulic Head



A Graphical-User Interface for the U.S. Geological Survey Modular Three-Dimensional Finite-Difference Ground-Water Flow Model (MODFLOW-96) Using Argus Numerical Environments

by Allen M. Shapiro¹, Joshua Margolin², Shahar Dolev², and Yaacov Ben-Israel²

¹U.S. Geological Survey, Reston, VA

²Argus Interware, Jericho, NY

U.S. GEOLOGICAL SURVEY

Open-File Report 97-121



**Reston, Virginia
1997**

U.S. DEPARTMENT OF THE INTERIOR

BRUCE BABBITT, Secretary

U.S. GEOLOGICAL SURVEY

Gordon P. Eaton, Director

Although the computer program described in this report has been tested and used by the U.S. Geological Survey (USGS), no warranty, expressed or implied, is made by the USGS as to the accuracy of the functioning of the program and related material.

Any use of trade, product, or firm names in this publication is for descriptive purposes only and does not imply endorsement by the U.S. Government.

For additional information write to:

Office of Ground Water
U.S. Geological Survey
411 National Center
Reston, VA 20192

Copies of this report can be purchased
from:

U.S. Geological Survey
Branch of Information Services
Box 25286
Denver, Colorado 80225-0286

CONTENTS

	Page
Abstract.....	1
Introduction.....	1
System Requirements and Installation.....	2
Launching the Preprocessor and Saving Project Information.....	3
Entering and Editing Information in the MODFLOW-96 Preprocessor.....	5
Project Dialog.....	5
Geology Dialog.....	5
Editing Attributes of Geologic Units.....	6
Deleting a Geologic Unit.....	6
Adding a Geologic Unit.....	6
Attributes of Geologic Units.....	7
Modeling Geologic Units That Are Not Areally Extensive.....	8
Misc. Controls Dialog.....	8
Stresses/Solvers Dialog.....	10
Choosing stress packages.....	11
Choosing a solver.....	11
Time Dialog.....	11
Editing attributes of stress periods.....	12
Deleting a stress period.....	12
Adding a stress period.....	13
Attributes of stress periods.....	13
Time-varying and steady stresses.....	13
Output Files Dialog.....	13
Root Name of Data and Output Files.....	14
Head/Drawdown Solutions.....	14
Cell-By-Cell Flows.....	14
Output Controls Dialog.....	15
Output in MODFLOW-96 Listing File.....	15
Output to External Files.....	16
Solver Dialog.....	16
SIP--Strongly Implicit Procedure Package.....	16
SOR--Slice-Successive Overrelaxation Package.....	17
PCG--Preconditioned Conjugate-Gradient Package.....	18
DE4-- Direct-Solution Package with Alternating Diagonal Ordering.....	19
Geospatial Information Layers.....	21
Geospatial Information Layers in ArgusNE.....	21
Creating Geospatial Information Layers in the MODFLOW-96 Preprocessor.....	22
Drawing Size, Scale and Units.....	23

General Model Information Layers.....	23
Map Unit[i].....	23
MODFLOW Domain Outline.....	24
Added Inactive Area Unit[i].....	24
Topographic Information Layers.....	24
Elevation Top Unit[i]	25
Elevation Bottom Unit[i]	27
Consistent Elevations Between Geologic Units.....	27
Elevation of Top and Bottom of Model Layers.....	27
Hydrogeologic Information Layers.....	27
Prescribed Head Unit[i]	27
Initial Head Unit[i]	28
Hydraulic Conductivity Unit[i]	28
Specific Yield Unit[i]	29
Specific Storage Unit[i]	29
Wetting Threshold Unit[i]	29
Recharge Information Layer.....	30
Recharge.....	30
Evapotranspiration Information Layer.....	31
Evapotranspiration.....	31
Well Information Layers.....	31
Wells Unit[i]	31
River Information Layers.....	32
Line River Unit[i]	32
Area River Unit[i]	32
Drain Information Layers.....	33
Line Drain Unit[i]	33
Area Drain Unit[i]	33
General-Head Boundary Information Layers.....	34
Point Gen Head Bound Unit[i]	34
Line Gen Head Bound Unit[i]	34
Area Gen Head Bound Unit[i]	35
Finite-Difference Information Layers.....	35
MODFLOW Grid Density.....	36
MODFLOW FD Grid.....	36
Grid Type, Grid Direction, and other Grid Operations.....	36
Adding Geospatial Information Layers.....	37
Visualizing Geospatial Information Linked to the Finite-	
Difference Grid.....	37
Visualization of Topographic Information.....	38
Elev Top Unit[i]	38
Elev Bot Unit[i]	38
Thickness Unit[i]	38
Visualization of Hydrogeologic Information.....	38
IBOUND Unit[i]	38
Initial Head Unit[i]	38
Kx Unit[i]	38
Kz Unit[i]	38

Sp_Yield Unit[i]	38
Sp_Storage Unit[i]	38
Wetting Unit[i]	39
Visualization of Fluid Stresses.....	39
Recharge Elevation.....	39
ET Surface Elevation.....	39
Well Location Unit[i]	39
River Location Unit[i]	39
Drain Location Unit[i]	39
Gen Head B Location Unit[i]	39
Adding Parameters Linked to the Finite-Difference Grid.....	40
Creating Data Files and Executing MODFLOW-96.....	40
Files Created for MODFLOW-96 Simulations.....	41
Files Created by Executing MODFLOW-96.....	42
Visualizing Hydraulic Head and Drawdown Solutions from MODFLOW-96.....	43
Launching the Postprocessor.....	43
Contour Map.....	45
Color Map.....	45
Three-Dimensional Surface Map.....	46
Cross-Section.....	46
References.....	47

ILLUSTRATIONS

Figure	Page
1. MODFLOW-96 preprocessor dialog box.....	4
2. Geology dialog in MODFLOW-96 preprocessor.....	6
3. Schematic diagram of a geologic unit that is not areally extensive.....	8
4. Misc. Controls dialog in MODFLOW-96 preprocessor.....	9
5. Stresses/Solvers dialog in MODFLOW-96 preprocessor.....	10
6. Time dialog in MODFLOW-96 preprocessor.....	12
7. Output Files dialog in MODFLOW-96 preprocessor.....	14
8. Output Controls dialog in MODFLOW-96 preprocessor.....	15
9. SIP Package dialog in MODFLOW-96 preprocessor.....	17
10. SOR Package dialog in MODFLOW-96 preprocessor.....	18
11. PCG Package dialog in MODFLOW-96 preprocessor.....	19
12. DE4 Package dialog in MODFLOW-96 preprocessor.....	20
13. ArgusNE work space and floating layers window.....	23
14. ArgusNE Layers dialog.....	26
15. ArgusNE Expression dialog.....	26
16. Data dialog for MODFLOW-96 postprocessor.....	44
17. Visualization dialog for MODFLOW-96 postprocessor.....	45

A GRAPHICAL-USER INTERFACE FOR THE U.S. GEOLOGICAL SURVEY MODULAR THREE-DIMENSIONAL FINITE-DIFFERENCE GROUND-WATER FLOW MODEL (MODFLOW-96) USING ARGUS NUMERICAL ENVIRONMENTS

Allen M. Shapiro¹, Joshua Margolin², Shahar Dolev² and Yaacov Ben-Israel²

¹U.S. Geological Survey, Reston, VA

²Argus Interware, Jericho, NY

ABSTRACT

This report describes a Graphical-User Interface (GUI) developed for MODFLOW-96, the latest revision of the U.S. Geological Survey (USGS) modular, three-dimensional, finite-difference ground-water flow model. The pre- and post-processing GUI's for MODFLOW-96 were developed as Plug-In Extensions (PIEs) to the commercially available software developed by Argus Interware. The Argus Interware product, known as Argus Numerical Environments (ArgusNE), is a programmable geographic information system (GIS) that has automated gridding and meshing capabilities to link geospatial information with finite-difference and finite-element discretization, as well as several means of importing geospatial information. The pre- and post-processing interfaces automate the use of ArgusNE to create the appropriate GIS coverages or layers for MODFLOW-96 automatically, and to install menus and dialogs to synthesize geospatial information and simulation control parameters for MODFLOW-96, as well as visualize the model results. In addition to the Basic, Block-Centered Flow and Output Control packages of MODFLOW-96, the preprocessing GUI also incorporates the river, drain, well, general-head boundary, recharge and evapotranspiration packages, as well as four matrix solution algorithms. The preprocessing GUI creates formatted ASCII files that can be read by MODFLOW-96. MODFLOW-96 can be executed within the ArgusNE application, and hydraulic head and drawdown results from MODFLOW-96 simulations can be visualized with the postprocessing GUI. The GUI for MODFLOW-96 discussed in this report is a fully functioning graphical pre- and post-processor; however, it also allows the user to apply programmable features within ArgusNE to tailor the GUI to meet the unique demands of the each ground-water modeling project.

INTRODUCTION

Numerical models can not be regarded as representations of the real world because the complexity of natural hydrogeologic systems can never be captured in the discretized parameters of a numerical model. Instead, numerical modeling should be viewed as a means of testing hydrologic hypotheses based on model parameters that best represent measured phenomena. However, testing hydrologic hypotheses often becomes time consuming because numerical models have complex data requirements. To facilitate the modeling process, graphical-user interfaces (GUI's) are needed to synthesize geospatial information and simulation control parameters, as well as visualize the simulated results.

This report describes a GUI developed for MODFLOW-96, the latest revision of the U.S. Geological Survey (USGS) modular, three-dimensional, finite-difference ground-water flow model (Harbaugh and McDonald, 1996a; 1996b). Attributes of MODFLOW-96 as compared to earlier versions of MODFLOW are discussed in Harbaugh and McDonald (1996a).

The GUI for MODFLOW-96 discussed in this report is developed using commercially available software developed by Argus Interware. The Argus Interware product, known as Argus Numerical Environments (ArgusNE), is a programmable geographic information system (GIS) that has automated gridding and meshing capabilities to link geospatial information with finite-difference and finite-element discretization, as well as several means of importing geospatial information. The programmable nature of ArgusNE allows geospatial information and simulation control parameters to be exported to ASCII files that can be read by the numerical model, in this case, MODFLOW-96. In addition, ArgusNE allows access to externally developed Plug-In Extensions (PIEs), which are executable codes loaded into the memory of ArgusNE such that they appear as part of ArgusNE, even though they have been developed independently (Argus Interware, 1997b). For example, PIEs can be developed for purposes such as spatial interpolation, grid and mesh generation, geostatistics and control of model pre- and post-processing.

Although ArgusNE operates on multiple computing platforms, the GUI for MODFLOW-96 has been developed for computers operating under the Windows 3.11, Windows 95 and Windows NT operating systems. The GUI consists of two PIEs that appear as the files MFGUI_10.DLL and MFPOST10.DLL. The file extension DLL is referred to as a dynamically linked library, which is the name of the Microsoft technology that allows external codes to be loaded in the memory of software applications. The file MFGUI_10.DLL is the preprocessor for MODFLOW-96, and MFPOST10.DLL is the postprocessor for visualizing hydraulic head and drawdown solutions generated from MODFLOW-96 simulations. These PIEs are available without charge from the U.S. Geological Survey and can be distributed freely, however, they require an executable version of ArgusNE (version 3.0 revision s or higher) to operate. Furthermore, the PIEs described in this report are referred to as version 1, as enhancements in these codes are anticipated as users' needs are evaluated.

Although the GUI for MODFLOW-96 discussed in this report is a fully functioning graphical pre- and post-processor, it also allows the user to apply programmable features within ArgusNE to meet the unique demands of the each modeling project. Thus, the GUI for MODFLOW-96 is intended as a structure from which the user can add capability according to the demands of the modeling project.

This report is intended as a description of the use of the PIEs as graphical pre- and post-processors for MODFLOW-96. This report is not intended as a description of the programming that has been used to develop the PIEs ; however, the source codes for the PIEs (developed with Microsoft Visual C++) are available for those who wish to modify or augment the graphical pre- and post-processing capability developed in this version. Furthermore, it is assumed that the reader has a knowledge of the basic data requirements and underlying principles for using the USGS modular, three-dimensional, finite-difference, ground-water flow model. McDonald and Harbaugh (1988) and Harbaugh and McDonald (1996a, 1996b) provide thorough discussions of principles underlying MODFLOW-96. In addition, it is assumed that the reader has a knowledge of the general attributes and use of ArgusNE. Information about ArgusNE can be obtained from the ArgusNE User's Guide (Argus Interware, 1997a) and the World-Wide Web site for Argus Interware (<http://www.argusint.com>).

SYSTEM REQUIREMENTS AND INSTALLATION

The pre- and post-processing GUI developed for MODFLOW-96 and described in this report uses Argus Numerical Environments (ArgusNE) version 3.0 (revision s). More recent versions of ArgusNE also are compatible with the GUI for MODFLOW-96. ArgusNE operates on multiple computing platforms, however, the GUI discussed in this report has been developed only for computers operating under Windows 3.11, Windows 95 and Windows NT. Optimal operation of ArgusNE requires a Pentium 100 Mhz processor with 16 MB of RAM, 7 MB of free disk space and a video card capable of displaying 256 colors; however, capability to use 65,000 colors is recommended.

The pre- and post-processing GUI for MODFLOW-96 consists of four files, MFGUI_10.DLL and MFPOST10.DLL , MODFLOW.MET and MODFLOW.VAL. The file MFGUI_10.DLL is the PIE associated with preprocessing of simulation controls and geospatial information for MODFLOW-96. The file MFPOST10.DLL is the PIE associated with postprocessing visualization of hydraulic head and drawdown solutions from MODFLOW-96. The file MODFLOW.MET is the ArgusNE export template used with MFGUI_10.DLL to export simulation control and geospatial information into ASCII files that are read by MODFLOW-96. The file MODFLOW.VAL consists of default values for simulation control parameters used with MFGUI_10.DLL.

The pre- and post-processing PIEs for MODFLOW-96 have been developed using Microsoft Visual C++. The source codes for the PIEs are available at the World-Wide Web site <http://water.usgs.gov/software/> along with the files discussed above; this information is included under the category **Ground Water**. Additional information about ArgusNE can be found on the World-Wide Web site <http://www.argusint.com>.

To use the pre- and post-processing PIEs for MODFLOW-96 with ArgusNE, the files MFGUI_10.DLL and MFPOST10.DLL , MODFLOW.MET and MODFLOW.VAL must be placed in the directory **ArgusPIE** (or within a directory in the ArgusPIE directory) under the ArgusNE application. ArgusNE searches the **ArgusPIE** directory upon being launched and loads those PIEs that it encounters.

The executable version of MODFLOW-96 (MODFLW96.EXE) is assumed to be located in a directory with the pathname C:\MODFLW96.3_1\BIN; the full pathname of the executable for MODFLOW-96 is assumed to be C:\MODFLW96.3_1\BIN\MODFLW96.EXE. If the executable version of MODFLOW-96 is located in another directory, the MODFLOW.MET file in the ArgusPIE\mfgui1.0 directory must be edited using a text editor that can save files in an ASCII format. The pathname of the executable version of MODFLOW-96 is given in the second line from the bottom of the file. This line currently reads:

Execute external code: "C:\MODFLW96.3_1\BIN\MODFLW96.EXE"

The pathname in quotation marks should be replaced with the full pathname of the executable version of MODFLOW-96.

LAUNCHING THE PREPROCESSOR AND SAVING PROJECT INFORMATION

The preprocessing PIE for MODFLOW-96 automates the use of ArgusNE to create the appropriate GIS coverages or layers for MODFLOW-96 automatically and install menus and dialogs specific to MODFLOW-96 that can be invoked from within the ArgusNE application.

With the files MFGUI_10.DLL, MODFLOW.MET and MODFLOW.VAL in the ArgusPIE directory, launching ArgusNE will automatically load the PIE needed to launch the preprocessing interface for MODFLOW-96. After launching ArgusNE, the MODFLOW-96 preprocessor is launched by selecting the **New MODFLOW Project** menu item from the **File** menu. The MODFLOW-96 Preprocessor dialog box shown in Figure 1 appears on the screen. This dialog box is composed of a series of tab-dialog boxes in which project information is entered for MODFLOW-96 simulations. The titles of the tab dialog boxes are:

Project
Geology
Misc. Controls
Stresses/Solvers
Time
Output Files
Output Controls
Solver (where *Solver* is one of the following, **PCG**, **SOR**, **DE4**, or **SIP**)

The Project Information dialog boxes are used to enter simulation control parameters and other nonspatial information. Geospatial information, such as the spatial distribution of physical parameters, is created or imported in geospatial information layers, which will be described in a subsequent section.

The cursor is used to move from one tab dialog box to the next by clicking the tab of the desired dialog box. After information is entered into the tab dialog boxes, clicking the **OK** button prepares the set of geospatial information layers prescribed in the MODFLOW-96 Preprocessor that are to be used in the MODFLOW-96 simulation; control is then returned to the ArgusNE application. Clicking the **Cancel** button ignores any changes made in the tab-dialog boxes. The **OK** or **Cancel** button can be clicked at any time while editing project information for the MODFLOW-96 simulation; it is not necessary to access all of the tab dialog boxes before using the **OK** or **Cancel** buttons. Existing information in the MODFLOW-96 Preprocessor tab dialog boxes can be edited using the **Edit Project Info** menu item in the **Edit** menu, which causes the tab-dialog boxes to appear on the screen where information can again be entered and edited.

The project information for the MODFLOW-96 simulations as well as any information entered into the geospatial information layers in the ArgusNE application is saved by using the **Save** or **Save As...** command in the **File** menu. Launching ArgusNE application and opening an existing file containing MODFLOW-96 simulation information will retrieve the project information in the MODFLOW-96 Preprocessor tab dialog boxes and the geospatial information that was entered previously.




Figure 1. MODFLOW-96 preprocessor dialog box.

ENTERING AND EDITING INFORMATION IN THE MODFLOW-96 PREPROCESSOR

Geospatial information such as the spatial distribution of physical parameters is entered into geospatial information layers as described in the Geospatial Information Layers section of this report. The MODFLOW-96 Preprocessor dialog boxes are used to enter simulation control parameters and other nonspatial information.

To enter project information for a MODFLOW-96 simulation, the MODFLOW-96 preprocessor is launched from the **File** menu by choosing **New MODFLOW Project**. For an existing project saved in an ArgusNE file, the preprocessor information is edited from the **Edit** menu by choosing **Edit Project Info**. Either method causes the MODFLOW-96 Preprocessor dialog boxes to appear on the screen. The information in these dialog boxes is synthesized to build the structure of geospatial information layers needed for the MODFLOW-96 simulation. In the following, the information in each of the preprocessor dialog boxes is described.

Project Dialog

Information related to the description of the simulation is entered in the Project tab dialog box (Figure 1). The *Project Name*, *Date* and *Description* are editable fields used to describe the simulation. This information is not exported to the files used by MODFLOW-96; it is stored in an ArgusNE file and is provided as a convenience for archiving model information.

The two editable fields at the bottom of the Project dialog box entitled *Project title* are exported to the ASCII files read by MODFLOW-96.

Geology Dialog

The information in the Geology tab dialog box (Figure 2) defines the basic geologic structure of the three-dimensional modeled domain. In this dialog box, the number of geologic units in a simulation is defined and attributes for these geologic units are specified. Here, it is important to note that a distinction is made between geologic units and model layers. A geologic unit may consist of one or more model layers. Geospatial properties of geologic units are assumed to be constant over the thickness of a given geologic unit, however, these properties may vary in the areal dimensions; a discussion of geospatial information for MODFLOW-96 simulations is discussed in the following section.

The defaults for the Geology tab dialog box assume 3 geologic units, referred to as Top Aquifer, Aquitard and Bottom Aquifer. The names and attributes of these geologic units can be edited, by using the editable fields at the bottom of the dialog box and the **Modify** button at the right of the dialog box. Geologic units also can be added and deleted by using the **Insert** and **Delete** buttons at the right of the dialog box.

The order of the geologic units in the table is assumed to be the exact physical sequence that is to be modeled. The top of the simulated sequence is associated with geologic unit 1, and lower geologic units in the sequence are denoted by unit 2, unit 3, and so forth, for as many geologic units as exist.

MODFLOW DataSets

Project | **Geology** | Misc. Controls | Stresses/Solvers | Time | Output Files | Output Controls | PCG

Geologic Units

Number of Geologic Units: 3

N	Name	Sim...	Interblock Transmissi...	Aquifer type	Anisotro...	V. Discr...
1	Top Aquifer	Yes	Harmonic mean	Confined	1	1
2	Aquitard	No				1
3	Bottom Aquifer	Yes	Harmonic mean	Confined	1	1

Name: Top Aquifer ☒ Simulated Insert

Interblock Transmissivity: Harmonic mean (0) Modify

Aquifer type: Confined (0) (LAYCON) Delete

Anisotropy factor (Ky/Kx): 1 (TRPY)

Vertical discretization: 1

OK Cancel

Figure 2. Geology dialog in MODFLOW-96 preprocessor.

Editing Attributes of Geologic Units

To edit attributes associated with a given geologic unit, click the desired geologic unit in the table. The current attributes of that geologic unit will be placed in the editable fields at the bottom of the dialog box. Modifications to the attributes of the geologic unit are made in the editable fields at the bottom of the dialog box. Clicking the **Modify** button accepts the changes made in the editable fields and these changes are entered in the table at the top of the dialog box.

Deleting a Geologic Unit

To delete a geologic unit from the list, the cursor is moved to the table listing the geologic units. Clicking the row in the table highlights the information and then clicking the **Delete** button removes the geologic unit from the list. The remaining geologic units are renumbered. It is important to note that deleting a geologic unit will delete the geospatial information layers and all information in those layers. This information will be deleted once the **OK** button is clicked; clicking the **Cancel** button will cancel changes made in the dialog boxes. If the attributes and the geospatial information of the geologic unit may be needed at a later time, to avoid entering or importing this information again, the project information should be saved to another filename by first exiting the dialog boxes and using the **Save As...** command in the **File** pull-down menu.

Adding a Geologic Unit

To add a geologic unit, the cursor is moved to the table listing the geologic units and a row is select by clicking on it. Clicking the **Insert** button adds a geologic unit below the highlighted geologic unit. Attributes associated with the selected geologic unit are copied to the new geologic unit. The geologic units are then renumbered to reflect the addition of the new geologic unit.

Attributes of Geologic Units

Number is the sequence number of the geologic unit. The sequence number is assigned by the order of the geologic units, where the top most geologic unit is unit 1. The sequence number is not an editable attribute of the geologic unit, it can be changed only by inserting or deleting geologic units.

Name is the name of the geologic unit. This field is only intended for descriptive purposes. Geospatial information will be referenced to the sequence number (Unit 1, Unit 2 and so forth), not the name of the geologic unit.

Simulated is a flag indicating whether the geologic unit is to be simulated or not. Simulating the geologic unit implies that a hydraulic head solution will be achieved in the model layers of that geologic unit. Not simulating a geologic unit implies that the geologic unit is treated as a semi-confining unit and quasi-steady vertical flow is assumed to exist through that unit. Under such an assumption, a hydraulic head solution is not generated for the nonsimulated unit, however, hydraulic and topographic properties (in particular, the vertical hydraulic conductivity and top and bottom elevations) of that unit are used in preparing the information needed to solve for the hydraulic heads in the adjacent simulated geologic units. More than one

nonsimulated geologic unit can be placed between simulated geologic units. If nonsimulated geologic units are located at the top or bottom of the sequence of geologic units, they do not effect the solution for hydraulic head in the simulated geologic units in between.

For a nonsimulated geologic unit, only the vertical hydraulic conductivity and top and bottom elevation of the unit are used in generating information that is eventually exported for executing MODFLOW-96. Entering or importing this information will be described in detail in the following section. However, other geospatial information can be stored in the other geospatial information layers of a nonsimulated geologic unit in the event that the nonsimulated geologic unit will be changed to a simulated geologic unit.

Interblock Transmissivity is the method of computing the interblock transmissivity in a given geologic unit. A pop-up menu provides the choices for this parameter, which are harmonic mean, arithmetic mean, logarithmic mean and arithmetic mean of saturated thickness and logarithmic mean of transmissivity. (For the last option, the *Matrix Storage* parameter in the Misc. Controls dialog box discussed below must be set so that the storage in the arrays BUFF and RHS is separate.) More information about the choices for interblock transmissivity is provided in Goode and Appel (1992) and Harbaugh and McDonald (1996a, 1996b).

Aquifer Type is the type of aquifer (confined, unconfined or convertible) for the geologic unit. Only the uppermost simulated geologic unit can be an unconfined aquifer. For an unconfined geologic unit that is divided into more than one model layer, the top layer is assumed to be unconfined and subsequent layers are assumed to be convertible model layers. More information about the choices for aquifer type is provided in Harbaugh and McDonald (1996a, 1996b).

Anisotropy Factor is the ratio of hydraulic conductivity in the y-direction to the hydraulic conductivity in the x-direction of the modeled domain. A value of 1 implies an isotropic hydraulic conductivity.

Vertical Discretization is the number of model layers associated with the geologic unit. The model layers are assumed to be equally spaced in the vertical direction. The thickness of the geologic unit can vary in the areal dimensions, however, at a given areal location the thickness of the geologic unit is divided into equally spaced model layers in the vertical direction.

Modeling Geologic Units That Are Not Areally Extensive

The conceptual model of a sequence of geologic units implicitly assumes that geologic units are areally extensive in the modeled domain. Geologic units that are not areally extensive can also be modeled. To model geologic units that pinch out, a conceptual picture similar to that shown in Figure 3 must be used; Figure 3 is a cross section of a series of geologic units, where one of the units pinches out. A geologic unit that pinches out is assumed to be areally extensive with a finite thickness at all points in the areal dimensions; however the hydraulic properties of the geologic unit are made to vary in the areal dimensions to reflect the pinching out of the geologic unit.




Figure 3. Schematic diagram of a geologic unit that is not areally extensive.

Misc. Controls Dialog

In the Misc. Controls tab dialog (Figure 4), control information used in MODFLOW-96 simulations is specified. The control information is entered directly in the editable fields or from options provided in pop-up menus.

In the upper half of the dialog box, several of the control parameters Basic Package of MODFLOW-96 are specified. Harbaugh and McDonald (1996a, 1996b) provide additional information about the definition of these control parameters.

Matrix Storage defines storage locations for arrays in MODFLOW-96. Two options are provided in the pop-up menu; the vectors “BUFF, RHS occupy the same storage space” or “BUFF, RHS occupy different storage space.” If the *interblock transmissivity* for any of the geologic units specified in the Geology Dialog is defined as having an arithmetic mean of saturated thickness and logarithmic mean of transmissivity, then matrix storage should be specified such that “BUFF, RHS occupy different storage space.”

Keep Initial Heads defines whether the initial hydraulic heads are to be stored for use in calculating drawdowns. Two options are provided in the pop-up menu; “initial heads are not kept” and “initial heads are kept.” If drawdown is to be calculated from the hydraulic head solution and printed to the listing file or to external files for the postprocessing visualization, then the initial heads must be kept.




Figure 4. Misc. Controls dialog in MODFLOW-96 preprocessor.

Head Value for Inactive Cells is the hydraulic head assigned to no-flow cells (IBOUND=0) in the finite-difference grid at the start of the simulation. Additional information about the IBOUND array can be found in Harbaugh and McDonald (1996a).

Misc. Control Options specifies if flow between adjacent constant head cells is to be calculated or not.

In the lower half of the dialog box, controls for rewetting dry cells are entered. Harbaugh and McDonald (1996a, 1996b) provide additional information about the definition of these parameters.

Wetting Flag is the flag that specifies whether the wetting capability is inactive or active.

Head Assigned to Dry Cells is the head assigned to cells that have gone dry during the simulation.

Wetting Factor is the factor that is included in the equation for rewetting cells. The equation for rewetting cells is given in the pop-up menu labeled “Equation for Rewetting Cells.”.

Check for Wetting Cells is the iteration interval for attempting to rewet cells.

Equation for Rewetting Cells is the equation to define the initial head at cells that become wet, where BOT is the bottom of the modeled layer, WETFCT is specified in the editable field given above (Wetting Factor) and WETDRY is defined from the geospatial information layer Wetting Threshold.

Stresses/Solvers Dialog

In the Stresses/Solvers tab dialog box (Figure 5), the fluid stresses that are applied in the MODFLOW-96 simulation are defined along with the choice of the solver that is used in solving the matrix of equations generated from the finite-difference discretization of the ground-water flow equations. This version (version 1) of the preprocessor for MODFLOW-96 has included the following fluid stress packages discussed in McDonald and Harbaugh (1988) and Harbaugh and McDonald (1996a);

Recharge,
Rivers,
Wells
Drains
General Head Boundary.
Evapotranspiration.

In addition, the following solvers discussed in Harbaugh and McDonald (1996a), Hill (1990) and Harbaugh (1995) have been included in the preprocessor for MODFLOW-96;

SIP--Strongly Implicit Procedure
SOR--Slice-Successive Overrelaxation Method
PCG--Preconditioned Conjugate-Gradient Method
DE4--Direct-Solution Package with Alternating Diagonal Ordering

The screenshot shows the 'MODFLOW DataSets' dialog box with the 'Stresses/Solvers' tab selected. The dialog is divided into two main sections: 'Stresses Applied to MODFLOW Simulation' and 'Matrix Solution Method'.

Stresses Applied to MODFLOW Simulation:

- Recharge:** ☐ RCH. Steady stress (0). Recharge option code: Recharge is to top layer only (1) (NRCHOP).
- Rivers:** ☐ RIV. Steady stress (0).
- Wells:** ☐ WEL. Steady stress (0).
- Drains:** ☐ DRN. Steady stress (0).
- General-Head Boundaries:** ☐ GHB. Steady stress (0).
- Evapotranspiration:** ☐ EVT. Steady stress (0). Evapotranspiration option code: ET calculated only at top grid layer (1).

Matrix Solution Method:

- Strongly Implicit Procedure:** ☐ SIP ☒ PCG
- DE4:** ☐ DE4 ☐ SOR

At the bottom right are 'OK' and 'Cancel' buttons.

Figure 5. Stresses/Solvers dialog in MODFLOW-96 preprocessor.

Choosing Stress Packages

To include a particular stress package in the MODFLOW-96 simulation, the box adjacent to the named stress is clicked. Boxes with check marks indicate stresses that are to be included in the MODFLOW-96 simulation. The fluid stresses that are included in a MODFLOW-96 simulation will have geospatial information layers created in which to import or create information for the fluid stress under consideration. A discussion of importing or creating information for the stress packages is given in the following section.

Also associated with each stress package is a pop-up dialog box with two options; “steady stress” or “time-variable stress”. If the “steady stress” option is chosen, then the stress information is assumed to be constant throughout the entire simulation. If the “time-variable stress” option is chosen, then time-variable information associated with that stress package must be entered for each of the stress periods. A discussion of entering time-variable information for fluid stresses in MODFLOW-96 simulations is given in the following section.

For the recharge and evapotranspiration fluid stresses, an additional control parameter is provided for each to orient the applied stress in the vertical dimension. For the recharge stress, the three options are “recharge is to top model layer only,” “vertical recharge specified,” and “recharge applied to highest active cell.” The first and third option do not require geospatial information, although a geospatial information layer defining the recharge elevation is provided in the event that this option is changed. The second option uses the spatial distribution of the recharge elevation specified in a geospatial information layer to define the location in the vertical dimension where recharge is applied.

For the evapotranspiration stress, two options are provided; these are “ET calculated at top of grid” and “vertical distribution of ET specified in ET surface.” The first option applies evapotranspiration to the top model layer of the domain, while the second option uses the spatial distribution specified in the ET surface to identify the location of evapotranspiration in the vertical dimension. A geospatial layer defining the evapotranspiration surface and other parameters of evapotranspiration is created when the evapotranspiration stress is specified.

Choosing a Solver

At the bottom of the dialog box, radio buttons are given for the solvers that can be used in solving the matrix equations generated in MODFLOW-96. Only one solver can be used at a time. The solver to be used is accessed by clicking the radio button adjacent to its name. Clicking the radio button associated with a given solver also changes the name of the last tab dialog box to the name of the solver that is chosen. Parameters associated with the solver that is chosen are edited in the dialog box with the solver name. In Figure 5, the PCG solver is chosen and PCG appears as the title of the last tab dialog box.

Time Dialog

The Time tab dialog box (Figure 6) contains information related to the temporal controls in MODFLOW-96 simulations. At the top of the dialog box, general temporal controls for the simulation are specified.

Transient/Steady State Flow is the flag used to specify whether a simulation is for steady-state or transient flow conditions. A pop-up menu is provided to specify this option.

Time Units is the flag to identify the time units used in the simulation. A pop-up menu provides options for undefined time units, seconds, minutes, hours, days and years.

Number of Stress Periods displays the number of stress periods in the simulation; this is not an editable field. The number of stress periods can be changed only by adding or deleting stress periods in the table at the bottom of the dialog box.

MODFLOW DataSets

Project | Geology | Misc. Controls | Stresses/Solvers | **Time** | Output Files | Output Controls | PCG

Temporal Control for MODFLOW Simulation

Transient/Steady state flow: Steady-state flow (1) (ISS)

Time units: Undefined (0) (ITMUNI)

Number of stress periods: 1 (NPER)

N.	Length	No. of steps	Multiplier
1	1	1	1

Length: 1 (PERLEN) [Insert]

No. of steps: 1 (NSTP) [Modify]

Multiplier: 1 (TSMULT) [Delete]

[OK] [Cancel]

Figure 6. Time dialog in MODFLOW-96 preprocessor.

Editing Attributes of Stress Periods

To edit attributes associated with a given stress period, the cursor is moved to the table listing the stress periods in the middle of the dialog box; clicking one of the rows of the table places the current attributes of the stress period in the editable fields at the bottom of the dialog. Modifications to the attributes of the stress period are made in the editable fields at the bottom of the dialog box. Clicking the **Modify** button accepts the changes made in the editable fields and these changes are displayed in the table at the middle of the dialog box.

Deleting a Stress Period

To delete a stress period from the list, the cursor is moved to the table listing the stress periods. Clicking the row in the table highlights the information and then clicking the **Delete** button removes the stress period from the list, and the remaining stress periods are renumbered.

It is important to note that deleting a stress period will remove the information associated with that stress period in the geospatial information layers. This information will be deleted once the **OK** button is clicked; clicking the **Cancel** button will cancel changes made in the dialog boxes. If the temporal information in the geospatial information layers may be needed at a later time, to avoid entering or importing that information again, it is recommended that the project information be saved to another filename by first exiting the dialog boxes and using the **Save As...** command in the **File** pull-down menu.

Adding a Stress Period

To add a stress period, the cursor is moved to the table listing the stress period and a row of the table is highlighted by clicking on it. Clicking the **Insert** button adds a geologic unit below the highlighted stress period. Attributes associated with the stress period above are copied to the new stress period. The stress periods are then renumbered to reflect the addition of the new stress period.

Attributes of Stress Periods

Length is the length of the stress period in the time units specified in the upper part of this dialog box.

No. of steps is the number of time steps in the stress period.

Multiplier is the multiplier for the length of successive time steps in the stress period. Based on the length of the stress period and number of time steps in the stress period, the initial time step size is defined as

$$\Delta t_1 = \text{PERLEN} \frac{\text{TSMULT} - 1}{\text{TSMULT}^{\text{NSTP}} - 1}$$

where PERLEN is the length of the stress period, NSTP is the number of time steps in the stress period, TSMULT is the multiplier for the stress period and Δt_1 is the size of the first time step.

Time-Varying and Steady Stresses

Each of the fluid stress packages in the Stresses/Solvers dialog can have time-varying stresses specified, where the stress is constant within a stress period, but changes from one stress period to the next. In the geospatial information layers associated with a given fluid stress, a dialog will appear where the time-varying stress is entered for each of the stress periods. In the following section, a discussion of entering the time-varying stresses will be discussed for each of the fluid stresses considered in MODFLOW-96.

In the Stresses/Solvers dialog, a “steady stress” can also be specified for a fluid stress. In this case, the fluid stress specified in the first stress period will be used for all stress periods in the simulation. In the geospatial information layers associated with fluid stresses that are defined to be a “steady” stresses, the dialog where the time-varying stresses are entered will show all the stress periods, however, only information in the first stress period will be considered in the simulation. The other stress periods are listed in the event that the user may wish to change the fluid stress from “steady” to “time varying.”

Output Files Dialog

In the Output Files tab dialog (Figure 7), the root name for the data and output files associated with the MODFLOW-96 simulation is specified along with the types of external files (other than the listing file) that are to be generated when MODFLOW-96 is executed.




Figure 7. Output Files dialog in MODFLOW-96 preprocessor.

Root Name of Data and Output Files

The “root name” for all files associated with the simulation is specified in the editable field at the top of the dialog box. The same “root name” is given to all data files for the MODFLOW-96 simulation and all files with simulation results that are created. The extension associated with a given file will specify the type of information in that file. The types of file extensions will be discussed in the section “Creating Data Files and Executing MODFLOW-96.”

Head/Drawdown Solutions

Hydraulic head and drawdown solutions from a MODFLOW-96 simulation can be exported to formatted text files or binary data files. For the hydraulic head and drawdown solutions, a pop-up menu is used to choose either of these file types, or “none” to indicate that an external file with hydraulic head or drawdown results will not be generated when executing MODFLOW-96. If the drawdown solution is to be stored to an external file, then the flag for keeping the initial hydraulic heads specified in the Misc. Controls dialog must be set to “keep the initial hydraulic heads.”

If the postprocessing PIE for MODFLOW-96 discussed in this report is to be used, then the hydraulic head and/or drawdown solutions from the MODFLOW-96 simulations must be stored in formatted text files.

Cell-by-Cell Flows

Cell-by-cell flows derived from the volumetric budgets prepared by MODFLOW-96 are always stored in binary files. Cell-by-cell flows can be stored in a single binary file, or a separate binary file can be generated for each type of fluid stress, as well as the cell-by-cell flows from the Block-Centered Flow (BCF) package. Boxes checked at the bottom of the Output Files dialog indicate that an option is active. For example, if the cell-by-cell flows are to be gathered into one file, the cursor is used to check the box in front of “gather all cell-by-cell binary output into one file.” Specifying the export of the cell-by-cell flows for each of the stress packages and the BCF package is done separately by checking the appropriate boxes at the bottom of the dialog.

A new feature in MODFLOW-96 offers a more compact means of storing binary files having the cell-by-cell flow information. If this option box is checked, binary files will be stored in a compact format that requires less disk space; however, programs that read binary files generated from previous version of MODFLOW will have to be modified to read the compact format. If this option box is not checked then the method of storing binary files used in previous versions of MODFLOW is used.

Output Controls Dialog

In the Output Controls tab dialog (Figure 8), the frequencies of printing hydraulic head and drawdown solutions are specified along with the frequencies of printing the overall volumetric budget and the cell-by-cell flows.




Figure 8. Output Controls dialog in MODFLOW-96 preprocessor.

Output in MODFLOW-96 Listing File

In the top of the dialog, the frequencies for including the hydraulic head and drawdown solution and the overall volumetric budget in the MODFLOW-96 listing file are specified. The frequencies of printing these results in the listing is given in the three options in the pop-up menu; these options are “none,” “each Nth time step” and “last time step of each stress period.” When the second option is used, the value of N is specified in the editable field at the right of the dialog. If a drawdown solution is to be printed in the MODFLOW-96 listing file, then the flag for keeping the initial hydraulic heads specified in the Misc. Controls dialog must be set to “keep the initial hydraulic heads.”

Output to External Files

If the hydraulic head solution, the drawdown solution or cell-by-cell flows are to be exported to external files, the frequencies of exporting this information to external files are specified in the editable fields at the bottom of the dialog. The editable fields for specifying the frequency of output to external files will be operational only if these files are specified in the Output Files dialog. The frequency of printing results in external files is given in the three options in the pop-up menu; these options are “none,” “each Nth time step” and “last time step of each stress period.” When the second option is used, the value of N is specified in the editable field at the right of the dialog. If a drawdown solution is to be exported to an external file, then the flag for keeping the initial hydraulic heads specified in the Misc. Controls dialog must be set to “keep the initial hydraulic heads.”

Solver Dialog

Choosing a solver in the Stresses/Solvers dialog specifies the name of the solver in the title of the final tab dialog box of the MODFLOW-96 Preprocessor. Only one solver can be used in the simulation. The parameters associated with the operation of that solver are specified in editable fields and pop-up menus in the solver dialog.

SIP--Strongly Implicit Procedure Package

The parameters listed below are defined in the dialog when using the SIP solver (Figure 9). Additional information about the SIP package can be obtained from McDonald and Harbaugh (1988) and Harbaugh and McDonald (1996a).

MXITER is the maximum number of iterations allowed in a time step.

NPARM is the number of iteration parameters.

ACCL is the acceleration parameter.

HCLOSE is the maximum absolute change in the hydraulic head from one iteration to the next used in accepting the hydraulic head solution. The change in the hydraulic head solution from all modeled cells must be less than or equal to *HCLOSE*.

IPCALC is the flag indicating whether the seed for calculating iteration parameters will be specified or calculated internally.

WSEED is the seed for calculating iteration parameters. This parameter is ignored if *IPCALC* is set to generate the seed internally to the program.

IPRSIP is the printing interval for information about the solution. The maximum head change is printed for each iteration of a time step whenever the time step is an even multiple of *IPRSIP*. The printout also is generated at the end of each stress period.




Figure 9. SIP Package dialog in MODFLOW-96 preprocessor

SOR--Slice-Successive Overrelaxation Package

The parameters listed below are defined in the dialog when using the SOR solver (Figure 10). Additional information about the SOR package can be obtained from McDonald and Harbaugh (1988) and Harbaugh and McDonald (1996a).

MXITER is the maximum number of iterations allowed in a time step.

ACCL is the acceleration parameter.

HCLOSE is the maximum absolute change in the hydraulic head from one iteration to the next used in accepting the hydraulic head solution. The change in the hydraulic head solution from all modeled cells must be less than or equal to *HCLOSE*.

IPRSOR is the printing interval for information about the solution. The maximum head change is printed for each iteration of a time step whenever the time step is an even multiple of *IPRSOR*. The printout also is generated at the end of each stress period.




Figure 10. SOR Package dialog in MODFLOW-96 preprocessor.

PCG--Preconditioned Conjugate-Gradient Package

The parameters listed below are defined in the dialog when using the PCG solver (Figure 11). Additional information about the PCG package can be obtained from Hill (1990).

MXITER is the maximum number of outer iterations.

ITER1 is the maximum number of inner iterations.

NPCOND is the flag to select the matrix preconditioning. *NPCOND*=1 indicates the use of the modified incomplete Cholesky method. *NPCOND*=2 indicates the use of the polynomial method.

HCLOSE is the maximum absolute change in the hydraulic head from one iteration to the next used in accepting the hydraulic head solution. The change in the hydraulic head solution from all modeled cells must be less than or equal to *HCLOSE*.

RCLOSE is the maximum absolute residual used to accept the hydraulic head solution.

RELAX is the relaxation parameter.

NBPOL is used only when *NPCOND*=2 and indicates the upper bound of the maximum eigenvalue. *NBPOL*=2 specifies the maximum eigenvalue to be 2. The other option forces the eigenvalue to be calculated.

IPRPCG is the printing interval for the solver. Information is printed for each iteration of a time step whenever the time step is an even multiple of *IPRPCG*. The printout also is generated at the end of each stress period.

MUTPCG is the flag controlling the information that is to be printed.

IPCGCD is the flag used when *NPCOND*=1 to control whether the same Cholesky decomposition is to be used repeatedly.

MODFLOW DataSets		
PCG		
Preconditional Conjugate Gradient Package		
Max number of outer iterations:	20	(MXITER)
Max number of inner iterations:	30	(ITER1)
Matrix preconditioning method:	Modified incomplete Cholesky (1)	(NPCOND)
Max. abs. change in head:	0.1	(HCLOSE)
Max. abs. change in residual:	0.1	(RCLOSE)
Relation parameter:	1	(RELAX)
Upper bound of the max. eigenvalue:	Two (2)	(NBPOL)
Printout interval:	999	(IPRPCG)
Printing control:	Suppress printing (2)	(MUTPCG)
Cholesky decomp. used for multiple calls:	Yes (1)	(IPCGCD)
		OK Cancel

Figure 11. PCG Package dialog in MODFLOW-96 preprocessor.

DE4--Direct-Solution Package with Alternating Diagonal Ordering

The parameters listed below are defined in the dialog when using the DE4 solver (Figure 12). Additional information about the DE4 package can be obtained from Harbaugh (1995).

ITMX is the maximum number of iterations allowed in a time step.

MXUP is the maximum number of equations in the upper part of the equations to be solved. If set to 0, the program will calculate *MXUP*. Harbaugh (1995) provides information on defining this parameter.




Figure 12. DE4 Package dialog in MODFLOW-96 preprocessor.

MXLOW is the maximum number of equations in the lower part of the equations to be solved. If set to 0, the program will calculate *MXLOW*. Harbaugh (1995) provides information on defining this parameter.

MXBW is the maximum bandwidth plus 1 of the [AL] matrix. If set to 0, the program will calculate *MXBW*.

IFREQ is the flag indicating the frequency at which coefficients in the [A] matrix change. The pop-up menu provides the three options; *IFREQ*=1 indicates constant linear flow equations with constant coefficients throughout the simulation; *IFREQ*=2 indicates linear flow equations, but coefficients associated with hydraulic head in fluid stresses change at the beginning of a stress period; *IFREQ*=3 indicates nonlinear flow equations.

MUTD4 is the flag indicating the information that is to be printed when convergence information is printed for a given time step. The pop-up menu provides the three options; *MUTD4*=0 indicates printing the number of iterations and the maximum head change; *MUTD4*=1 indicates printing of only the number of iterations; *MUTD4*=2 indicates no information is printed.

ACCL is the multiplier for the computed head change for each iteration.

HCLOSE is the maximum absolute change in the hydraulic head from one iteration to the next used in accepting the hydraulic head solution. The change in the hydraulic head solution from all modeled cells must be less than or equal to *HCLOSE*.

IPRD4 is the printing interval for information about the solution. The maximum head change is printed for each iteration of a time step whenever the time step is an even multiple of *IPRSIP*. The printout also is generated at the end of each stress period.

GEOSPATIAL INFORMATION LAYERS

ArgusNE offers a GIS environment where two-dimensional coverages or layers are superimposed over each other. Note that the term “layer” in the context of ArgusNE does not have the same meaning as a modeled layer in a MODFLOW-96 finite-difference grid. Each layer in ArgusNE can be accessed and information can be generated using drawing tools that are part of ArgusNE, or spatial information can be imported from a variety of sources including text files, DXF files and ARC/Info Shape files. Additional information about importing geospatial information into ArgusNE layers can be found in ArgusNE User’s Guide and the World-Wide Web site for Argus Interware (<http://www.argusint.com>).

In this section, the geospatial information layers generated as part of the MODFLOW-96 preprocessor are described; these include topographic, hydrologic, fluid stress and finite-difference geospatial information layers. Before executing MODFLOW-96, appropriate information must be entered into the geospatial information layers to describe the physical and hydrologic setting for the ground-water flow simulation and the numerical discretization of the modeled domain. To initiate this discussion on geospatial information layers, a brief summary of the types of geospatial information layers provided in the ArgusNE application is given.

Geospatial Information Layers in ArgusNE

ArgusNE supports several types of two-dimensional coverages or layers; these layer types are referred to as quadrilateral mesh, triangular mesh, finite-difference grid, map, domain, data and information layers. MODFLOW-96 is based on the finite-difference method, thus, the quadrilateral and triangular mesh layers which are used for finite-element numerical models are not used here.

Map layers provide a visual base for other geospatial information layers; information in map layers cannot be linked to other layers for use in the simulation. Map layers also can be used to visualize point data from ArgusNE *Data layers* using a variety of visualization tools provided in ArgusNE. The postprocessing visualization of hydraulic heads and drawdown for MODFLOW-96 simulations is generated in a map layer.

A *domain layer* specifies the areal extent of the modeled domain. The domain layer is used by the finite-difference grid layer to create the finite-difference grid for the numerical simulation.

Data layers allow scattered, gridded or meshed (point-wise) data to be imported which can then be linked to the finite-difference grid or visualized in map layers.

Information layers allow one to describe the distribution of geospatial information in the form of open contours, closed contours and point contours (similar to topographic map contours). This contour information is interpreted to define the spatial variability of the information in the layer. Various interpolation methods are available within ArgusNE for this purpose. This information can then be linked to the discretization in the finite-difference grid

layer and can be eventually exported in a format that can be read by MODFLOW-96. Geospatial information created or imported in information layers does not need a prior knowledge of the finite-difference grid. The finite-difference grid is superimposed on information layers and the information within grid cells is extracted. Thus, it is easy to change discretization without affecting the underlying geospatial information.

A finite-difference *grid layer* allows a finite-difference grid to be generated based on the *domain layer*. The finite-difference grid layer can take advantage of a special type of information layer, referred to as a *density layer*, to automatically increase or decrease the density of finite-difference grid lines in selected regions of the modeled domain; grid lines also can be edited manually.

Additional information about the attributes of these types of layers and linking information between layers, as well as the methods of importing and exporting information to these layers is available in the ArgusNE User's Guide.

Creating Geospatial Information Layers in the MODFLOW-96 Preprocessor

The MODFLOW-96 Preprocessor dialog boxes are used to specify the simulation control parameters and create the geospatial information layers needed for the simulation of ground-water flow using MODFLOW-96. After preparing all information in the MODFLOW-96 Preprocessor dialog boxes and clicking the **OK** button, control is returned to the ArgusNE work space. Clicking the button adjacent to the Argus logo above the work space opens the floating window of geospatial information layers created by the MODFLOW-96 preprocessor (Figure 13). The checked layer is the active layer and an “eye” indicates whether a layer is visible or not.

Geospatial information layers are created for each geologic unit that is specified in the Geology tab dialog box within the MODFLOW-96 Preprocessor. In addition, geospatial information layers are created within each geologic unit for each of the fluid stresses that are specified; the exceptions are for the recharge and evapotranspiration stresses which have one geospatial information layer each. If additional geologic units or fluid stresses need to be specified, the project information can be edited at any time using the **Edit Project Info** command in the **Edit** menu. If new geologic units are added or removed, the geospatial information layers are renumbered to reflect the new order associated with the geologic units. Caution should be used in deleting geologic units in the Geology dialog as this will result in the loss of all geospatial information prepared for the geologic unit under consideration. If this information is to be used at a later time, it is recommended that the project information be saved to another filename by first exiting the dialog boxes and using the **Save As...** command in the **File** pull-down menu.

In the following, the geospatial information layers created by the MODFLOW-96 preprocessor are described. Reference to geospatial information layers for geologic units is denoted by [i], where the “i” denotes the sequence number of the geologic unit. Furthermore, geospatial information layers denoted by [i] indicate that a geospatial information layer of that type will be created for each geologic unit specified in the Geology dialog in the MODFLOW-96 Preprocessor.




Figure 13. ArgusNE work space and floating layers window.

Drawing Size, Scale and Units

Prior to creating or importing information in geospatial information layers, it is recommended that the user specify the drawing size of the work space, as well as the scale and units of the modeling project. This information can be entered from the **Drawing Size...** and **Scale and Units...** commands in the **Special** pull-down menu. The Argus User's Guide provides information on setting attributes in the dialog boxes that appear when these commands are used.

General Model Information Layers

Map Unit[i]

For each geologic unit, a map layer is created by the MODFLOW-96 preprocessor. Map information can either be imported from text, DXF or ARC/Info Shape files, or generated using the drawing tools on the tool palette (to the left of the work space). Details regarding importing map information can be found in the ArgusNE User's Guide and the ArgusNE Web site; information on the operation of the drawing tools can be found in the ArgusNE User's Guide.

Map information is only used as a visual basis for other geospatial information layers. Objects in map layers (lines, points and other vector objects) can be copied from the map layer and pasted into other geospatial information layers where attributes associated with the geospatial information layer can be assigned to these objects. For example, if the boundary line on a map is associated with a prescribed hydraulic head, the boundary line can be copied from the map layer to the **Prescribed Head Unit[i]** layer. Information about copying and pasting objects in ArgusNE can be found in the ArgusNE User's Guide.

MODFLOW Domain Outline

The MODFLOW Domain Outline layer contains the closed boundary that represents the maximum areal extent of the simulated regions from all geologic units in the vertical sequence. Because a three-dimensional simulation is visualized on a two-dimensional areal surface, the domain outline specified in this layer must be the union of the simulated regions in all of the geologic units. To account for the fact that each geologic unit may have a different simulated domain, a geospatial information layer for each geologic unit, referred to as **Added Inactive Area Unit[i]**, is created. Areas that are outside the simulated region in a given geologic unit but lie within the model domain boundary specified in **MODFLOW Domain Outline** can be defined as being inactive in the layer **Added Inactive Area Unit[i]**.

The domain outline can either be generated with the domain drawing tool shown at the left of the workspace in this layer or it can be imported from text, DXF or ARC/Info Shape files. Information on the operation of the domain drawing tools can be found in the ArgusNE User's Guide. If the domain outline is generated with the drawing tool, a dialog box will appear once a closed domain has been specified. In the dialog box, the density of finite-difference grid lines is specified as the average distance between grid lines in the units of the project.

Complex domain boundary shapes can be generated using the drawing tools. For example, islands of inactive areas can be placed within a simulated domain outline. Information on generating complex domain boundaries can be found in the ArgusNE User's Guide.

Added Inactive Area Unit[i]

To account for the fact that each geologic unit may have a different simulated region in comparison to the closed boundary represented in the **MODFLOW Domain Outline** layer, regions in the **Added Inactive Area Unit[i]** layer can be specified as being outside the modeled region in the geologic unit under consideration. If no information is entered into this layer, it is assumed that the domain outline in the **MODFLOW Domain Outline** layer is identical to the simulated region in the geologic unit under consideration. Furthermore, the information in the layer **Added Inactive Area Unit[i]** is only evaluated if the geologic unit is a simulated geologic unit (see the attributes of geologic units in the Geology dialog of the MODFLOW-96 Preprocessor).

To specify an inactive area of a simulated geologic unit, select the "closed contour" tool from the tool palette and digitize a closed region. A discussion of the use of the contouring tools is provided in the ArgusNE User's Guide. Upon closing the region a dialog box appears and a value of 0 (zero) must be entered into the dialog under the "Value" column. The value of zero indicates that the closed region will be made inactive in the geologic unit under consideration.

The shape of this inactive area can be changed or the inactive area can be move; information on performing these tasks is provided in the ArgusNE User's Guide.

Topographic Information Layers

The preprocessor for MODFLOW-96 assumes that all data is referenced to the same reference elevation or datum. For example, information in the fluid stress packages that refer to elevations such as river stages, elevations of drains, and so forth, must make use of the same reference elevation as the topographic information layers. Furthermore, all geologic units must have topographic information specified, including nonsimulated geologic units (that is, those geologic units assumed to be semi-confining units with quasi-steady vertical leakage).

The default elevations specified by the MODFLOW-96 preprocessor for the layers **Elevation Top Unit[i]** and **Elevation Bottom Unit[i]** are set to a constant value of zero throughout the modeled region. The user must change these elevations to reflect the topographic information in the model simulation, otherwise errors will arise in executing MODFLOW-96. Methods of changing the default elevation and creating spatially variable topographic information are discussed below.

Elevation Top Unit[i]

Elevation Top Unit[i] specifies the top elevation of the geologic unit. The elevation of the top of the geologic unit can be a constant or spatially varying in the areal dimensions. Spatially varying elevation can be created using the contouring tools from the tool palette, copying vector objects from other layers such as map layers and information layers, or by importing information contours from text, DXF or ARC/Info Shape files. If the contouring tools are used, all three contouring tools (closed, line or point) can be used to create a spatially varying elevation. After a (closed, line or point) contour is applied to the work space, a dialog will appear where the value associated with the elevation contour can be entered.

To specify a constant elevation, or default elevation, or change the method of interpolating elevation, or program a spatially varying elevation for the top of the geologic unit, the **Layers dialog** must be used. Moving the cursor to the "Layers..." button in the floating layers window and clicking (Figure 13), opens the Layers dialog (Figure 14). The list at the top of the dialog is the list of layers. Highlighting the layer under consideration, in this case **Elevation Top Unit[i]**, in that list by clicking it with the cursor shows the parameters associated with that information layer in the table at the bottom of the dialog box. Moving the cursor to the "Value" column and clicking and holding causes the "expression" box to appear. Moving the cursor over the "expression" box causes the **Expression dialog** to appear (Figure 15). A mathematical expression, for example, a numerical value can be entered or another geospatial information layer can be used as the expression for the top of the geologic unit. Clicking **OK** exits the expression dialog. Clicking **Cancel** exits the expression dialog without modifying the value. The interpolation method for the layer can be changed by using the pop-up menu at the bottom of the layers dialog. More detailed information on using the **Layers dialog** and **Expression dialog** can be found in the ArgusNE User's Guide.




Figure 14. ArgusNE Layers dialog.




Figure 15. ArgusNE Expression dialog.

If the spatial distribution of elevation is available by a set of scattered or gridded data points, this information can be imported. To do so, open the **Layers dialog** and select the layer to be changed from an ArgusNE Information layer to an ArgusNE Data layer. Moving the cursor to

the Type field of the layer and clicking and holding displays the pop-up menu. Selecting “Data” from the pop-up menu will convert the layer to an ArgusNE Data layer that will accept scattered or gridded data points.

Elevation Bottom Unit[i]

The elevation for the bottom of a geologic unit can be specified in a manner similar to that discussed for the layer **Elevation Top Unit[i]**.

Consistent Elevations Between Geologic Units

In the MODFLOW-96 preprocessor, it is assumed that there will be no “gaps” or inconsistencies in the elevations between geologic units, for example, the bottom of geologic unit 1 must equal the top of geologic unit 2. To insure that this occurs, the user should specify the top elevation of geologic unit 1 and the bottom of all geologic units (1, 2, ...N) using the methods discussed for layer **Elevation Top Unit[i]**. The top elevation of geologic units 2, 3, ...N given in layers **Elevation Top Unit[i], i=2,3,...N** can then be specified as being equal to the bottom elevation of the preceding geologic unit in the sequence. To specify this equivalence, the **Layers dialog** must be used. Clicking the “Layers...” button at the top of the floating layers window opens the Layers Dialog. Highlighting the layer under consideration, in this case **Elevation Top Unit[i], i=2,3,...N**, by clicking it with the cursor shows the parameters associated with that information layer in the list at the bottom of the dialog box. Moving the cursor to the “Value” column and clicking and holding causes the “expression” box to appear. Releasing the cursor over the “expression” box causes the **Expression dialog** to appear. From the list of layers at the bottom of the dialog, the layer **Elevation Bottom Unit[i-1]** is chosen by clicking it. Double clicking the parameter name (in this case **Elevation Bottom Unit[i-1]**) in the list to the right, places this parameter in the expression at the top of the dialog box. Clicking **OK** applies the change and exits the expression dialog.

If geologic units are deleted or added, the topographic information should be edited to insure consistent elevations between geologic units.

Elevation of Top and Bottom of Model Layers

Specifying the elevation of the top and bottom of the geologic unit also specifies the elevation of the top and bottom of each model layer in a geologic unit. The number of model layers in a geologic unit is specified in the Geology dialog box in the MODFLOW-96 Preprocessor. Although the thickness of the geologic unit can vary in the areal dimensions, the thickness of the geologic unit is divided into model layers of equal thickness at a given areal location.

Hydrogeologic Information Layers

Prescribed Head Unit[i]

The point contour, line contour and closed contour tools in the tool palette can be used to specify points, lines, and areas of prescribed head in the geologic unit. Objects copied from other geospatial information layers, such as map layers, also can be used to specify locations of prescribed head in the modeled geologic units. Also, locations of prescribed head can be

imported from text, DXF and ARC/Info Shape files. Information concerning the use of the contour tools and copying information from one layer to another and importing information from files is provided in the ArgusNE User's Guide. If the prescribed head distribution is available through a set of data points, change the layer type to an ArgusNE Data layer and import that information (see the procedure above in Topographic Information Layers).

After placing a contour of prescribed head (point, line or area) in the modeled domain a dialog box appears where the value of the prescribed head is specified under the value column in the dialog. If an object was copied from another geospatial information layer or imported, double clicking on the object will bring up the dialog where the value of the prescribed head can be specified.

The prescribed hydraulic head specified in line contours and closed contours are assumed to be constant over the line or area. To define a spatially varying prescribed hydraulic head along a line or area, segments of lines or areas can be placed end to end, where in each segment the prescribed head is constant. To accommodate this, the **Allow Intersection** command in the **Special** menu should be used. If the **Allow Intersection** command is active, a check mark will appear next to it in the pull-down menu. The **Allow Intersection** command allows contours to intersect each other, such as placing segments of lines or areas adjacent to each other.

The application of the prescribed head assumes that it is applied over the entire thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model layer, the specified hydraulic head will be applied to each model layer in the vertical dimension at the areal locations specified.

Initial Head Unit[i]

The initial hydraulic head can be specified to be a constant or contour information describing a spatially varying initial hydraulic head can be imported or generated. The default initial hydraulic head is zero for all geologic units. To change the default value or to change the interpolation method or program a spatially variable initial hydraulic head the user must enter the **Layers dialog** and the **Expression dialog** for the layer **Initial Head Unit[i]**. A brief discussion of this procedure is presented in the section describing the layer **Elevation Top Unit[i]**. The ArgusNE User's Guide provides more detailed information about the use of the **Layers dialog** and the **Expression dialog**.

The initial hydraulic head also can be imported from text, DXF or ARC/Info Shape files, or generated using the point, line and closed contour tools to the left of the project work space. If the contour tools are used to generate a spatial distribution of initial hydraulic head, a dialog will appear after applying a given contour tool where the initial hydraulic head is specified in the dialog under the "value" column. If the contours of initial hydraulic head are imported, doubling clicking on a contour in the work space will show the dialog box in which the initial hydraulic head can be entered or edited. If the initial hydraulic head distribution is available through a set of data points, change the layer type to an ArgusNE Data layer and import the information (see detailed procedure above in Topographic Information Layers)

The initial hydraulic head in the geologic unit is assumed to be applied over the entire thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model

layer, the hydraulic head at a given areal location will be applied to each model layer in the vertical dimension.

Hydraulic Conductivity[i]

The spatial variability of the hydraulic conductivity of the geologic unit can be specified similarly to that discussed for the layer **Initial Head Unit[i]**. However, the hydraulic conductivity requires the definition of two parameters, the hydraulic conductivity in the x-direction (K_x) and the hydraulic conductivity in the z-direction (K_z); the hydraulic conductivity in the y-direction is known from the hydraulic conductivity in the x-direction and the anisotropic ratio defined for each geologic unit in the Geology dialog box in the MODFLOW-96 Preprocessor. If the hydraulic conductivity distribution is available through a set of data points, change the layer type to an Argus NE Data layer and import that information (see detailed procedure above in Topographic Information Layers)

If the geologic unit is assumed to be nonsimulated and it lies between simulated geologic units, then the hydraulic conductivity in the z-direction must be specified because the nonsimulated geologic unit is assumed to be a semi-confining unit with quasi-steady vertical leakage.

The hydraulic conductivity (both K_x and K_z) is assumed to be uniform over the entire thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model layer, the hydraulic conductivity at a given areal location will be applied to each model layer in the vertical dimension; however, the hydraulic conductivity (both K_x and K_z) can vary spatially in the areal dimensions.

Specific Yield Unit[i]

The spatial variability of the specific yield of the geologic unit can be specified similarly to that discussed for the layer **Initial Head Unit[i]**. Although in particular model simulations, the specific yield may not be used, for example, in a confined aquifer, this information layer is still provided for the geologic unit in the event that the geologic unit is converted from a confined aquifer to an unconfined aquifer. If the specific yield distribution is available through a set of data points, change the layer type to an ArgusNE Data layer and import that information (see detailed procedure above in Topographic Information Layers)

Similarly to the hydraulic conductivity, the specific yield is assumed to be uniform over the entire thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model layer, the specific yield at a given areal location will be applied to each model layer in the vertical dimension; however, the specific yield can vary spatially in the areal dimensions.

Specific Storage Unit[i]

The spatial variability of the specific storage of the geologic unit can be specified similarly to that discussed for the layer **Initial Head Unit[i]**. Although in a particular simulation, the specific storage may not be used, for example, in a steady-state flow simulation, this information layer is still provided for the geologic unit in the event that the type of simulation changes to where it will be needed in the simulation. If the specific storage distribution is

available through a set of data points, change the layer type to an ArgusNE Data layer and import that information (see detailed procedure above in Topographic Information Layers)

Similarly to the hydraulic conductivity, the specific storage is assumed to be uniform over the entire thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model layer, the specific storage at a given areal location will be applied to each model layer in the vertical dimension; however, the specific storage can vary spatially in the areal dimensions.

Wetting Threshold Unit[i]

The spatial variability of the wetting threshold of the geologic unit can be specified similarly to that discussed for the layer **Initial Head Unit[i]**. Although in particular model simulations, the wetting threshold may not be used, for example, in a confined aquifer, this information layer is still provided for the geologic unit in the event that the geologic unit is converted from a confined aquifer to an unconfined aquifer and rewetting calculations are specified in the Misc. Controls dialog. If the wetting threshold distribution is available through a set of data points, change the layer type to an ArgusNE Data layer and import that information (see detailed procedure above in Topographic Information Layers)

Similarly to the hydraulic conductivity, the layer **Wetting Threshold Unit[i]** has two parameters that must be defined, the wetting threshold and the wetting flag. The wetting threshold and wetting flag used in MODFLOW-96 simulations are described in McDonald and others (1992). The wetting flag is an integer (-1, 0, or 1) that indicates which neighboring cells can cause a cell to rewet. If the wetting flag is -1, only the cell below the dry can cause a cell to rewet. If the wetting flag is 1, the cell below the dry cell and the four adjacent cells can cause a cell to rewet. If the wetting flag is 0, the cell can not be rewetted.

The wetting threshold will only be applied to unconfined geologic units or geologic units denoted as being convertible between confined and unconfined. If a geologic unit is unconfined, only the top model layer in the geologic unit is unconfined; the model layers below the top model layer are assumed to be convertible. Furthermore, the wetting threshold is assumed to be constant over the thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model layer, the wetting threshold at a given areal location will be applied to each model layer in the vertical dimension; however, the wetting threshold and wetting flag can vary spatially in the areal dimensions.

Recharge Information Layer

Recharge

In MODFLOW-96, the recharge stress is applied as a two-dimensional spatial distribution of the recharge rate given in units of length per time, or equivalently, length cubed per time per unit area. The volumetric recharge applied to each model cell is automatically calculated based on the area of the cell. If finite-difference discretization changes, the volumetric recharge applied to each model cell will be automatically recalculated and it is not necessary to change the underlying recharge rate specified in the layer **Recharge**. The spatial variability of the parameters describing recharge can be specified similarly to that discussed for the layer **Initial Head Unit[i]**.

The vertical distribution of recharge depends on the recharge option specified in the Stresses/Solvers dialog. If the recharge option is specified to apply recharge to the top model layer only or to apply recharge to the highest active cell, then the recharge elevation in the dialog that appears when entering or editing information in the layer **Recharge** is not used. However, the recharge elevation will continue to appear in the dialog associated with the layer **Recharge** in the event that the recharge option is changed in other simulations.

If the recharge option in the Stresses/Solvers dialog is specified to apply recharge based on the recharge elevation, then the spatial distribution of the recharge elevation prescribed in the layer **Recharge** is used to identify the geologic unit and the model layer where recharge is applied.

If more than one stress period is included in the simulation and the recharge stress has been specified to be time-varying in the Stresses/Solvers dialog, then the recharge rates should be entered into the spaces provided for each stress period in the dialog that appears when entering or editing information in the layer **Recharge**. If the recharge stress has been specified to be steady in the Stresses/Solvers dialog, then it is sufficient to specify only the recharge rate in the first stress period.

Evapotranspiration Information Layer

Evapotranspiration

In MODFLOW-96, the evapotranspiration stress is applied as a two-dimensional spatial distribution of the evapotranspiration rate given in units of length per time, or equivalently, length cubed per time per unit area. The volumetric evapotranspiration rate applied to each model cell is automatically calculated based on the area of the cell. If finite-difference discretization changes, the evapotranspiration rate for each cell is automatically recalculated. The spatial variability of parameters associated with the evapotranspiration (evapotranspiration surface, evapotranspiration extinction depth and the evapotranspiration rate) can be specified similarly to that discussed for the layer **Initial Head Unit[i]**.

The vertical distribution of the evapotranspiration rate depends on the evapotranspiration option specified in the Stresses/Solvers dialog. If the evapotranspiration option is specified to apply evapotranspiration to the top model layer only, then the evapotranspiration surface is not used to specify the vertical location for applying the evapotranspiration rate.

If the evapotranspiration option in the Stresses/Solvers dialog box in the MODFLOW-96 Preprocessor is specified to apply evapotranspiration based on the evapotranspiration surface, then the spatial distribution of the evapotranspiration surface elevation prescribed in the layer **Evapotranspiration** is used to identify the geologic unit and the model layer where evapotranspiration is applied.

If more than one stress period is included in the simulation and the evapotranspiration stress has been specified to be time-varying in the Stresses/Solvers dialog, then the evapotranspiration rates should be entered into the spaces provided for each stress period in the dialog that appears when entering or editing information in the layer **Evapotranspiration**. If the recharge stress has been specified to be steady in the Stresses/Solvers dialog, then it is sufficient to specify only the recharge rate in the first stress period.

Well Information Layers

Wells Unit[i]

Wells are specified in the Well Unit[i] layer by using the point contour tool from the tool palette, copying point objects from other layers such as map layers or importing information from text, DXF or ARC/Info Shape files. Clicking in the work space using the point contour tool places a well where the cursor is located. A dialog box appears where the well information is entered. The well is defined by the elevation of the top of the open interval in the geologic unit, the elevation of the bottom of the open interval in the geologic unit and the stress in units of cubic length per time (positive values indicating recharge and negative values indicating withdrawals from the geologic unit). Moving the cursor to a point object and double clicking on it will show the well information associated with that object.

If the geologic unit is divided into several model layers, the cells in the vertical dimension intersected by the open interval of the well will be specified in the preprocessor and

the appropriate amount of the recharge or pumping rate will be automatically applied to each cell according to its length in the cell.

If more than one stress period is included in the simulation and the well stress has been specified to be time-varying in the Stresses/Solvers dialog, then the recharge or pumping rate should be entered into the space provided for each stress period. If the well stress has been specified to be steady in the Stresses/Solvers dialog, then it is sufficient to specify only the pumping or recharge in the first stress period.

River Information Layers

Rivers can be specified as being “line” rivers or “area” rivers. Similar information is requested with the exception of the conductance of the bottom of the river. The conductance per unit length of a “line” river is specified in units of length per time. The length of the “line” river within a model cell multiplied by the conductance per unit length will yield the total conductance of that river in the model cell. Similarly, for an “area” river, the conductance per unit area is specified in units of inverse time. The area of the “area” river in a cell multiplied by the conductance per unit area associated with the “area” river yields the total conductance of the river in the model cell. With these definitions of parameters for “line” and “area” rivers, it is not necessary for the user to have prior knowledge of the total conductance or the length of the “line” river or the area of an “area” river in a model cell; this information is calculated internally by the preprocessor. Thus, it is not necessary to change the conductance applied to a river if the discretization of the finite-difference grid is changed.

Line River Unit[i]

Line rivers are specified using the line contour tool to the left of the work space. After using the line contour tool to specify the location of a segment of a line river, a dialog appears where information associated with that segment of the river is entered. The information required for the line river is the conductance per unit length in units of length per time, the bottom elevation of the river and the stage of the river for each stress period. If the river stress was specified to be “steady” in the Stresses/Solvers dialog, then it is necessary to enter only the stage associated with the first stress period.

The attributes defining the line river in the dialog are assumed to be constant over the length of the line contour specified in the work space. To incorporate varying properties over the length of the river, for example, conductance, bottom and stage, segments of line rivers must be placed end to end. To accommodate this, the **Allow Intersection** command in the **Special** pull-down menu should be used. If the **Allow Intersection** command is active, a check mark will appear next to it in the pull-down menu. The **Allow Intersection** command allows contours to intersect each other, such as placing segments of a line river end to end.

If there is more than one model layer in the geologic unit, the location of the line river in the vertical direction will depend on the elevation associated with the bottom of the line riverbed. The river will be located within the model layer that contains the bottom elevation of the riverbed.

Area River Unit[i]

Area rivers are specified using the closed contour tool to the left of the work space. After using the closed contour tool to specify the location of a segment of an area river, a dialog appears where information associated with that segment of the river is entered. The information required for the area river is the conductance per unit area in units of inverse time, the bottom elevation of the river and the stage of the river for each stress period. If the river stress was specified to be “steady” in the Stresses/Solvers dialog, then it is necessary to enter only the stage associated with the first stress period.

The attributes defining the area river in the dialog are assumed to be constant over the area of the closed contour specified in the work space. To incorporate varying properties over the length of the area river, for example, conductance, bottom and stage, segments of area rivers must be placed end to end. To accommodate this, the **Allow Intersection** command in the **Special** pull-down menu should be used. If the **Allow Intersection** command is active, a check mark will appear next to it in the pull-down menu. The **Allow Intersection** command allows contours to intersect each other, such as placing segments of an area river end to end.

If there is more than one model layer in the geologic unit, the location of the area river in the vertical direction will depend on the elevation associated with the bottom of the area riverbed. The river will be located within the model layer that contains the bottom elevation of the riverbed.

Drain Information Layers

Drains can be specified as being “line” drains or “area” drains. Similar information is requested with the exception of the conductance of drain. The conductance per unit length of a “line” drain is specified in units of length per time. The length of the “line” drain within a model cell multiplied by the conductance per unit length will yield the total conductance of that drain in the model cell. Similarly, for an “area” drain, the conductance per unit area is specified in units of inverse time. The area of the “area” drain in a cell multiplied by the conductance per unit area associated with the “area” drain yields the total conductance of the drain in the model cell. With these definitions of parameters for “line” and “area” drains, it is not necessary for the user to have prior knowledge of the total conductance or the length of the “line” drain or the area of an “area” drain in a model cell; this information is calculated internally by the preprocessor. Thus, it is not necessary to change the conductance applied to a drain if the discretization of the finite-difference grid is changed.

Line Drain Unit[i]

Line drains are specified using the line contour tool to the left of the work space. After using the line contour tool to specify the location of a segment of a line drain, a dialog appears where information associated with that segment of the drain is entered. The information required for the line drain is the conductance per unit length in units of length per time, the elevation of the drain, and whether the drain is operating or not during the stress period. If the drain is operating, a value of “True” is used, otherwise a value of “False” is used. If the drain stress was specified to be “steady” in the Stresses/Solvers dialog, then it is necessary to enter the operation of the drain in the first stress period only.

The attributes defining the line drain in the dialog are assumed to be constant over the length of the line contour specified in the work space. To incorporate varying properties over the

length of the drain, for example, conductance, elevation and operation, segments of line drains must be placed end to end. To accommodate this, the **Allow Intersection** command in the **Special** pull-down menu should be used. If the **Allow Intersection** command is active, a check mark will appear next to it in the pull-down menu. The **Allow Intersection** command allows contours to intersect each other, such as placing segments of a line drain end to end.

If there is more than one model layer in the geologic unit, the location of the line drain in the vertical direction will depend on the elevation associated with the line drain. The drain will be located within the model layer that contains the elevation of the drain.

Area Drain Unit[i]

Area drains are specified using the closed contour tool to the left of the work space. After using the closed contour tool to specify the location of a segment of an area drain, a dialog appears where information associated with that segment of the drain is entered. The information required for the area drain is the conductance per unit area in units of inverse time, the elevation of the drain, and whether the drain is operating or not during the stress period. If the drain is operating, a value of “True” is used, otherwise a value of “False” is used. If the drain stress was specified to be “steady” in the Stresses/Solvers dialog, then it is necessary to enter the operation of the drain in the first stress period only.

The attributes defining the area drain in the dialog are assumed to be constant over the closed contour specified in the work space. To incorporate varying properties over the area of the drain, for example, conductance, elevation and operation, segments of area drains must be placed end to end. To accommodate this, the **Allow Intersection** command in the **Special** pull-down menu should be used. If the **Allow Intersection** command is active, a check mark will appear next to it in the pull-down menu. The **Allow Intersection** command allows contours to intersect each other, such as placing segments of an area drain end to end.

If there is more than one model layer in the geologic unit, the location of the area drain in the vertical direction will depend on the elevation associated with the area drain. The drain will be located within the model layer that contains the bottom elevation of the drain.

General Head Boundary Information Layers

General head boundary stresses can be specified as being a “point,” “line” or “area.” Similar information is requested with the exception of the conductance of each. A “point” general head boundary stress requires conductance to be given in units of length squared per time. A “line” general head boundary stress requires conductance to be given in units of length per time. An “area” general head boundary requires conductance to be given in units of inverse time. With these definitions of parameters for “line” and “area” general head boundary stresses, it is not necessary for the user to have prior knowledge of the total conductance of the general head boundary in a model cell; this information is calculated internally in the preprocessor by using the length and area of the “line” and “area” general head boundary stress, respectively. Thus, it is not necessary to change the conductance applied to a general head boundary stress if the discretization of the finite-difference grid is changed. If a “point” general head boundary stress is applied, however, changing discretization will not change the conductance of the stress. Thus, the user should use caution in applying “point” general head boundary stresses when

changing discretization in the finite-difference grid because the same conductance is applied regardless of the discretization.

Point Gen Head Boundary Unit[i]

Point general head boundary stresses are specified using the point contour tool from the tool palette. After using the point contour tool to specify the location of a general head boundary stress, a dialog appears where information associated with that stress is entered. The information required for the point general head boundary stress is the conductance in units of length squared per time, and boundary head for each stress period. If the general head boundary stress was specified to be “steady” in the Stresses/Solvers dialog, then it is necessary to enter the boundary head in the first stress period only.

The application of the point general head boundary stress in the geologic unit assumes that the stress is applied over the thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model layer, each cell in the vertical direction will be given attributes associated with the point general head boundary stress.

Line General Head Boundary Unit[i]

Line general head boundary stresses are specified using the line contour tool to the left of the work space. After using the line contour tool to specify the location of a general head boundary stress, a dialog appears where information associated with that stress is entered. The information required for the line general head boundary is the conductance per unit length in units of length per time, and boundary head for each stress period. If the general head boundary stress was specified to be “steady” in the Stresses/Solvers dialog, then it is necessary to enter the boundary head in the first stress period only.

The attributes defining the line general head boundary stress in the dialog are assumed to be constant over the line contour specified in the work space. To incorporate varying properties over the length of a general head boundary stress, for example, the conductance and boundary head, segments of area general head boundary stresses must be placed end to end. To accommodate this, the **Allow Intersection** command in the **Special** pull-down menu should be used. If the **Allow Intersection** command is active, a check mark will appear next to it in the pull-down menu. The **Allow Intersection** command allows contours to intersect each other, such as placing segments of an area general head boundary stress end to end.

The application of the line general head boundary stress in the geologic unit assumes that the stress is applied over the thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model layer, each cell in the vertical direction will be given attributes associated with the line general head boundary stress.

Area General Head Boundary Unit[i]

Area general head boundary stresses are specified using the closed contour tool to the left of the work space. After using the closed contour tool to specify the location of a general head boundary stress, a dialog appears where information associated with that stress is entered. The information required for the area general head boundary is the conductance per unit area in units of inverse time, and boundary head for each stress period. If the general head boundary stress

was specified to be “steady” in the Stresses/Solvers dialog, then it is necessary to enter the boundary head in the first stress period only.

The attributes defining the area general head boundary stress in the dialog are assumed to be constant over the closed contour specified in the work space. To incorporate varying properties over the area of the general head boundary stress, for example, the conductance and boundary head, segments of area general head boundary stresses must be placed end to end. To accommodate this, the **Allow Intersection** command in the **Special** pull-down menu should be used. If the **Allow Intersection** command is active, a check mark will appear next to it in the pull-down menu. The **Allow Intersection** command allows contours to intersect each other, such as placing segments of an area general head boundary stress end to end.

The application of the area general head boundary stress in the geologic unit assumes that the stress is applied over the thickness of the geologic unit. Therefore, if the geologic unit is divided into more than one model layer, each cell in the vertical direction will be given attributes associated with the area general head boundary stress.

Finite-Difference Grid Information Layers

The information layers associated with the finite-difference discretization and the finite-difference grid are presented last in this section because, in general, a modeling project should proceed by acquiring or generating the topographic and hydrologic information first, and then evaluating this information in order to specify where increased discretization is warranted to capture the spatially varying attributes of the geospatial information. Because geospatial information is specified independently of the finite difference grid in ArgusNE, rediscretization does not require the user to respecify the underlying geospatial information.

MODFLOW Grid Density

The layer **MODFLOW Grid Density** is an ArgusNE information layer that is used by the **MODFLOW FD Grid** layer to define the discretization of the finite difference grid. Regions where increased or decreased discretization may be warranted can be prescribed in the **MODFLOW Grid Density** layer. The point, line and closed contour tools can be used to specify the approximate distance between finite-difference grid lines in regions of the modeled domain. After using one of the contour tools, a dialog will appear where the finite-difference grid density is entered; the density is the approximate distance between finite difference grid lines. Examples of using the density layer to specify the finite-difference discretization are described in the ArgusNE User’s Guide.

If grid density is not specified, the density specified in the layer **MODFLOW Domain Outline** is used in creating the finite difference grid.

MODFLOW FD Grid

If the model domain outline has been specified in the layer **MODFLOW Domain Outline**, the finite-difference grid can be generated automatically using the magic wand tool from the tool palette. A discussion of the operation of the tools in the grid layer can be found in the ArgusNE User’s Guide. These tools can be used to edit the horizontal and vertical grid lines.

The finite-difference grid is assumed to be extruded in the vertical dimension and applies to all geologic units. Thus, any changes made in finite-difference grid are extruded to all geologic units. Inactive cells outside the modeled domain are noted as thatched areas. However, each geologic unit can have additional inactive cells as specified in the layer **Added Inactive Area Unit[i]**.

Grid Type, Grid Direction and other Grid Operations

In the **Edit** pull-down menu of the layer **MODFLOW FD Grid**, the commands **Grid Type** allows the user to modify the type of finite difference grid used in the simulation. In the preprocessor for MODFLOW-96, it is assumed that a **Block-Centered** finite-difference grid is used; this is the default setting and it should not be changed when using the preprocessor described in this report.

The command **Grid Direction** in the **Edit** pull-down menu allows the user to specify the direction in which grid information (that is, geospatial information linked to the grid) is exported. To be consistent with previous uses of MODFLOW, it is recommended that the grid direction be specified as **Positive X** and **Negative Y**; the user should make these changes using the **Grid Direction** menu item. Among other things, this will ensure that the listing of model parameters and results in files generated by MODFLOW-96 will appear in matrix form in the same orientation as the finite-difference grid on the screen; the top row of cells on the screen will correspond to the top row of model parameters and results for each model layer given in the files that are created. Here it is assumed that orientation of (positive) x-axis is to the right of the work space and the orientation of the (positive) y-axis is to the top of the work space.

The **Toggle Active** menu in the **Edit** menu can be used to make selected finite-difference grid cells inactive or active. For example, this command may be useful in making selected grid cells active or inactive along a complexly shaped domain boundary that may isolate grid cells from the remainder of the grid because of the density of the discretization that is applied. The use of the **Toggle Active** command and other grid operations are described in the ArgusNE User's Guide.

Adding Geospatial Information Layers

The list of geospatial information layers created in the MODFLOW-96 preprocessor and discussed above are directly correlated to the information that is used in the numerical model. In many ground-water modeling projects, however, model information required for the simulation may not be available, while proxy information that may be used to infer hydrogeologic properties may be available. For example, instead of having information on hydraulic conductivity, the spatial distribution of soil types may be available. If hydraulic conductivity can be inferred from soil types, then the hydraulic conductivity could be linked to this information.

Geospatial information layers can be added to the layers already created by the MODFLOW-96 preprocessor. Using the example above, a geospatial information layer for soil types for each geologic unit can be added and a mathematical expression can be prepared to correlate the proxy information to the information required in the numerical model. The ArgusNE User's Guide provides the details of adding information layers and linking information layers to other information layers using mathematical expressions. Thus, the list of geospatial information layers created in the MODFLOW-96 preprocessor should be regarded as a

rudimentary structure that can be adapted to the unique demands of each modeling project. By adding geospatial information layers, a seamless computing environment can be created for ground-water flow modeling within one application, rather than performing correlations with proxy information externally and importing the results.

Although geospatial information layers can be added, the geospatial information layers created by the MODFLOW-96 preprocessor should not be deleted or renamed manually. The names of the geospatial information layers created by the MODFLOW-96 preprocessor are needed to link the geospatial information to the finite-difference grid and export this information in a form that can be read by MODFLOW-96. If the geospatial information layers are deleted or changed, the data files created for MODFLOW-96 might be corrupted.

VISUALIZING GEOSPATIAL INFORMATION LINKED TO THE FINITE-DIFFERENCE GRID

It is advantageous to visualize the effect of the finite-difference discretization on the geospatial information that is used in the numerical model. For example, visualizing the geospatial information linked to the finite-difference grid may indicate if discretization is too coarse to capture the spatially varying nature of certain hydrologic properties. Visualization of geospatial information linked to the finite-difference grid is conducted in the layer **MODFLOW FD Grid**. Making this the active layer and using the cursor to click-hold the triangle to the right of the color legend in the tool palette opens a menu with the list of the parameters linked to the finite-difference grid. Moving the cursor to one of parameters on the list and releasing the mouse button will visualize the information in the selected parameter as it is linked to the finite-difference grid. The mathematical statements used to link the geospatial information to the finite-difference grid can be seen in the **Layers dialog** under the parameters linked to the layer **MODFLOW FD Grid**. In addition, the spatial information attributed to a finite-difference cell can be examined by doubling clicking on the cell in the layer **MODFLOW FD Grid**; a dialog box appears with a list of the parameter values linked to that finite-difference cell.

In the following, the geospatial information linked to the finite-difference grid by the MODFLOW-96 preprocessor is described. References to geologic units are denoted by [i], where the “i” denotes the sequence number of the geologic unit. Furthermore, geospatial information layers denoted by [i] indicate that a geospatial information layer of that type will be created for each geologic unit specified in the Geology dialog in the MODFLOW-96 Preprocessor.

Visualization of Topographic Information

Elev Top Unit[i]

Selecting **Elev Top Unit[i]** evaluates by color the grid cell values from the layer **Elevation Top Unit[i]**.

Elev Bot Unit[i]

Selecting **Elev Bot Unit[i]** evaluates by color the grid cell values from the layer **Elevation Bottom Unit[i]**.

Thickness Unit[i]

Selecting **Thickness Unit[i]** evaluates by color the grid cell values from the difference between the layer **Elevation Top Unit[i]** and **Elevation Bottom Unit[i]**.

Visualization of Hydrogeologic Information

IBOUND Unit[i]

The IBOUND array in MODFLOW-96 defines the location of active cells, inactive cells and cells having a prescribed hydraulic head. Inactive cells are assigned a value of zero, active cells are assigned a value of one and cells having a prescribed head are assigned a value of negative one. Selecting **IBOUND Unit[i]** evaluates by color the grid cell values for the IBOUND array. The layers **Added Inactive Area Unit[i]** and **Prescribed Head Unit[i]** are used to define the parameter **IBOUND Unit[i]**.

Initial Head Unit[i]

Selecting **Initial Head Unit[i]** evaluates by color the grid cell values from the layer **Initial Head Unit[i]**.

Kx Unit[i]

Selecting **Kx Unit[i]** evaluates by color the grid cell values from the parameter K_x in the layer **Hydraulic Conductivity Unit[i]**.

Kz Unit[i]

Selecting **Kz Unit[i]** evaluates by color the grid cell values from the parameter K_z in the layer **Hydraulic Conductivity Unit[i]**.

Sp_Yield Unit[i]

Selecting **Sp_Yield Unit[i]** evaluates by color the grid cell values from the layer **Specific Yield Unit[i]**.

Sp_Storage Unit[i]

Selecting **Sp_Storage Unit[i]** evaluates by color the grid cell values from the layer **Specific Storage Unit[i]**.

Wetting Unit[i]

Selecting **Wetting Unit[i]** evaluates by color the grid cell values of the product of the wetting threshold and the wetting flag parameters specified in the layer **Wetting Threshold Unit[i]**.

Visualization of Fluid Stresses

Recharge Elevation

Selecting **Recharge Elevation** evaluates by color the grid cell values of the parameter recharge elevation that appears in the layer **Recharge**. The recharge elevation is used only if the recharge option in the Stresses/Solvers dialog indicates that the application of the recharge is to be specified from the recharge elevation.

ET Surface Elevation

Selecting **ET Surface Elevation** evaluates by color the grid cell values of the parameter evapotranspiration surface specified in the layer **Evapotranspiration**.

Well Location Unit[i]

The wells specified in the layer **Wells Unit[i]** are visualized in **Well Location Unit[i]**. The grid cells with one or more wells are given a value of one; grid cells without wells are given a value of zero. If more than one well is located in a grid cell, the preprocessor for MODFLOW-96 will export information associated with each well individually for use in MODFLOW-96.

River Location Unit[i]

The grid cells occupied by line and area rivers from the layers **Line River Unit[i]** and **Area River Unit[i]** are visualized in **River Location Unit[i]**. The grid cells with one or more line or area rivers are given a value of one; grid cells without line or area rivers are given a value of zero. If more than one line or area river is located in a grid cell, the preprocessor for MODFLOW-96 will export information associated with each river individually for use in MODFLOW-96.

Drain Location Unit[i]

The grid cells occupied by line and area drains from the layers **Line Drain Unit[i]** and **Area Drain Unit[i]** are visualized in **Drain Location Unit[i]**. The grid cells with one or more line or area drains are given a value of one; grid cells without line or area drains are given a value of zero. If more than one line or area drain is located in a grid cell, the preprocessor for MODFLOW-96 will export information associated with each drain individually for use in MODFLOW-96.

Gen Head B Location Unit[i]

The grid cells occupied by point, line and area general-head boundary stresses from the layers **Point Gen Head Boundary Unit[i]**, **Line Gen Head Boundary Unit[i]** and **Area Gen Head Boundary Unit[i]** are visualized in **Gen Head B Location Unit[i]**. The grid cells with one or more point, line or area general-head boundary stresses are given a value of one; grid cells without general-head boundary stresses are given a value of zero. If more than one general-head boundary stress is located in a grid cell, the preprocessor for MODFLOW-96 will export information associated with each individually for use in MODFLOW-96.

Adding Parameters Linked to the Finite-Difference Grid

The list of parameters linked to the finite-difference grid for visualization in the MODFLOW-96 preprocessor can be expanded according to the unique needs of each modeling project. The ArgusNE User's Guide provides the details of adding and linking parameters to the finite-difference grid. Thus, the list of parameters linked to the finite-difference grid for visualization as created in the MODFLOW-96 preprocessor should be regarded as a rudimentary structure that can be adapted to the unique demands of each modeling project.

Although additional parameters can be linked to the finite-difference grid, it is not recommended that existing parameters linked to the finite-difference grid be deleted. Deleting parameters linked to the finite-difference grid would reduce the ability to visualize the effect of discretization on geospatial information used in MODFLOW-96 simulations.

CREATING DATA FILES AND EXECUTING MODFLOW-96

The file MODFLOW.MET in the ArgusPIE directory is the export template used by MFGUI_10.DLL to export and format the ASCII files needed to execute MODFLOW-96. The MODFLOW.MET file synthesizes the project information and geospatial information linked to the finite-difference grid and exports this information in a format that can be read by the executable version of MODFLOW-96. In addition, MODFLOW-96 can be executed from within ArgusNE and the hydraulic head and/or drawdown solutions from MODFLOW-96 can be visualized, thus, creating a seamless computing environment for ground-water simulations.

The ASCII files used to execute MODFLOW-96 are created from the **MODFLOW FD Grid** layer in ArgusNE. While in the **MODFLOW FD Grid** layer, the cursor is moved to the **Export** command in the **File** pull-down file menu. The **Export** command is a hierarchical menu, and within this hierarchical menu the **Run MODFLOW** command is chosen. A dialog box appears with two options, "Create MODFLOW Input Files" and "Create MODFLOW Input Files and Run MODFLOW." The first option only creates the ASCII files suitable for execution of MODFLOW-96; these files contain the simulation control information and the geospatial information linked to the finite-difference grid. The second option creates the ASCII files and then executes MODFLOW-96 from within ArgusNE, after which control is returned to ArgusNE. Also listed on this dialog box is an option to return to the MODFLOW-96 Preprocessor dialog boxes to edit or check the project information; clicking the **Edit Parameters** button returns to the MODFLOW-96 Preprocessor dialog boxes.

Choosing either the “Create MODFLOW Input Files” or “Create MODFLOW Input Files and Run MODFLOW” option leads to a dialog box in which the directory needs to be specified for storing the files created for executing MODFLOW-96. The file name at the bottom of this dialog box can be ignored because the root name of the files to be created and the extensions for these files are specified in the Output Files dialog box and in the export template. If the user wishes to run MODFLOW-96 from within ArgusNE, the directory containing the executable version of MODFLOW-96 should be chosen.

If it is desirable, the ASCII files created from ArgusNE for executing MODFLOW-96 can be viewed by using any text editor. It may be desirable to view and edit these files created for MODFLOW-96 if the user is familiar with the file structure and data input for MODFLOW-96 and only minor changes are needed for additional simulations. However, it is also possible and easier to make these changes in the MODFLOW-96 Preprocessor dialog boxes and have the file exported again.

Files Created for MODFLOW-96 Simulations

The files that are created for executing MODFLOW-96 will depend on the stress packages and solver used in the simulation. The following is a list and explanation of file names that are created by the preprocessing PIE for MODFLOW-96. In the following, *Rootname* refers to the file name specified in the Output Files dialog box of the MODFLOW-96 Preprocessor.

modflow.bf is the “batch” file containing the “name” file for the MODFLOW-96 simulation. Executing MODFLOW-96 from within ArgusNE executes MODFLOW-96 in a “batch” mode so that additional keyboard input is not needed. If it is desirable to execute MODFLOW-96 outside of ArgusNE, this “batch” file can be used to execute the files that have been created from within ArgusNE. Information about executing MODFLOW-96 in a “batch” mode are discussed in Harbaugh and McDonald (1996a). This file will always be created by the preprocessing PIE for MODFLOW-96.

Rootname is the “name” file containing the list of files and their unit numbers for the MODFLOW-96 simulation, where *Rootname* is the file name specified in the Output Files dialog box given in the MODFLOW-96 Preprocessor. This file will always be created by the preprocessing PIE for MODFLOW-96.

Rootname.BAS is the file containing information associated with the Basic package in MODFLOW-96. This file will always be created by the preprocessing PIE for MODFLOW-96.

Rootname.OC is the Output Control file for the MODFLOW-96 simulation. This file will always be created by the preprocessing PIE for MODFLOW-96.

Rootname.BCF is the file containing information for the Block-Centered Flow package. This file will always be created by the preprocessing PIE for MODFLOW-96.

Rootname.RCH is the file containing information for the Recharge package; this file is created only if the recharge package is chosen in the Stresses/Solvers dialog box.

Rootname.RIV is the file containing information for the River package; this file is created only if the river package is chosen in the Stresses/Solvers dialog box.

Rootname.WEL is the file containing information for the Well package; this file is created only if the well package is chosen in the Stresses/Solvers dialog box.

Rootname.DRN is the file containing information for the Drain package; this file is created only if the drain package is chosen in the Stresses/Solvers dialog box.

Rootname.GHB is the file containing information for the General-Head Boundary package; this file is created only if the general-head boundary package is chosen in the Stresses/Solvers dialog box.

Rootname.EVT is the file containing information for the Evapotranspiration package; this file is created only if the evapotranspiration package is chosen in the Stresses/Solvers dialog box.

Rootname.SIP is the file containing information for the Strongly-implicit procedure package; this file is created only if SIP solver is chosen in the Stresses/Solvers dialog box.

Rootname.SOR is the file containing information for the Slice-successive overrelaxation package; this file is created only if the SOR solver is chosen in the Stresses/Solvers dialog box.

Rootname.PCG is the file containing information for the preconditioned conjugate-gradient package; this file is created only if the PCG solver is chosen in the Stresses/Solvers dialog box.

Rootname.DE4 is the file containing information for the direct solution package with alternating diagonal ordering package; this file is created only if the DE4 solver is chosen in the Stresses/Solvers dialog box.

Files Created by Executing MODFLOW-96

The files that are optionally created by executing MODFLOW-96 are defined in the Output Files dialog in the MODFLOW-96 Preprocessor. In addition, the MODFLOW-96 listing file, given the name *Rootname.LST*, will always be generated by MODFLOW-96. The following is a list and explanation of file names that are created by executing MODFLOW-96 if the preprocessing PIE discussed in this report is being used. In the following, *Rootname* refers to the file name specified in the Output Files dialog box.

Rootname.LST is the MODFLOW-96 listing file containing general information about the simulation. This file is always created by MODFLOW-96.

Rootname.FHD is the formatted text file containing the hydraulic head solutions for the time steps specified in the Output Controls dialog. The hydraulic head solution for all layers in the simulation are exported into this file. This file will be created by MODFLOW-96 only if formatted text files for the hydraulic head have been specified in the Output Files dialog. The postprocessing visualization of hydraulic head that is described in this report uses this file.

Rootname.FDN is the formatted text file containing the drawdown solutions for the time steps specified in the Output Controls dialog. The drawdown solution for all layers in the simulation are exported into this file. This file will be created by MODFLOW-96 only if formatted text files for the drawdown have been specified in the Output Files dialog. The postprocessing visualization drawdown that is described in this report uses this file.

Rootname.BHD is the file containing the hydraulic head solutions written in a binary format for the time steps specified in the Output Controls dialog. The hydraulic head solution for all layers in the simulation are exported into this file. This file will be created by MODFLOW-96 only if a binary file for the hydraulic head solution has been specified in the Output Files dialog.

Rootname.BDN is the file containing the drawdown solutions written in a binary format for the time steps specified in the Output Controls dialog. The drawdown solution for all layers in the simulation are exported into this file. This file will be created by MODFLOW-96 only if a binary file for the drawdown solution has been specified in the Output Files dialog.

Rootname.BUD is the file of cell-by-cell flows from the Block-Centered Flow package, if it is specified in the Output Files dialog that the cell-by-cell flow from the Block-Centered Flow package are to be exported. Furthermore, if in the Output Files dialog, it is specified that all cell-by-cell flows from all fluid stresses are to be exported into a single file, the cell-by-cell flows from the stresses marked in the Output Files dialog will be exported into this file. This file is created in a binary format.

Rootname.BWE is the file of cell-by-cell flows from the well package, if it is specified in the Output Files dialog that cell-by-cell flows from the well package are to be exported, and the export of this information is to be placed in a separate file. This file is created in a binary format.

Rootname.BRC is the file of cell-by-cell flows from the recharge package, if it is specified in the Output Files dialog that cell-by-cell flows from the recharge package are to be exported, and the export of this information is to be placed in a separate file. This file is created in a binary format.

Rootname.BDR is the file of cell-by-cell flows from the drain package, if it is specified in the Output Files dialog that cell-by-cell flows from the drain package are to be exported, and the export of this information is to be placed in a separate file. This file is created in a binary format.

Rootname.BRI is the file of cell-by-cell flows from the river package, if it is specified in the Output Files dialog that cell-by-cell flows from the river package are to be exported, and the export of this information is to be placed in a separate file. This file is created in a binary format.

Rootname.BEV is the file of cell-by-cell flows from the evapotranspiration package, if it is specified in the Output Files dialog that cell-by-cell flows from the evapotranspiration package are to be exported, and the export of this information is to be placed in a separate file. This file is created in a binary format.

Rootname.BGH is the file of cell-by-cell flows from the general-head boundary package, if it is specified in the Output Files dialog that cell-by-cell flows from the general-head boundary package are to be exported, and the export of this information is to be placed in a separate file. This file is created in a binary format.

VISUALIZING HYDRAULIC HEAD AND DRAWDOWN SOLUTIONS FROM MODFLOW-96

The quick visualization of model results is important in facilitating the modeling process so that changes in project information and geospatial information can be made and additional simulation can be conducted with minimum delay. For this purpose, a postprocessing PIE has been developed for MODFLOW-96 simulation results that have used the preprocessing PIE for MODFLOW-96 in the ArgusNE application. The postprocessing PIE uses the formatted text files for hydraulic head and drawdown generated by executing MODFLOW-96. These files are given the names, *Rootname.FHD* and *Rootname.FDN*, where *Rootname* is the file name specified in the Output Files dialog.

The postprocessing PIE for MODFLOW-96 is launched from within the ArgusNE application. With the file MFPOST10.DLL in the ArgusPIE directory, launching ArgusNE will automatically load the PIE needed to launch the postprocessing interface for MODFLOW-96.

The postprocessing PIE for MODFLOW-96 uses information from the layer **MODFLOW FD Grid**. Therefore, it is necessary to have a project file open with the finite-difference grid that was used to generate the files *Rootname.FHD* and *Rootname.FDN*. If changes have been made in the geospatial information without changing the finite-difference grid, then multiple files with the extension FHD and FDN can be visualized using the same project file even though the current geospatial information has been altered. However, if changes are made in the finite-difference discretization in the layer **MODFLOW FD Grid**, and the visualization of simulations made with previous finite-difference grids is desired, the user should save the project file before making changes in the finite-difference discretization using the **Save As...** command in the **File** pull-down menu.

Launching the Postprocessor

To execute the post processing PIE, the **Import** command in the **File** menu is used. The **Import** command yields a hierarchical menu of import options. Choosing the option **MODFLOW PostProc** launches the postprocessing PIE and causes a file dialog to appear. Files with the extensions FHD and FDN can be chosen from this dialog, as long as these files were created from MODFLOW-96 simulations that used the finite-difference grid in the layer **MODFLOW FD Grid** of the current project file.

The postprocessing PIE reads the file that is chosen and a dialog appears giving a listing of solutions for hydraulic head or drawdown (Figure 16). For each model layer that is contained in the file, the stress period, the time step and the data type (hydraulic head or drawdown) is also specified; in the dialog, stress period is abbreviated by **SP** and time step is abbreviated by **S**. The cursor is used to highlight one or more of the solutions for model layers by clicking on one or more rows in the dialog. Clicking **OK** causes another dialog to appear where the type of postprocessing visualization is to be specified (Figure 17). The types of postprocessing methods are Contour Map, Color Map, 3D Surface Map and Cross Section. Clicking on one of these postprocessing methods and clicking **OK** results in two layers being added to the project file. These layers are titled **MODFLOW Data** and **MODFLOW Post Processing Charts**. These layers can be seen in the list of layers in the floating layers. The layer **MODFLOW Data** is an ArgusNE data layer and the layer **MODFLOW Post Processing Charts** is an ArgusNE maps layer. Making the layer **MODFLOW Post Processing Charts** the active layer shows the postprocessing objects that have been created; it may be necessary to hide other layers in order to clearly see the postprocessing charts that were created.




Figure 16. Data dialog for MODFLOW-96 postprocessor.




Figure 17. Visualization dialog for MODFLOW-96 postprocessor.

The layer **MODFLOW Data** contains the solutions that have been imported for visualization. This data appears as discrete points located at the center of the grid cells. The solutions in this data layer can be used for purposes other than the visualization that appears in the layer **MODFLOW Post Processing Charts**. For example, the solutions in the layer **MODFLOW Data** can be compared with measured hydraulic heads or drawdowns, if such information has been entered into geospatial information layers. It is then possible to create and visualize a new parameter linked to the finite-difference grid which gives the difference between the measured hydraulic head and the hydraulic head solutions.

In the following, a brief description of the postprocessing methods is given. Additional information on creating and modifying the appearance of postprocessing objects in Argus NE is given in the ArgusNE User's Guide.

Contour Map

Selecting the contour map option produces a contour map of the hydraulic head or drawdown in the selected layers for the selected time steps in the selected stress periods. If only one layer is selected, the hydraulic head or drawdown contour map will overlay the finite-difference grid. If more than layer is selected, then the selected contour maps will be scaled and placed in the layer **MODFLOW Post Processing Charts**.

Clicking on a postprocessing object in the layer **MODFLOW Post Processing Charts** will bring up a dialog box that can be used to alter the appearance of the contour map. Additional information on editing the appearance of contour maps can be found in the ArgusNE User's Guide.

Color Map

Selecting the color map option produces a colorized interpolation of the hydraulic head or drawdown in the selected layers for the selected time steps in the selected stress periods. If only one layer is selected, the hydraulic head or drawdown color map will overlay the finite-difference grid. If more than layer is selected, then the selected contour maps will be scaled and placed in the layer **MODFLOW Post Processing Charts**.

Clicking on a postprocessing object in the layer **MODFLOW Post Processing Charts** will bring up a dialog box that can be used to alter the appearance of the color map. Additional information on editing the appearance of color maps can be found in the ArgusNE User's Guide.

Three-Dimensional Surface Map

Selecting the three-dimensional surface map option produces a colorized three-dimensional perspective map of the hydraulic head or drawdown in the selected layers for the selected time steps in the selected stress periods.

Clicking on a postprocessing object in the layer **MODFLOW Post Processing Charts** will bring up a dialog box that can be used to alter the appearance of the three-dimensional surface map. Additional information on editing the appearance of surface maps can be found in the ArgusNE User's Guide.

Cross Section

Selecting the cross-section option produces a plot of the hydraulic head or drawdown as a function of distance along a line through the modeled domain. The hydraulic head or drawdown from more than one layer can be included on the cross-section by choosing more than one layer in the Data dialog for the MODFLOW-96 postprocessor. The orientation of the line and other attributes of the plot of the cross section can be adjusted by double clicking on the

postprocessing object. Additional information on editing the appearance of cross-sectional plots can be found in the ArgusNE User's Guide.

REFERENCES

- Argus Interware, 1997a, Argus Numerical Environments and MeshMaker User's Guide, 463 p.
- Argus Interware, 1997b, Argus Numerical Environments PIE Technical Notes, 31 p.
- Goode, D. J., and Appel, C. A., 1992, Finite-difference interblock transmissivity for unconfined aquifers and for aquifers having smoothly varying transmissivity: U.S. Geological Survey Water-Resources Investigations Report 92-4124, 79 p.
- Harbaugh, A. W., 1995, Direct solution package based on alternating diagonal ordering for the U.S. Geological Survey modular finite-difference ground-water flow model: U.S. Geological Survey Open-File Report 95-288, 46 p.
- Harbaugh, A. W., and McDonald, M. G., 1996a, User's documentation for MODFLOW-96, An update to the U.S. Geological Survey modular finite-difference ground-water flow model: U.S. Geological Survey Open-File Report 96-485, 56 p.
- Harbaugh, A. W., and McDonald, M. G., 1996b, Programmer's documentation for MODFLOW-96, An update to the U.S. Geological Survey modular finite-difference ground-water flow model: U.S. Geological Survey Open-File Report 96-486, 220 p.
- Hill, M. C., 1990, Preconditioned conjugate-gradient 2 (PCG2), A computer program for solving ground-water flow equations, U.S. Geological Survey Water-Resources Investigations Report 90-4048, 43 p.
- McDonald, M. G., and Harbaugh, A. W., 1988, A modular three-dimensional finite-difference ground-water flow model: Techniques of Water-Resources Investigations of the United States Geological Survey, Book 6, Chapter A1, 586 p.
- McDonald, M. G., Harbaugh, A. W., Orr, B. R., and Ackerman, D. J., 1992, A method of converting no-flow cells to variable-head cells for the U.S. Geological Survey modular finite-difference ground-water flow model: U.S. Geological Survey Open-File Report 91-536, 99 p.