



PRMS-IV, the Precipitation-Runoff Modeling System, Version 4

By Steven L. Markstrom, R. Steven Regan, Lauren E. Hay, Roland J. Viger, Richard M. T. Webb, Robert A. Payn, and Jacob H. LaFontaine

Updated tables for version 4.0.3 – June 19, 2017

Suggested citation:

Markstrom, S.L., Regan, R.S., Hay, L.E., Viger, R.J., Webb, R.M.T., Payn, R.A., and LaFontaine, J.H., 2015, PRMS-IV, the precipitation-runoff modeling system, version 4: U.S. Geological Survey Techniques and Methods, book 6, chap. B7, 158 p.

Any use of trade, product, or firm names is for descriptive purposes only and does not imply endorsement by the U.S. Government.

Table 2. Description of modules implemented in the Precipitation-Runoff Modeling System, version 4 (PRMS-IV).

Module name	Description
Basin definition process	
basin	Defines shared watershed-wide and hydrologic response unit (HRU) physical parameters and variables.
Cascading flow process	
cascade	Determines computational order of the HRUs and groundwater reservoirs for routing flow downslope.
Solar table process	
soltab	Compute potential solar radiation and sunlight hours for each HRU for each day of year; modification of soltab_prms.
Time series data process	
obs	Reads and stores observed data from all specified measurement stations.
Temperature distribution process	
temp_1sta	Distributes maximum and minimum temperatures to each HRU by using temperature data measured at one station and an estimated monthly lapse rate.
temp_laps	Distributes maximum and minimum temperatures to each HRU by computing a daily lapse rate with temperature data measured at two stations.
temp_dist2	Distributes maximum and minimum temperatures to each HRU by using a basin-wide lapse rate applied to the temperature data, adjusted for distance, measured at each station.
climate_hru	Reads distributed temperature values directly from files.
Precipitation distribution process	
precip_1sta	Determines the form of precipitation and distributes it from one or more stations to each HRU by using monthly correction factors to account for differences in altitude, spatial variation, topography, and measurement gage efficiency.
precip_laps	Determines the form of precipitation and distributes it to each HRU by using monthly lapse rates.
precip_dist2	Determines the form of precipitation and distributes it to each HRU by using an inverse distance weighting scheme.
climate_hru	Reads distributed precipitation values directly from files.
Combined climate distribution process	
ide_dist	Determines the form of precipitation and distributes precipitation and temperatures to each HRU on the basis of measurements at stations with closest elevation or shortest distance to the respective HRU.
xyz_dist	Determines the form of precipitation and distributes precipitation and temperatures to each HRU by using a multiple linear regression of measured data from a group of measurement stations or from atmospheric model simulation.
climate_hru	Reads distributed climate values directly from files.
Solar radiation distribution process	
ddsolrad	Distributes solar radiation to each HRU and estimates missing solar radiation data using a maximum temperature per degree-day relation; modification of ddsolrad_prms.
ccsolrad	Distributes solar radiation to each HRU and estimates missing solar radiation data using a relation between solar radiation and cloud cover; modification of ccsolrad_prms.
climate_hru	Reads distributed solar radiation values directly from files.
Transpiration period process	
transp_frost	Determines whether the current time step is in a period of active transpiration by the killing frost

transp_tindex	method. Determines whether the current time step is in a period of active transpiration by the temperature index method.
climate_hru	Reads the state of transpiration directly from files.
Potential evapotranspiration process	
potet_hamon	Computes the potential evapotranspiration by using the Hamon formulation (Hamon, 1961); modification of potet_hamon_prms.
potet_jh	Computes the potential evapotranspiration by using the Jensen-Haise formulation (Jensen and Haise, 1963).
potet_hs	Computes the potential evapotranspiration by using the Hargreaves-Samani formulation (Hargreaves and Samani, 1982).
potet_pt	Computes the potential evapotranspiration by using the Priestley-Taylor formulation (Priestley and Taylor, 1972).
potet_pm	Computes the potential evapotranspiration by using the Penman-Monteith formulation (Penman, 1948; Monteith, 1965) using specified windspeed and humidity in CBH Files.
potet_pan	Computes the potential evapotranspiration for each HRU by using pan-evaporation data.
climate_hru	Reads distributed potential evapotranspiration values directly from files.
Canopy Interception process	
intcp	Computes volume of intercepted precipitation, evaporation from intercepted precipitation, and throughfall that reaches the soil or snowpack.
Snow process	
snowcomp	Initiates development of a snowpack and simulates snow accumulation and depletion processes by using an energy-budget approach.
Surface runoff process	
srunoff_smidx	Computes surface runoff and infiltration for each HRU by using a nonlinear variable-source-area method allowing for cascading flow; modification of srunoff_smidx_prms.
srunoff_carea	Computes surface runoff and infiltration for each HRU by using a linear variable-source-area method allowing for cascading flow; modification of srunoff_carea_prms.
Soil-zone process	
soilzone	Computes inflows to and outflows from soil zone of each HRU and includes inflows from infiltration, groundwater, and upslope HRUs, and outflows to gravity drainage, interflow, and surface runoff to down-slope HRUs; merge of smbal_prms and sflow_prms with enhancements.
Groundwater process	
gwwflow	Sums inflow to and outflow from PRMS groundwater reservoirs; outflow can be routed to downslope groundwater reservoirs and stream segments; modification of gwwflow_prms.
Streamflow process	
strmflow	Computes daily streamflow as the sum of surface runoff, shallow-subsurface flow, detention reservoir flow, and groundwater flow.
muskingum routing	Routes water between segments in the system using Muskingum routing. Computes streamflow routing order and common streamflow routing results, used when modules muskingum, strmflow_in_out, or strmflow_lake are active.
strmflow_in_out	Routes water between segments in the system by setting the outflow to the inflow.
strmflow_lake	Computes basin on-channel reservoir storage and outflows.
Summary process	
basin_sum	Computes daily, monthly, yearly, and total flow summaries of volumes and flows for all HRUs.
subbasin	Computes streamflow at internal basin nodes and variables by subbasin.
map_results	Writes HRU summaries to a user specified target map at weekly, monthly, yearly, and total time steps.
prms_summary	Writes selected basin area-weighted results to a Comma-Separated Values (CSV) File when control

mhru_summary	parameter csvON_OFF is specified equal to 1. Write selected user-selected results dimensioned by the value of dimension nhru to separate CSV Files at daily, monthly, and mean monthly time steps.
Deprecated modules	
ccsolrad_prms	Similar to module ccsolrad, except this version uses conceptual radiation planes instead of HRUs.
ddsolrad_prms	Similar to module ddsolrad, except this version uses conceptual radiation planes instead of HRUs.
hru_sum_prms	Computes monthly and yearly summaries of selected variables for each HRU.
potet_hamon_prms	Similar to module potet_hamon, except this version uses conceptual radiation planes instead of HRUs.
smbal_prms	Computes soil moisture accounting for each HRU.
soltab_prms	Similar to module soltab, except this version uses conceptual radiation planes instead of HRUs.
ssflow_prms	Adds inflow to subsurface reservoirs and computes outflow to ground water reservoirs and to streamflow.
temp_2sta_prms	Similar to temp_laps, except this version bases the lapse rate on the difference between the elevation of a measurement station assigned to an HRU and the difference in elevation for two station measurement stations.

Table 1-1. Dimensions used in the Precipitation-Runoff Modeling System, version 4 (PRMS-IV).

[HRU, hydrologic response unit; GWR, groundwater reservoir; >, greater than; control parameters **temp_module**, **precip_module**, **solrad_module**, **et_module**, **strmflow_module**, **subbasin_flag**, **cascade_flag**, **cascadegw_flag**, and **mapOutON_OFF** defined in table 1-2; parameter **hru_solsta** defined in table 1-3]

Dimension ³	Description	Default	Required/Condition
Spatial dimensions			
ngw ²	Number of GWRs	1	required
ngwcell	Number of spatial units in the target map for mapped results	0	mapOutON_OFF = 1
nhru	Number of hydrologic response units	1	required
nhruccell	Number of unique intersections between HRUs and spatial units of a target map for mapped results	0	mapOutON_OFF = 1
nlake	Number of lake HRUs	0	required when any HRU has hru_type specified equal to 2 strmflow_module = strmflow_lake
nradpl	Number of solar radiation planes—deprecated	0	solrad_module = ccsolrad_prms or ddsolrad_prms
nsegment	Number of stream-channel segments	0	strmflow_module = strmflow_lake , muskingum, or strmflow_in_out or cascade_flag = 1 or cascadegw_flag = 1
nssr ²	Number of subsurface reservoirs	1	required
nsub	Number of internal subbasins	0	subbasin_flag = 1
Time-series input data dimensions ¹			
nevap	Number of pan-evaporation data sets	0	et_module = potet_pan
nhumid	Number of relative humidity measurement stations	0	optional
nlakeelev	Maximum number of lake elevations for any rating table data set	0	strmflow_module = strmflow_lake
nobs	Number of streamflow-measurement stations	0	replacement flow when strmflow_module = strmflow_lake , muskingum, or strmflow_in_out
npoigages	Number of points-of-interest streamflow gages	0	optional
nrain	Number of precipitation-measurement stations	0	precip_module = precip_1sta , precip_laps , precip_dist2 , ide_dist , or xyz_dist
nratetbl	Number of rating-table data sets for lake elevations	0	strmflow_module = strmflow_lake
nsnow	Number of snow-depth measurement stations	0	optional
nsol	Number of solar-radiation measurement stations	0	computation of solar radiation distribution using parameter hru_solsta
ntemp	Number of air-temperature-measurement stations	0	temp_module = temp_1sta, temp_2sta_prms deprecated, temp_laps, temp_dist2, ide_dist, or xyz_dist

Dimension ³	Description	Default	Required/Condition
nwind	Number of wind-speed measurement stations	0	Optional
Computation dimensions			
ncascade	Number of HRU links for cascading flow	0	cascade_flag = 1
ncascgdw	Number of GWR links for cascading flow	0	cascadegw_flag = 1 or 2
ndepl	Number of snow-depletion curves	1	required
ndeplval	Number of values in all snow-depletion curves (set to ndepl *11)	11	required
Lake computation dimensions			
mxnsos	Maximum number of storage/outflow table values for storage-detention reservoirs and lakes connected to the stream network using Puls routing	0	strmflow_module = strmflow_lake
ngate	Maximum number of reservoir gate-opening values (columns) for lake rating table 1	0	strmflow_module = strmflow_lake and nratetbl > 0
ngate2	Maximum number of reservoir gate-opening values (columns) for lake rating table 2	0	strmflow_module = strmflow_lake and nratetbl > 1
ngate3	Maximum number of reservoir gate-opening values (columns) for lake rating table 3	0	strmflow_module = strmflow_lake and nratetbl > 2
ngate4	Maximum number of reservoir gate-opening values (columns) for lake rating table 4	0	strmflow_module = strmflow_lake and nratetbl > 3
nstage	Maximum number of lake elevations values (rows) for lake rating table 1	0	strmflow_module = strmflow_lake and nratetbl > 0
nstage2	Maximum number of lake elevations values (rows) for lake rating table 2	0	strmflow_module = strmflow_lake and nratetbl > 1
nstage3	Maximum number of lake elevations values (rows) for lake rating table 3	0	strmflow_module = strmflow_lake and nratetbl > 2
nstage4	Maximum number of lake elevations values (rows) for lake rating table 4	0	strmflow_module = strmflow_lake and nratetbl > 3
Fixed dimensions			
ndays	Maximum number of days in a year	366	optional
nlapse	Number of lapse rates in X, Y, and Z directions	3	precip_module = xyz_dist
nmonths	Number of months in a year	12	optional
one	Dimension of scalar parameters and variables	1	optional

¹All associated data specified in Data File can be used for calibration purposes.

²Use of **nssr** and **ngw** not equal to **nhru** is deprecated.

³Dimensions that do not have an associated parameter specified in the Parameter File or variable specified in the Data File are optional.

Table 1-2. Parameters specified in the Control File for the Precipitation-Runoff Modeling System, version 4 (PRMS-IV).

[Data Type: 1=integer, 2=single precision floating point (real), 3=double precision floating point (double); 4=character string; HRU, hydrologic response unit; GWR, groundwater reservoir; CBH, climate-by-HRU; ET, evapotranspiration; >, greater than; dimensions **ncascade**, **ncascdgw**, and **nsub** defined in table 1-1; ~~modules soltab_prms, temp_2sta_prms, ccsolrad_prms, ddsolrad_prms, potet_hamon_prms, smbals_prms, ssflow_prms, and hru_sum_prms are deprecated and only included for backwards compatibility for PRMS models built prior to PRMS-IV;~~ the first two blocks of control parameters listed in the table are recommended for every simulation, though all parameters are optional depending appropriateness of the default values]

Parameter name	Description	Option	Number of Values	Data type	Default value
Simulation execution and required input and output files					
data_file ²	Pathname(s) for measured input Data File(s), typically a single Data File is specified	measured input	number of Data Files	4	prms.data
end_time	Simulation end date and time specified in order in the control item as: year, month, day, hour, minute, second	time period	6	1	2001, 9, 30, 0, 0, 0
model_mode	Flag to indicate the simulation mode (PRMS=PRMS; FROST=growing season for each HRU; WRITE_CLIMATE=write CBH files of minimum and maximum air temperature (variables <i>tminf</i> and <i>tmaxf</i> -Fahrenheit); precipitation (variable <i>hru_ppt</i> -inches); solar radiation (variable <i>swrad</i> -Langleys); potential ET (variable <i>potet</i> -inches); and/or transpiration flag (variable <i>transp_on</i> -none); POTET=simulate to potential ET; TRANSPIRE=simulate to transpiration period; DOCUMENTATION=write files of all declared parameters and variables in the executable)	simulation mode selection	1	4	PRMS
model_output_file ²	Pathname for Water-Budget File for results module <i>basin_sum</i> and <i>hru_sum_prms</i> —deprecated	simulation output	1	4	prms.out
param_file ²	Pathname(s) for Parameter File(s)	parameter input	number of Parameter Files	4	prms.params
start_time	Simulation start date and time specified in order in the control item as: year, month, day, hour, minute, second	time period	6	1	2000, 10, 1, 0, 0, 0
Module selection and simulation options					
cascade_flag	Flag to indicate if HRU cascades are computed (0=no; 1=yes)	cascade flow with ncascade > 0	1	1	1
cascadegw_flag	Flag to indicate if GWR cascades are computed (0=no; 1=yes; 2 = GWR cascades are set equal to the HRU cascades and parameters gw_up_id , gw_strmseg_down_in , gw_down_id , and gw_pct_up are not required)	cascade flow with ncascdgw > 0	1	1	1

Parameter name	Description	Option	Number of Values	Data type	Default value
dprst_flag	Flag to indicate if depression-storage simulation is computed (0=no; 1=yes)	surface-depression storage	1	1	0
et_module	Module name for potential evapotranspiration method (climate_hru, potet_jh, potet_hamon, potet_hs, potet_pt, potet_pm, or potet_pan, or potet_hamon_prms—deprecated)	module selection	1	4	potet_jh
gwr_swale_flag	Flag to indicate if GWR swales are allowed (0=no; 1=groundwater flow goes to groundwater sink; 3=groundwater flow goes to stream segment specified using parameter hru_segment)	swales	1	1	0
precip_module	Module name for precipitation-distribution method (climate_hru, ide_dist, precip_1sta, precip_dist2, precip_laps, or xyz_dist)	module selection	1	4	precip_1sta
soilzone_module	Module name for capillary and gravity reservoir simulation method; either soilzone or deprecated modules smb1_prms and ssflow_prms (soilzone or smb1_prms)	module selection	1	4	soilzone
solrad_module	Module name for solar-radiation-distribution method (ccsolrad or ddsolrad, ecsolrad_prms—deprecated, or ddsolrad_prms—deprecated; if either deprecated module is specified, soltab_prms—deprecated is used instead of the soltab module and hru_sum_prms is active)	module selection	1	4	ddsolrad
srunoff_module	Module name for surface-runoff/infiltration computation method (srunoff_carea or srunoff_smidx)	module selection	1	4	srunoff_smidx
strmflow_module	Module name for streamflow routing simulation method (strmflow, muskingum, strmflow_in_out, or strmflow_lake)	module selection	1	4	strmflow
subbasin_flag	Flag to indicate if internal subbasin are computed (0=no; 1=yes)	nsub > 0	1	1	1
temp_module	Module name for temperature-distribution method (climate_hru, temp_1sta, temp_dist2, temp_laps, ide_dist, or xyz_dist, or temp_2sta_prms—deprecated)	module selection	1	4	temp_1sta
transp_module	Module name for transpiration simulation method (climate_hru, transp_frost, or transp_tindex)	module selection	1	4	transp_tindex
Climate-by-HRU Files					
cbh_binary_flag	Flag to specify whether to input CBH files in a binary format using the same order of values as the text file version (0=no; 1=yes)	input options	1	1	0
humidity_day²	Pathname of the CBH file of pre-processed humidity input data for each HRU to specify variable humidity_hru-percentage	et_module = potet_pm	1	4	humidity.day
orad_flag	Flag to specify whether or not the variable orad is specified as the	solrad_module =	1	1	1

Parameter name	Description	Option	Number of Values	Data type	Default value
potet_day ²	last column of the swrad_day CBH file (0=no; 1=yes) Pathname of the CBH file of pre-processed potential-ET input data for each HRU to specify variable <i>potet</i> -inches	climate_hru et_module = climate_hru	1	4	potet.day
precip_day ²	Pathname of the CBH file of pre-processed precipitation input data for each HRU to specify variable <i>precip</i> -inches	precip_module = climate_hru	1	4	precip.day
swrad_day ²	Pathname of the CBH file of pre-processed solar-radiation input data for each HRU to specify variable <i>swrad</i> -Langleys	solrad_module = climate_hru	1	4	swrad.day
tmax_day ²	Pathname of the CBH file of pre-processed maximum air temperature input data for each HRU to specify variable <i>tmaxf</i> -degrees Fahrenheit	temp_module = climate_hru	1	4	tmax.day
tmin_day ²	Pathname of the CBH file of pre-processed minimum air temperature input data for each HRU to specify variable <i>tminf</i> -degrees Fahrenheit	temp_module = climate_hru	1	4	tmin.day
transp_day ²	Pathname of the CBH file of pre-processed transpiration on or off flag for each HRU file to specify variable <i>transp_on</i> -none	transp_module = climate_hru	1	4	transp.day
windspeed_day ²	Pathname of the CBH file of pre-processed wind speed input data for each HRU to specify variable <i>windspeed_hru</i> -meters/second	et_module = potet_pm	1	4	windspeed.day
Debug options					
cbh_check_flag	Flag to indicate if CBH values are validated each time step (0=no; 1=yes)	CBH input	1	1	1
parameter_check_flag	Flag to indicate if selected parameter values validation checks are treated as warnings or errors (0=no; 1=yes; 2=check parameters and then stop)	parameter validation check	1	1	1
print_debug ¹	Flag to indicate type of debug output (-1=minimize screen output; 0=none; 1=water balances; 2=basin module; 4=basin_sum module; 5=soltab module; 7=soilzone module; 9=snowcomp module; 13=cascade module; 14=subbasin module)	debug output	1	1	0
Statistic Variables (statvar) Files					
nstatVars	Number of variables to include in Statistics Variables File and names specified in statVar_names	statsON_OFF = 1	1	1	0
stat_var_file ²	Pathname for Statistics Variables File	statsON_OFF = 1	1	4	statvar.out
statsON_OFF	Switch to specify whether or not the Statistics Variables File is generated (0=no; 1=statvartext format; 2=CSV format)	statsON_OFF = 1	1	1	0
statVar_element	List of identification numbers corresponding to variables specified in statVar_names list (1 to variable's dimension size)	statsON_OFF = 1	nstatVars	4	none
statVar_names	List of variable names for which output is written to Statistics	statsON_OFF = 1	nstatVars	4	none

Parameter name	Description	Option	Number of Values	Data type	Default value
Variables File					
Initial Condition Files					
init_vars_from_file	Flag to specify whether or not the Initial Conditions File is specified as an input file (0=no; 1=yes; 2=yes and use parameter values in Parameter File instead of values in Initial Conditions File)	initial condtns	1	1	0
save_vars_to_file	Flag to determine if an Initial Conditions File will be generated at the end of simulation (0=no; 1=yes)	initial condtns	1	1	0
var_init_file²	Pathname for Initial Conditions input file	init_vars_from_file = 1	1	4	prms_ic.in
var_save_file²	Pathname for the Initial Conditions File to be generated at end of simulation	save_vars_to_file = 1	1	4	prms_ic.out
Animation Files					
ani_output_file²	Root pathname for Animation Files(s) to which a filename suffix based on dimension name associated with selected variables is appended	aniOutON_OFF = 1	1	4	animation.out
aniOutON_OFF	Switch to specify whether or not Animation File(s) are generated (0=no; 1=yes)	animation output	1	1	0
aniOutVar_names	List of variable names for which all values of the variable (that is, the entire dimension size) for each time step are written Animation Dimension Files(s)	aniOutON_OFF = 1	naniOutVars	4	none
naniOutVars	Number of output variables specified in the aniOutVar_names list	aniOutON_OFF = 1	1	1	0
Mapped Results Files					
mapOutON_OFF	Switch to specify whether or not mapped output file(s) by a specified number of columns (parameter ncol) of daily , monthly, yearly, or total simulation results is generated (0=no; 1=yes)	mapped results	1	1	0
mapOutVar_names	List of variable names for which output is written to mapped output files(s)	map_resultsON_OFF = 1	nmapOutVars	4	none
nmapOutVars	Number of variables to include in mapped output file(s)	map_resultsON_OFF = 1	1	1	0
Nhru Summary Results Files					
nhruOutBaseFileName²	String to define the prefix for each nhru summary output file.	nhruOutON_OFF = 1	1	4	none
nhruOutON_OFF	Switch to specify whether or not nhru summary output files are generated (0=no; 1=yes)	nhru summary results	1	1	0
nhruOutVar_names	List of variable names for which output is written to nhru summary Comma Separated Values (CSV) output files(s). Each variable is written to a separate file with the prefix of each file equal to the value of nhruOutBaseFileName .	nhruOutON_OFF = 1	nhruOutVars	4	none
nhruOutVars	Number of variables to include in mapped output file(s)	nhruOutON_OFF = 1	1	1	0

Parameter name	Description	Option	Number of Values	Data type	Default value
nhruOut_freq	Output frequency and type (1=daily; 2=monthly; 3=both; 4=mean monthly)	nhruOutON_OFF = 1	1	1	1
PRMS Summary Results Files					
csvON_OFF	Switch to specify whether or not common-separated values (CSV) summary output files are generated (0=no; 1=yes)	PRMS summary results	1	1	0
csv_output_file²	Pathname of CSV output file	csvON_OFF = 1	1	4	none
Runtime graphs					
dispGraphsBuffSize	Number of time steps to wait before updating the runtime graph	ndispGraphs > 0	1	1	50
dispVar_element	List of identification numbers corresponding to variables specified in dispVar_names list (1 to variable's dimension size)	ndispGraphs > 0	number of variables	4	none
dispVar_names	List of variable names for which plots are output to the runtime graph	ndispGraphs > 0	number of variables	4	none
dispVar_plot	List of variable names for which plots are output to the runtime graph	ndispGraphs > 0	number of variables	4	none
executable_desc	Descriptive text to identify the PRMS-IV executable	ndispGraphs > 0	1	4	MOWS executable
executable_model²	Pathname (full or relative) of the PRMS-IV executable	ndispGraphs > 0	1	4	prmsIV
initial_deltat	Initial time step for the simulation	ndispGraphs > 0	1	2	24.0
ndispGraphs	Number of plots included in the runtime graph	graphical output	1	1	0

¹File and screen output options: 1=water balance output files written in current directory, for `intcp` module file `intcp.wbal`; for `snowcomp` module `snowcomp.wbal`; for `srunoff` module `srunoff_smidx.wbal` or `srunoff_carea.wbal`; for `soilzone` module `soilzone.wbal`; for `gwflow` module `gwflow.wbal`; 2=basin module output written to screen; 4=basin_sum debug information written to file `basin_sum.dbg` in current directory; 5=soltab module output written to the file `soltab_debug` in current directory; 7=soilzone debug information concerning input parameter consistency written to file `soilzone.dbg` in current directory; 9=arrays of `net_rain`, `net_snow`, and `snowmelt` written to screen; 13=subbasin error and warning messages and cascade paths are written to the file `cascade.msgs` in current directory; 14=subbasin computation order written to file `tree_structure` in current directory.

²Pathnames for all files can have a maximum of **256** characters.

³~~Variable names can have a maximum of 32 characters.~~

Table 1-3. Parameters listed by usage with the associated modules in which they are used for the Precipitation-Runoff Modeling System, version 4 (PRMS-IV).

[HRU, hydrologic response unit; GWR, groundwater reservoir; cfs, cubic feet per second; cms, cubic meters per second; ET, evapotranspiration; dday, degree-day, the amount a day's average temperature departed from 65 degrees Fahrenheit; >, greater than; dimensions defined in table 1-1; control parameters **temp_module**, **precip_module**, **solrad_module**, **et_module**, **transp_module**, **srunoff_module**, **strmflow_module**, **soilzone_module**, **model_mode**, **dprst_flag**, **subbasin_flag**, **cascade_flag**, **cascadegw_flag**, and **mapOutON_OFF** defined in table 1-2. ~~Note: modules soltab_prms, temp_2sta_prms, eesolrad_prms, ddsolrad_prms, potet_hamon_prms, smbal_prms, ssflow_prms, and hru_sum_prms are deprecated and only included for backwards compatibility for PRMS models built prior to PRMS-IV]~~

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
Basic physical attributes							
basin_area	Area of basin	one	real	acres	0.0 to 1.0E9	1.0	deprecated¹⁰
elev_units	Flag to indicate the units of elevation values (0=feet; 1=meters)	one	integer	none	0 or 1	0	required
hru_area	Area of each HRU	nhru	real	acres	0.0001 to 1.0E9	1.0	required
hru_aspect	Aspect of each HRU	nhru	real	angular degrees	0.0 to 360.0	0.0	required ⁶
hru_elev	Mean elevation for each HRU	nhru	real	elev_units	-1,000.0 to 30,000.0	0.0	required
hru_lat	Latitude of each HRU	nhru	real	angular degrees	-90.0 to 90.0	40.0	required ⁶
hru_lon	Longitude of each HRU	nhru	real	angular degrees	-360.0 to 360.0	-105.0	netCDF output
hru_radpl	Index of radiation plane used to compute solar radiation for each HRU	nradpl	integer	none	1 to nradpl	1	solrad_module = ddsolrad_prms or eesolrad_prms required⁶
hru_slope	Slope of each HRU	nhru	real	decimal fraction	0.0 to 10.0	0.0	required ⁶
hru_type⁵	Type of each HRU (0=inactive; 1=land; 2=lake; 3=swale)	nhru	integer	none	0 to 3	1	required
Measured input							
outlet_sta	Index of measured streamflow station corresponding to the basin outlet	one	integer	none	0 to nobs	0	nobs > 0
precip_units	Flag to indicate the units of measured precipitation values (0=inches; 1=mm)	one	integer	none	0 or 1	0	required

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
rad_conv	Conversion factor to Langleys for measured solar radiation	one	real	Langleys/ radiation units	0.1 to 100.0	1.0	nsol > 0
rain_code	Monthly (January to December) flag indicating rule for precipitation measurement station use (1=only precipitation if the regression stations have precipitation; 2=only precipitation if any station in the basin has precipitation; 3=precipitation if module xyz_dist computes any; 4=only precipitation if <i>rain_day</i> variable is set to 1; 5=only precipitation if psta_freq_nuse stations have precipitation)	nmonths	integer	none	1 to 5	2	precip_module = xyz_dist
runoff_units	Measured streamflow units (0=cfs; 1=cms)	one	integer	none	0 or 1	0	nobs > 0
temp_units	Flag to indicate the units of measured air-temperature values (0=Fahrenheit; 1=Celsius)	one	integer	none	0 or 1	0	required
Air temperature and precipitation distribution							
adj_by_hru	Flag to indicate whether to adjust precipitation and air temperature by HRU or subbasin (0=subbasin; 1=HRU)	one	integer	none	0 or 1	1	precip_module = climate_hru required
adjmix_rain	Monthly (January to December) factor to adjust rain proportion in a mixed rain/snow event	nhru, nmonths	real	decimal fraction	0.6 to 1.4	1.0	
adjust_rain	Monthly (January to December) rain downscaling adjustment factor for each precipitation measurement station	nrain, nmonths	real	decimal fraction	-0.5 to 0.5	-0.4	precip_module = ide_dist or xyz_dist
adjust_snow	Monthly (January to December) snow downscaling adjustment factor for each precipitation measurement station	nrain, nmonths	real	decimal fraction	-0.5 to 0.5	-0.4	precip_module = ide_dist or xyz_dist
basin_tsta	Index of temperature station used to compute basin temperature values	one	integer	none	0 to ntemp	0	temp_module = temp_1sta, temp_2sta_prms, temp_dist2, or temp_laps
conv_flag	Elevation conversion flag (0=none; 1=feet to meters; 2=meters to feet)	one	integer	none	0 to 2	0	precip_module and temp_module = xyz_dist
dist_exp	Exponent for inverse distance calculations	one	real	none	0.0 to 10.0	2.0	precip_module and temp_module = ide_dist
dist_max	Maximum distance from an HRU to a measurement station for use in calculations	one	real	feet	0.0 to 1.0E9	1.0E9	precip_module = precip_dist2 and/or temp_module

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
hi_index	Index of upper temperature station for daily lapse rate computations	one	integer	none	1 to ntemp	1	temp_module = temp_dist2
hru_plaps	Index of the lapse precipitation measurement station used for lapse rate calculations for each HRU	nhru	integer	none	0 to nrain	0	temp_2sta_prms precip_module = precip_laps
hru_psta	Index of the base precipitation measurement station used for lapse rate calculations for each HRU	nhru	integer	none	0 to nrain	0	precip_module = precip_1sta or precip_laps
hru_tlaps	Index of the lapse temperature station used for lapse rate calculations	nhru	integer	none	0 to ntemp	0	temp_module = temp_laps
hru_tsta	Index of the base temperature station used for lapse rate calculations	nhru	integer	none	0 to ntemp	0	temp_module = temp_1sta or temp_laps, or temp_2sta_prms
hru_x	Longitude (X) for each HRU in albers projection	nhru	real	meters	-1.0E7 to 1.0E7	0.0	precip_module and temp_module = ide_dist or xyz_dist
hru_xlong	Longitude of each HRU for the centroid, State Plane Coordinate System	nhru	real	feet	-1.0E9 to 1.0E9	0.0	temp_module = temp_dist2 or precip_module = precip_dist2
hru_y	Latitude (Y) for each HRU in albers projection	nhru	real	meters	-1.0E7 to 1.0E7	0.0	precip_module and temp_module = ide_dist or xyz_dist
hru_ylat	Latitude of each HRU for the centroid, State Plane Coordinate System	nhru	real	feet	-1.0E9 to 1.0E9	0.0	temp_module = temp_dist2 and/or precip_module = precip_dist2
lapsemax_max	Monthly (January to December) maximum lapse rate to constrain lowest maximum lapse rate based on historical daily air temperatures for all air temperature-measurement stations	nmonths	real	temp_units/feet	-3.0 to 3.0	2.0	temp_module = temp_dist2
lapsemax_min	Monthly (January to December) maximum lapse rate to constrain lowest minimum lapse rate on the basis of historical daily air temperatures for all air temperature-measurement stations	nmonths	real	temp_units/feet	-7.0 to -3.0	-6.5	temp_module = temp_dist2
lapsemin_max	Monthly (January to December) minimum lapse rate to constrain lowest maximum lapse rate on the basis of	nmonths	real	temp_units/feet	-2.0 to 4.0	3.0	temp_module = temp_dist2

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
lapsemin_min	historical daily air temperatures for all air temperature-measurement stations Monthly (January to December) minimum lapse rate to constrain lowest minimum lapse rate on the basis of historical daily air temperatures for all air temperature-measurement stations	nmonths	real	temp_units/ feet	-7.0 to -3.0	-4.0	temp_module = temp_dist2
lo_index	Index of lower temperature station for daily lapse rate computations	one	integer	none	1 to ntemp	1	temp_module = temp_2sta_prms
max_lapse	Monthly (January to December) maximum air temperature lapse rate for each direction (X, Y, and Z))	nlapse, nmonths	real	none	-100.0 to 100.0	0.0	temp_module = xyz_dist
max_missing	Maximum number of consecutive missing values allowed for any air temperature measurement station; missing value set to last valid value; 0=unlimited	one	integer	none	0 to 10	3	temp_module = temp_1sta or temp_laps
max_psta	Maximum number of precipitation measurement stations to distribute to an HRU	one	integer	none	0 to nrain	0	precip_module = precip_dist2
max_tsta	Maximum number of air temperature measurement stations to use for distributing temperature to any HRU	one	integer	none	0 to ntemp	0	temp_module = temp_dist2
maxday_prec	Maximum measured precipitation value above which precipitation is assumed to be in error	one	real	precip_units	0.0 to 20.0	15.0	precip_module = precip_dist2
min_lapse	Monthly (January to December) minimum air temperature lapse rate for each direction (X, Y, and Z)	nlapse, nmonths	real	none	-100.0 to 100.0	0.0	temp_module = xyz_dist
monmax	Monthly maximum air temperature to constrain lowest maximum air temperatures for bad values on the basis of historical temperature for all measurement stations	nmonths	real	temp_units	0.0 to 115.0	100.0	temp_module = temp_dist2
monmin	Monthly minimum air temperature to constrain lowest maximum air temperatures for bad values on the basis of historical temperature for all measurement stations	nmonths	real	temp_units	-60.0 to 65.0	-60.0	temp_module = temp_dist2
ndist_psta	Number of precipitation measure stations for inverse distance calculations	one	integer	none	0 to nrain	0	precip_module = ide_dist
ndist_tsta	Number of air temperature measurement stations for inverse distance calculations	one	integer	none	0 to ntemp	0	temp_module = ide_dist
padj_rn	Monthly (January to December) factor to adjust precipitation lapse rate computed between station hru_psta and station hru_plaps ; positive factors are multiplied times the lapse rate and negative factors are made positive and substituted for the computed lapse rate	nrain, nmonths	real	precip_units	-2.0 to 10.0	1.0	precip_module = precip_laps
padj_sn	Monthly (January to December) factor to adjust precipitation lapse rate computed between station hru_psta and station hru_plaps ; positive factors are	nrain, nmonths	real	precip_units	-2.0 to 10.0	1.0	precip_module = precip_laps

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
	multiplied times the lapse rate and negative factors are made positive and substituted for the computed lapse rate						
pmm_mo	Mean monthly (January to December) precipitation for each lapse precipitation measurement station	nrain, nmonths	real	precip_units	0.00001 to 100.0	1.0	precip_module = precip_laps
potet_cbh_adj	Monthly (January to December) adjustment factor to potential evapotranspiration specified in CBH Files for each HRU	nhru, nmonths	real	decimal fraction	0.5 to 1.5	1.0	et_module = climate_hru
ppt_add	Mean value for the precipitation measurement station transformation equation	one	real	precip_units	-10.0 to 10.0	0.0	precip_module = xyz_dist
ppt_div	Standard deviation for the precipitation measurement station transformation equation (not 0.0)	one	real	precip_units	-10.0 to 10.0	1.0	precip_module = xyz_dist
ppt_lapse	Monthly (January to December) precipitation lapse rate for each direction (X, Y, and Z)	nlapse, nmonths	real	none	-10.0 to 10.0	0.0	precip_module = xyz_dist
prcp_wght_dist	Monthly (January to December) precipitation weighting function for inverse distance calculations	nmonths	real	decimal fraction	0.0 to 1.0	0.5	precip_module = ide_dist
psta_elev	Elevation of each precipitation measurement station	nrain	real	elev_units	-300.0 to 30,000.0	0.0	precip_module = ide_dist, xyz_dist, or precip_laps
psta_freq_nuse	The subset of precipitation measurement stations used to determine if there is precipitation in the basin (0=station not used; 1=station used)	nrain	integer	none	0 or 1	1	precip_module = xyz_dist
psta_mon	Monthly (January to December) factor to precipitation at each measured station to adjust precipitation distributed to each HRU to account for differences in elevation, and so forth	nrain, nmonths	real	precip_units	0.0 to 50.0	1.0	precip_module = precip_dist2
psta_month_ppt	Average monthly (January to December) maximum precipitation at each precipitation measurement station	nrain, nmonths	real	precip_units	0.0 to 20.0	0.0	precip_module = xyz_dist
psta_nuse	The subset of precipitation measurement stations used in the distribution regression (0=station not used; 1=station used)	nrain	integer	none	0 or 1	1	precip_module = ide_dist or xyz_dist
psta_x	Longitude (X) for each precipitation measurement station in albers projection	nrain	real	meters	-1.0E7 to 1.0E7	0	precip_module = ide_dist or xyz_dist
psta_xlong	Longitude of each precipitation measurement station, State Plane Coordinate System	nrain	real	feet	-1.0E9 to 1.0E9	0.0	precip_module = precip_dist2
psta_y	Latitude (Y) for each precipitation measurement station in albers projection	nrain	real	meters	-1.0E7 to 1.0E7	0	precip_module = ide_dist or xyz_dist

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
psa_ylat	Latitude of each precipitation measurement station, State Plane Coordinate System	nrain	real	feet	-1.0E9 to 1.0E9	0.0	precip_module = precip_dist2
rain_adj	Monthly (January to December) factor to adjust measured precipitation on each HRU to account for differences in elevation, and so forth	nhru, nmonths	real	decimal fraction	0.5 to 2.0	1.0	precip_module = precip_1sta
rain_cbh_adj	Monthly (January to December) adjustment factor to measured precipitation determined to be rain on each HRU to account for differences in elevation, and so forth	nhru, nmonths	real	decimal fraction	0.5 to 2.0	1.0	precip_module = climate_hru
rain_mon	Monthly (January to December) factor to rain on each HRU to adjust precipitation distributed to each HRU to account for differences in elevation, and so forth	nhru, nmonths	real	precip_units	0.0 to 50.0	1.0	precip_module = precip_dist2
rain_sub_adj	Monthly (January to December) rain adjustment factor to measured precipitation for each subbasin	nsub, nmonths	real	decimal fraction	0.5 to 2.0	1.0	precip_module = climate_hru
snow_adj	Monthly (January to December) factor to adjust measured precipitation on each HRU to account for differences in elevation, and so forth	nhru, nmonths	real	decimal fraction	0.5 to 2.0	1.0	precip_module = precip_1sta
snow_cbh_adj	Monthly (January to December) adjustment factor to measured precipitation determined to be snow on each HRU to account for differences in elevation, and so forth	nhru, nmonths	real	decimal fraction	0.5 to 2.0	1.0	precip_module = climate_hru
snow_mon	Monthly (January to December) factor to snow on each HRU to adjust precipitation distributed to each HRU to account for differences in elevation, and so forth	nhru, nmonths	real	precip_units	0.0 to 50.0	1.0	precip_module = precip_dist2
snow_sub_adj	Monthly (January to December) snow adjustment factor to measured precipitation for each subbasin	nsub, nmonths	real	decimal fraction	0.5 to 2.0	1.0	precip_module = climate_hru
solrad_elev	Elevation of the solar radiation station used for the degree-day curves to distribute temperature	one	real	meters	-300.0 to 30,000.0	0.0	temp_module = ide_dist or xyz_dist
temp_wght_dist	Monthly (January to December) temperature weighting function for inverse distance calculations	nmonths	real	decimal fraction	0.0 to 1.0	0.5	temp_module = ide_dist
tmax_add	Mean value for the air-temperature measurement station transformation equation for maximum air temperature	one	real	temp_units	-100.0 to 100.0	0.0	temp_module = xyz_dist
tmax_adj	Adjustment to maximum air temperature for each HRU, estimated on the basis of slope and aspect	nhru, nmonths	real	temp_units	-10.0 to 10.0	0.0	temp_module = temp_1sta, temp_2sta_prms, temp_laps, temp_dist2, ide_dist or xyz_dist
tmax_allrain	Monthly (January to December) maximum air temperature when precipitation is assumed to be rain; if	nhru, nmonths	real	temp_units	-8.0 to 75.0	38.0	required

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
	HRU air temperature is greater than or equal to this value, precipitation is rain						
tmax_allrain_dist	Monthly (January to December) maximum air temperature when precipitation is assumed to be rain; if HRU air temperature is greater than or equal to this value, precipitation is rain	nmonths	real	temp_units	-8.0 to 75.0	38.0	temp_module = xyz_dist
tmax_allrain_sta	Monthly (January to December) maximum air temperature when precipitation is assumed to be rain; if precipitation measurement air temperature is greater than or equal to this value, precipitation is rain	nrain, nmonths	real	temp_units	-8.0 to 75.0	38.0	temp_module = ide_dist
tmax_allsnow	Monthly (January to December) maximum air temperature when precipitation is assumed to be snow; if HRU air temperature is less than or equal to this value, precipitation is snow	nhru, nmonths	real	temp_units	-10.0 to 40.0	32.0	required
tmax_allsnow_dist	Maximum air temperature when precipitation is assumed to be snow; if mean air temperature is less than or equal to this value, precipitation is snow	one	real	temp_units	-10.0 to 40.0	38.0	temp_module = xyz_dist
tmax_allsnow_sta	Monthly (January to December) maximum air temperature when precipitation is assumed to be snow; if precipitation measurement air temperature is less than or equal to this value, precipitation is snow	nrain, nmonths	real	temp_units	-10.0 to 40.0	38.0	temp_module = ide_dist
tmax_cbh_adj	Monthly (January to December) adjustment factor to maximum air temperature for each HRU, estimated on the basis of slope and aspect	nhru, nmonths	real	temp_units	-10.0 to 10.0	0.0	temp_module = climate_hru
tmax_div	Standard deviation for the air-temperature-measurement station transformation equation for maximum air temperature (not 0.0)	one	real	temp_units	-100.0 to 100.0	1.0	temp_module = xyz_dist
tmax_lapse	Monthly (January to December) values representing the change in maximum air temperature per 1,000 elev_units of elevation change for each HRU	nhru, nmonths	real	temp_units/ elev_units	-20.0 to 20.0	3.0	temp_module = temp_1sta
tmax_mo_adj	Monthly (January to December) adjustment factor to maximum air temperature for each HRU, estimated on the basis of slope and aspect	nhru, nmonths	real	temp_units	-10.0 to 10.0	0.0	temp_module = temp_dist2
tmin_add	Mean value for the air-temperature-measurement station transformation equation for minimum air temperature	one	real	temp_units	-100.0 to 100.0	0.0	temp_module = xyz_dist
tmin_adj	Adjustment to minimum air temperature for each HRU, estimated on the basis of slope and aspect	nhru, nmonths	real	temp_units	-10.0 to 10.0	0.0	temp_module = temp_1sta, temp_2sta_prms, temp_laps, temp_dist2,

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
tmin_cbh_adj	Monthly (January to December) adjustment factor to minimum air temperature for each HRU, estimated on the basis of slope and aspect	nhru, nmonths	real	temp_units	-10.0 to 10.0	0.0	ide_dist or xyz_dist temp_module = climate_hru
tmin_div	Standard deviation for the air-temperature-measurement station transformation equation for minimum air temperature (not 0.0)	one	real	temp_units	-100.0 to 100.0	1.0	temp_module = xyz_dist
tmin_lapse	Monthly (January to December) values representing the change in minimum air temperature per 1,000 elev_units of elevation change for each HRU	nhru, nmonths	real	temp_units/ elev_units	-20.0 to 20.0	3.0	temp_module = temp_1sta
tmin_mo_adj	Monthly (January to December) adjustment factor to minimum air temperature for each HRU, estimated on the basis of slope and aspect	nhru, nmonths	real	temp_units	-10.0 to 10.0	0.0	temp_module = temp_dist2
tsta_elev	Elevation of each air-temperature-measurement station	ntemp	real	elev_units	-300.0 to 30,000.0	0.0	temp_module = temp_1sta, temp_2sta_prms, temp_dist2, temp_laps, ide_dist or xyz_dist
tsta_month_max	Average monthly (January to December) maximum air temperature at each air-temperature-measurement station	ntemp, nmonths	real	temp_units	-100.0 to 100.0	0.0	temp_module = xyz_dist
tsta_month_min	Average monthly (January to December) minimum air temperature at each air-temperature-measurement station	ntemp, nmonths	real	temp_units	-100.0 to 100.0	0.0	temp_module = xyz_dist
tsta_nuse	The subset of temperature stations used in the distribution regression (0=station not used; 1=station used)	ntemp	integer	none	0 or 1	0	temp_module = ide_dist or xyz_dist
tsta_x	Longitude (X) for each air-temperature-measurement station in albers projection	ntemp	real	meters	-1.0E7 to 1.0E7	0.0	temp_module = ide_dist or xyz_dist
tsta_xlong	Longitude of each air-temperature-measurement station, State Plane Coordinate System	ntemp	real	feet	-1.0E9 to 1.0E9	0.0	temp_module = temp_dist2
tsta_y	Latitude (Y) for each air-temperature-measurement station in albers projection	ntemp	real	meters	-1.0E7 to 1.0E7	0.0	temp_module = ide_dist or xyz_dist
tsta_ylat	Latitude of each air-temperature-measurement station, State Plane Coordinate System	ntemp	real	feet	-1.0E9 to 1.0E9	0.0	temp_module = temp_dist2
x_add	Mean value for the climate station transformation equation for the longitude (X) coordinate	one	real	meters	-1.0E7 to 1.0E7	0.0	precip_module and temp_module =

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
x_div	Standard deviation for the climate station transformation equation for the longitude (X) coordinate (not 0 . 0)	one	real	meters	-1.0E7 to 1.0E7	1.0	xyz_dist precip_module and temp_module =
y_add	Mean value for the climate station transformation equation for the latitude (Y) coordinate	one	real	meters	-1.0E7 to 1.0E7	0.0	xyz_dist precip_module and temp_module =
y_div	Standard deviation for the climate station transformation equation for the latitude (Y) coordinate	one	real	meters	-1.0E7 to 1.0E7	1.0	xyz_dist precip_module and temp_module =
z_add	Mean value for the climate station transformation equation for the elevation (Z) coordinate	one	real	meters	-1.0E7 to 1.0E7	0.0	xyz_dist precip_module and temp_module =
z_div	Standard deviation for the climate station transformation equation for the elevation (Z) coordinate (not 0 . 0)	one	real	meters	-1.0E7 to 1.0E7	1.0	xyz_dist precip_module and temp_module =
Solar radiation							
basin_solsta	Index of solar radiation station used to compute basin radiation values; used when dimension nsol >0	one	integer	none	0 to nsol	0	nsol > 0
ccov_intcp	Monthly (January to December) intercept in cloud-cover relationship	nhru, nmonths	real	none	0.0 to 5.0	1.83	solrad_module = ccsolrad or ccsolrad_prms
ccov_slope	Monthly (January to December) coefficient in cloud-cover relationship	nhru, nmonths	real	none	-0.5 to -0.01	-0.13	solrad_module = ccsolrad or ccsolrad_prms
crad_coef	Coefficient(B) in Thompson (1976) equation; varies by region, contour map of values in reference	nhru, nmonths	real	none	0.1 to 0.7	0.4	solrad_module = ccsolrad or ccsolrad_prms
crad_exp	Exponent(P) in Thompson (1976) equation	nhru, nmonths	real	none	0.2 to 0.8	0.61	solrad_module = ccsolrad or ccsolrad_prms
dday_intcp	Monthly (January to December) intercept in degree-day equation for each HRU	nhru, nmonths	real	dday	-60.0 to 10.0	-40.0	solrad_module = ddsolrad or ddsolrad_prms
dday_slope	Monthly (January to December) slope in degree-day equation for each HRU	nhru, nmonths	real	dday/ temp_units	0.2 to 0.9	0.4	solrad_module = ddsolrad or ddsolrad_prms
hru_solsta	Index of solar radiation station associated with each HRU	nhru	integer	none	0 to nsol	0	nsol > 0
ppt_rad_adj	Monthly minimum precipitation, if HRU precipitation	nhru,	real	inches	0.0 to 0.5	0.02	required

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
radadj_intcp	exceeds this value, radiation is multiplied by radj_sppt or radj_wppt precipitation adjustment factor Monthly (January to December) intercept in air temperature range adjustment to degree-day equation for each HRU	nmonths nhru, nmonths	real	dday	0.0 to 1.0	1.0	solrad_module = ddsolrad or ddsolrad_prms solrad_module = ddsolrad or ddsolrad_prms
radadj_slope	Monthly (January to December) slope in air temperature range adjustment to degree-day equation for each HRU	nhru, nmonths	real	dday/ temp_units	0.0 to 1.0	0.0	solrad_module = ddsolrad or ddsolrad_prms solrad_module = ddsolrad or ddsolrad_prms
radj_sppt	Adjustment factor for computed solar radiation for summer day with greater than ppt_rad_adj inches precipitation for each HRU	nhru	real	decimal fraction	0.0 to 1.0	0.44	required
radj_wppt	Adjustment factor for computed solar radiation for winter day with greater than ppt_rad_adj inches precipitation for each HRU	nhru	real	decimal fraction	0.0 to 1.0	0.5	required
radmax	Monthly (January to December) maximum fraction of the potential solar radiation that may reach the ground due to haze, dust, smog, and so forth, for each HRU	nhru, nmonths	real	decimal fraction	0.1 to 1.0	0.8	required
radpl_aspect	Aspect for each radiation plane; used if control parameter	nradpl	real	degrees	0.0 to 360.0	0.0	solrad_module = ddsolrad_prms or ccsolrad_prms solrad_module = ddsolrad_prms or ccsolrad_prms
radpl_lat	Latitude of each radiation plane	nradpl	real	degrees	-90.0 to 90.0	40.0	solrad_module = ddsolrad_prms or ccsolrad_prms solrad_module = ddsolrad_prms or ccsolrad_prms
radpl_slope	Slope of each radiation plane, specified as change in vertical length divided by change in horizontal length	nradpl	real	decimal fraction	0.0 to 10.0	0.0	solrad_module = ddsolrad_prms or ccsolrad_prms solrad_module = ddsolrad_prms or ccsolrad_prms
tmax_index	Monthly (January to December) index temperature used to determine precipitation adjustments to solar radiation for each HRU	nhru, nmonths	real	temp_units	-10.0 to 110.0	50.0	solrad_module = ddsolrad or ddsolrad_prms solrad_module = ddsolrad or ddsolrad_prms
Potential evapotranspiration distribution							
crop_coef	Monthly (January to December) crop coefficient for each HRU	nhru, nmonths	real	decimal fraction	0.0 to 2.0	1.0	et_module = potet_pm
epan_coef	Monthly (January to December) evaporation pan coefficient for each HRU	nhru, nmonths	real	decimal fraction	0.01 to 3.0	1.0	et_module = potet_pan
hamon_coef	Monthly (January to December) air temperature coefficient used in Hamon potential ET computations for each HRU	nhru, nmonths	real	none	0.004 to 0.008	0.0055	et_module = potet_hamon or potet_hamon_prms et_module = potet_hamon or potet_hamon_prms
hru_pansta	Index of pan evaporation station used to compute HRU potential ET	nhru	integer	none	0 to nevap	0	et_module = potet_pan and

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
hs_krs	Monthly (January to December) adjustment factor used in Hargreaves-Samani potential ET computations for each HRU	nhru, nmonths	real	decimal fraction	0.01 to 0.24	0.0135	nevapl > 0 et_module = potet_hs
jh_coef	Monthly (January to December) air temperature coefficient used in Jensen-Haise potential ET computations for each HRU	nhru, nmonths	real	per degrees Fahrenheit	0.0 to 0.1	0.014	et_module = potet_jh
jh_coef_hru	Air temperature coefficient used in Jensen-Haise potential ET computations for each HRU	nhru	real	per degrees Fahrenheit	-99.0 to 150.0	13.0	et_module = potet_jh
pm_d_coef	Monthly (January to December) Penman-Monteith potential ET D wind speed coefficient for each HRU	nhru, nmonths	real	seconds/ meter	0.25 to 0.45	0.34	et_module = potet_pm
pm_n_coef	Monthly (January to December) Penman-Monteith potential ET N temperature coefficient for each HRU	nhru, nmonths	real	degrees Celsius per day	850.0 to 950.0	900.0	et_module = potet_pm
potet_cbh_adj	Monthly (January to December) adjustment factor to potential evapotranspiration specified in CBH Files for each HRU	nhru, nmonths	real	degrees decimal fraction	0.5 to 1.5	1.0	et_module = climate_hru
pt_alpha	Monthly (January to December) adjustment factor used in Priestly-Taylor potential ET computations for each HRU	nhru, nmonths	real	decimal fraction	1.0 to 2.0	1.26	et_module = potet_pt
Evapotranspiration and sublimation							
fall_frost	The solar date (number of days after winter solstice) of the first killing frost of the fall	nhru	integer	solar date	1 to 366	264	transp_module = transp_frost
frost_temp	Temperature of killing frost	nhru	real	temp_units	-10.0 to 32.0	28.0	model_mode = FROST
potet_sublim	Fraction of potential ET that is sublimated from snow in the canopy and snowpack for each HRU	nhru	real	decimal fraction	0.1 to 0.75	0.5	required
rad_trncf	Transmission coefficient for short-wave radiation through the winter vegetation canopy	nhru	real	decimal fraction	0.0 to 1.0	0.5	required
soil_type	Soil type of each HRU (1=sand; 2=loam; 3=clay)	nhru	integer	none	1 to 3	2	required
spring_frost	The solar date (number of days after winter solstice) of the last killing frost of the spring	nhru	integer	solar date	1 to 366	111	transp_module = transp_frost
transp_beg	Month to begin summing maximum air temperature for each HRU; when sum is greater than or equal to transp_tmax , transpiration begins	nhru	integer	month	1 to 12	1	transp_module = transp_tindex
transp_end	Month to stop transpiration computations; transpiration is computed thru end of previous month	nhru	integer	month	1 to 13	13	transp_module = transp_tindex
transp_tmax	Temperature index to determine the specific date of the start of the transpiration period; the maximum air temperature for each HRU is summed starting with the	nhru	real	temp_units	0.0 to 1,000.0	1.0	transp_module = transp_tindex

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
	first day of month transp_beg ; when the sum exceeds this index, transpiration begins						
Interception							
cov_type	Vegetation cover type for each HRU (0=bare soil; 1=grasses; 2=shrubs; 3=trees; 4=coniferous)	nhru	integer	none	0 to 4	3	required
cowden_sum	Summer vegetation cover density for the major vegetation type in each HRU	nhru	real	decimal fraction	0.0 to 1.0	0.5	required
cowden_win	Winter vegetation cover density for the major vegetation type in each HRU	nhru	real	decimal fraction	0.0 to 1.0	0.5	required
snow_intcp	Snow interception storage capacity for the major vegetation type in each HRU	nhru	real	inches	0.0 to 1.0	0.1	required
srain_intcp	Summer rain interception storage capacity for the major vegetation type in each HRU	nhru	real	inches	0.0 to 1.0	0.1	required
wrain_intcp	Winter rain interception storage capacity for the major vegetation type in each HRU	nhru	real	inches	0.0 to 1.0	0.1	required
Snow computations							
albset_rna	Fraction of rain in a mixed precipitation event above which the snow albedo is not reset; applied during the snowpack accumulation stage	one	real	decimal fraction	0.5 to 1.0	0.8	required
albset_rnm	Fraction of rain in a mixed precipitation event above which the snow albedo is not reset; applied during the snowpack melt stage	one	real	decimal fraction	0.4 to 1.0	0.6	required
albset_sna	Minimum snowfall, in water equivalent, needed to reset snow albedo during the snowpack accumulation stage	one	real	inches	0.01 to 1.0	0.05	required
albset_snm	Minimum snowfall, in water equivalent, needed to reset snow albedo during the snowpack melt stage	one	real	inches	0.1 to 1.0	0.2	required
cecn_coef	Monthly (January to December) convection condensation energy coefficient for each HRU	nhru, nmonths	real	calories per degree Celsius > 0	0.02.0 to 20.0	5.0	required
den_init	Initial density of new-fallen snow	one	real	grams/cubic centimeters	0.01 to 0.5	0.1	required
den_max	Average maximum snowpack density	one	real	grams/cubic centimeters	0.1 to 0.8	0.6	required
emis_noppt	Average emissivity of air on days without precipitation for each HRU	nhru	real	decimal fraction	0.757 to 1.0	0.757	required
freeh2o_cap	Free-water holding capacity of snowpack expressed as a decimal fraction of the frozen water content of the snowpack (<i>pk_ice</i>) for each HRU	nhru	real	decimal fraction	0.01 to 0.2	0.05	required
hru_deplcrv	Index number for the snowpack areal depletion curve associated with each HRU	nhru	integer	none	1 to ndepl	1	required

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
melt_force	Julian date to force snowpack to spring snowmelt stage; varies with region depending on length of time that permanent snowpack exists for each HRU	nhru	integer	Julian day	1 to 366	140	required
melt_look	Julian date to start looking for spring snowmelt stage; varies with region depending on length of time that permanent snowpack exists for each HRU	nhru	integer	Julian day	1 to 366	90	required
settle_const	Snowpack settlement time constant	one	real	decimal fraction	0.01 to 0.5	0.1	required
snarea_curve	Snow area depletion curve values, 11 values for each curve (0.0 to 1.0 in 0.1 increments)	ndeplval	real	decimal fraction	0.0 to 1.0	1.0	required
snarea_thresh	Maximum threshold snowpack water equivalent below which the snow-covered-area curve is applied; varies with elevation	nhru	real	inches	0.0 to 200.0	50.0	required
snowpack_init	Storage of snowpack in each HRU at the beginning of a simulation	nhru	real	inches	0.0 to 5000.0	0.0	required
tsorm_mo	Monthly indicator for prevalent storm type (0=frontal storms; 1=convective storms) for each HRU	nhru, nmonths	integer	none	0 or 1	0	required
Hortonian surface runoff, infiltration, and impervious storage							
carea_max	Maximum possible area contributing to surface runoff expressed as a portion of the HRU area	nhru	real	decimal fraction	0.0 to 1.0	0.6	required
carea_min	Minimum possible area contributing to surface runoff expressed as a portion of the area for each HRU	nhru	real	decimal fraction	0.0 to 1.0	0.2	srunoff_module = srunoff_carea
hru_percent_imperv²	Fraction of each HRU area that is impervious	nhru	real	decimal fraction	0.0 to 0.999	0.0	required
imperv_stor_max	Maximum impervious area retention storage for each HRU	nhru	real	inches	0.0 to 0.5	0.05	required
smidx_coef	Coefficient in non-linear contributing area algorithm for each HRU	nhru	real	decimal fraction	0.0 to 1.0	0.005	srunoff_module = srunoff_smidx
smidx_exp	Exponent in non-linear contributing area algorithm for each HRU	nhru	real	1/inch	0.0 to 1.0	0.3	srunoff_module = srunoff_smidx
snowinfil_max	Maximum snow infiltration per day for each HRU	nhru	real	inches/day	0.0 to 20.0	2.0	required
Surface depression storage							
dprst_area	Aggregate sum of surface-depression storage areas of each HRU (recommend that dprst_frac_hru be used instead of dprst_area)	nhru	real	acres	0.0 to 1.0E9	0.0	dprst_flag = 1
dprst_depth_avg	Average depth of storage depressions at maximum storage capacity	nhru	real	inches	0.0 to 500.0	132.0	dprst_flag = 1
dprst_et_coef	Fraction of unsatisfied potential evapotranspiration to apply to surface-depression storage	nhru	real	decimal fraction	0.0 to 1.0	1.0	dprst_flag = 1
dprst_flow_coef	Coefficient in linear flow routing equation for open	nhru	real	fraction/day	0.00001 to	0.05	dprst_flag = 1

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
dprst_frac_hru	surface depressions for each HRU Fraction of each HRU area that has surface depressions (If specified the parameter dprst_area is ignored if it also is specified)	nhru	real	decimal fraction	0.5 -1.0 to 0.999	-1.0	dprst_flag = 1
dprst_frac_init	Fraction of maximum surface-depression storage that contains water at the start of a simulation	nhru	real	decimal fraction	0.0 to 1.0	0.5	dprst_flag = 1
dprst_frac_open	Fraction of open surface-depression storage area within an HRU that can generate surface runoff as a function of storage volume	nhru	double	decimal fraction	0.0 to 1.0	1.0	dprst_flag = 1
dprst_seep_rate_clos	Coefficient used in linear seepage flow equation for closed surface depressions for each HRU	nhru	real	fraction/day	0.0001 to 0.1	0.02	dprst_flag = 1
dprst_seep_rate_open	Coefficient used in linear seepage flow equation for open surface depressions for each HRU	nhru	real	fraction/day	0.0001 to 0.1	0.02	dprst_flag = 1
op_flow_thres	Fraction of open depression storage above which surface runoff occurs; any water above maximum open storage capacity spills as surface runoff	nhru	real	decimal fraction	0.01 to 1.0	1.0	dprst_flag = 1
sro_to_dprst_imperv	Fraction of impervious surface runoff that flows into surface-depression storage; the remainder flows to a stream network for each HRU	nhru	real	decimal fraction	0.0 to 1.0	0.2	dprst_flag = 1
sro_to_dprst_perv	Fraction of pervious surface runoff that flows into surface-depression storage; the remainder flows to a stream network for each HRU	nhru	real	decimal fraction	0.0 to 1.0	0.2	dprst_flag = 1
va_clos_exp	Coefficient in the exponential equation relating maximum surface area to the fraction that closed depressions are full to compute current surface area for each HRU; 0.001 is an approximate rectangle; 1.0 is a triangle	nhru	real	none	0.0001 to 10.0	0.001	dprst_flag = 1
va_open_exp	Coefficient in the exponential equation relating maximum surface area to the fraction that open depressions are full to compute current surface area for each HRU; 0.001 is an approximate rectangle; 1.0 is a triangle	nhru	real	none	0.0001 to 10.0	0.001	dprst_flag = 1
Soil zone storage, interflow, gravity drainage, dunnian surface runoff							
fastcoef_lin	Linear coefficient in equation to route preferential-flow storage down slope for each HRU	nhru	real	fraction/day	0.0 to 1.0	0.1	required ⁸
fastcoef_sq	Non-linear coefficient in equation to route preferential-flow storage down slope for each HRU	nhru	real	none	0.0 to 1.0	0.8	required ⁸
hru_ssres⁷	Index of subsurface reservoir receiving excess water from capillary reservoir	nhru	integer	none	1 to nssr	1	soilzone_module = embai_pme

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
pref_flow_den	Fraction of the soil zone in which preferential flow occurs for each HRU	nhru	real	decimal fraction	0.0 to 0.5	0.0	required ⁸
sat_threshold	Water holding capacity of the gravity and preferential-flow reservoirs; difference between field capacity and total soil saturation for each HRU	nhru	real	inches	0.00001 to 999.0	999.0	required ⁸
slowcoef_lin	Linear coefficient in equation to route gravity-reservoir storage down slope for each HRU	nhru	real	fraction/day	0.0 to 1.0	0.015	required ⁸
slowcoef_sq	Non-linear coefficient in equation to route gravity-reservoir storage down slope for each HRU	nhru	real	none	0.0 to 1.0	0.1	required ⁸
soil_moist_init	Initial value of available water in capillary reservoir for each HRU	nhru	real	inches	0.0 to 10.0	3.0	required
soil_moist_max	Maximum available water holding capacity of capillary reservoir from land surface to rooting depth of the major vegetation type of each HRU	nhru	real	inches	0.00001 to 20.0	2.0	required
soil_rechr_init	Initial storage for soil recharge zone (upper part of capillary reservoir where losses occur as both evaporation and transpiration) for each HRU; must be less than or equal to soil_moist_init	nhru	real	inches	0.00001 to 10.0	1.0	required
soil_rechr_max	Maximum storage for soil recharge zone (upper portion of capillary reservoir where losses occur as both evaporation and transpiration) of must be less than or equal to soil_moist_max	nhru	real	inches	0.0 to 5.0	1.5	required
soil2gw_max	Maximum amount of the capillary reservoir excess that is routed directly to the GWR for each HRU	nhru	real	inches	0.0 to 5.0	0.0	required
ssr2gw_exp	Non-linear coefficient in equation used to route water from the gravity reservoirs to the GWR for each HRU	nssr	real	none	0.0 to 3.0	1.0	required
ssr2gw_rate	Linear coefficient in equation used to route water from the gravity reservoir to the GWR for each HRU	nssr	real	fraction/day	0.0001 to 1.0	0.1	required
ssrcoef_lin⁸	Coefficient to route subsurface storage to streamflow using the following equation: $ssres_flow = ssrcoef_lin * ssres_stor + ssrcoef_sq * ssres_stor^{**}2$	nssr	real	fraction/day	0.0 to 1.0	0.1	soilzone_module = embal_prms
ssrcoef_sq⁸	Coefficient to route subsurface storage to streamflow using the following equation: $ssres_flow = ssrcoef_lin * ssres_stor + ssrcoef_sq * ssres_stor^{**}2$	nssr	real	none	0.0 to 1.0	0.1	soilzone_module = embal_prms
ssrmax_coef⁸	Coefficient in equation used to route water from the subsurface reservoirs to the ground water reservoirs: $ssr_to_gw = ssr2gw_rate * ((ssres_stor / ssrmax_coef) ** ssr2gw_exp)$; recommended value is 1.0	nssr	real	inches	1.0 to 20.0	1.0	soilzone_module = embal_prms
ssstor_init	Initial storage of the gravity and preferential-flow reservoirs for each HRU	nssr	real	inches	0.0 to 5.0	0.0	required

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
Groundwater flow							
gwflow_coef	Linear coefficient in the equation to compute groundwater discharge for each GWR	ngw	real	fraction/day	0.0 to 0.5	0.015	required
gwsink_coef	Linear coefficient in the equation to compute outflow to the groundwater sink for each GWR	ngw	real	fraction/day	0.0 to 0.05	0.0	required
gwstor_init	Storage in each GWR at the beginning of a simulation	ngw	real	inches	0.0 to 10.0	2.0	required
gwstor_min	Minimum storage in each GWR to ensure storage is greater than specified value to account for inflow from deep aquifers or injection wells with the water source outside the basin	ngw	real	inches	0.0 to 1.0	0.0	required
hru_gwres²	Index of GWR receiving soil zone drainage from each associated HRU	nhru	integer	none	1 to ngw	1	soilzone_module = embal_prms
ssr_gwres²	Index of the GWR that receives flow from each associated subsurface or gravity reservoir	nssr	integer	none	1 to ngw	1	soilzone_module = embal_prms
Streamflow							
hru_segment	Segment index to which an HRU contributes lateral flows (surface runoff, interflow, and groundwater discharge)	nhru	integer	none	0 to nsegment	0	strmflow_module = muskingum, strmflow_in_out , or strmflow_lake
K_coef	Travel time of flood wave from one segment to the next downstream segment, called the Muskingum storage coefficient; enter 1.0 for reservoirs, diversions, and segment(s) flowing out of the basin	nsegment	real	hours	0.01 to 24.0	1.0	strmflow_module = muskingum
obsin_segment	Index of measured streamflow station that replaces inflow to a segment	nsegment	integer	none	0 to nobs	0	strmflow_module = muskingum, strmflow_in_out , or strmflow_lake
segment_flow_init	Initial flow in each stream segment	nsegment	real	cfs	0 to 1.0E7	0.0	strmflow_module = muskingum, strmflow_in_out , or strmflow_lake
segment_type	Segment type (0=segment; 1=diversion; 2=lake; 3=replace inflow)	nsegment	integer	none	0 to 3	0	strmflow_module = muskingum, strmflow_in_out , or strmflow_lake
tosegment	Index of downstream segment to which the segment	nsegment	integer	none	0 to	0	strmflow_module =

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
	streamflow flows; for segments that do not flow to another segment enter 0				nsegment		muskingum, strmflo_w_in_out, or strmflo_w_lake
x_coef	The amount of attenuation of the flow wave, called the Muskingum routing weighting factor; enter 0.0 for reservoirs, diversions, and segment(s) flowing out of the basin	nsegment	real	decimal fraction	0.0 to 0.5	0.2	strmflo_w_module = muskingum
Lake routing							
elev_outflow	Elevation of the main outflow point for each lake using broad-crested weir routing	nlake	real	feet	-300.0 to 10,000.0	0.0	strmflo_w_module = strmflo_w_lake
elevlake_init	Initial lake surface elevation for each lake using broad-crested weir routing or gate opening routing	nlake	real	feet	-300.0 to 10,000.0	1.0	strmflo_w_module = strmflo_w_lake
gw_seep_coef	Linear coefficient in equation to compute lakebed seepage to the GWR and groundwater discharge to each lake using broad-crested weir routing or gate opening routing	nlake	real	fraction/day	0.001 to 0.05	0.015	strmflo_w_module = strmflo_w_lake
lake_coef	Coefficient in equation to route storage to streamflow for each lake using linear routing	nlake	real	fraction/day	0.0001 to 1.0	0.1	strmflo_w_module = strmflo_w_lake
lake_din1	Initial inflow to each lake using Puls or linear storage routing	nlake	real	cfs	0.0 to 1.0E7	0.1	strmflo_w_module = strmflo_w_lake
lake_evap_adj	Monthly (January to December) adjustment factor for potential ET for each lake	nhru	real	decimal fraction	0.5 to 1.0	1.0	strmflo_w_module = strmflo_w_lake
lake_hru	Index of HRU for each lake	nlake	integer	none	0 to nhru	0	strmflo_w_module = strmflo_w_lake
lake_hru_id	Identification number of the lake associated with an HRU; more than one HRU can be associated with each lake	nhru	integer	none	0 to nlake	0	strmflo_w_module = strmflo_w_lake
lake_init	Initial storage in each lake using Puls or linear storage routing	nlake	real	cfs-days	0.0 to 1.0E7	0.0	strmflo_w_module = strmflo_w_lake
lake_out2	Switch to specify a second outflow point from each lake using gate opening routing (0=no; 1=yes)	nlake	integer	none	0 or 1	0	strmflo_w_module = strmflo_w_lake
lake_out2_a	Coefficient A in outflow equation for each lake with a second outlet using gate opening routing	nlake	real	cfs/feet	0.0 to 10,000.0	1.0	strmflo_w_module = strmflo_w_lake
lake_out2_b	Coefficient B in outflow equation for each lake with a second outlet using gate opening routing	nlake	real	cfs	0.0 to 10,000.0	100.0	strmflo_w_module = strmflo_w_lake
lake_qro	Initial daily mean outflow from each lake	nlake	real	cfs	0.0 to 1.0E7	0.1	strmflo_w_module = strmflo_w_lake
lake_seep_elev	Elevation over which lakebed seepage to the GWR occurs for lake HRUs using broad-crested weir routing	nlake	real	feet	-300.0 to 10,000.0	1.0	strmflo_w_module = strmflo_w_lake

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
lake_type	or gate opening routing Type of lake routing method (1=Puls routing; 2=linear routing; 3=flow through; 4=broad crested weir; 5=gate opening; and 6=measured flow)	nlake	integer	none	1 to 6	1	strmflow_module = strmflow_lake
lake_vol_init	Initial lake volume for each lake using broad-crested weir or gate opening routing	nlake	real	acre-feet	0.0 to 1.0E7	0.0	strmflow_module = strmflow_lake
nsos	Number of storage/outflow values in table for each lake using Puls routing	mxnsos , nlake	integer	none	0 to mxnsos	0	strmflow_module = strmflow_lake
o2	Outflow values in outflow/storage tables for each lake using Puls routing	mxnsos , nlake	real	cfs	0.0 to 1.0E7	0.0	strmflow_module = strmflow_lake
obsout_lake	Index of streamflow measurement station that specifies outflow from each lake using measured flow replacement	nlake	integer	none	0 to nobs	0	strmflow_module = strmflow_lake
rate_table	Rating table with stage (rows) and gate opening (cols) for rating table 1 for lakes using gate opening routing and nratetbl >0	nstage , ngate	real	cfs	-100.0 to 1,000.0	5.0	strmflow_module = strmflow_lake
rate_table2	Rating table with stage (rows) and gate opening (cols) for rating table 2 for lakes using gate opening routing and nratetbl >1	nstage2 , ngate2	real	cfs	-100.0 to 1,000.0	5.0	strmflow_module = strmflow_lake
rate_table3	Rating table with stage (rows) and gate opening (cols) for rating table 3 for lakes using gate opening routing and nratetbl >2	nstage3 , ngate3	real	cfs	-100.0 to 1,000.0	5.0	strmflow_module = strmflow_lake
rate_table4	Rating table with stage (rows) and gate opening (cols) for rating table 4 for lakes using gate opening routing and nratetbl >3	nstage4 , ngate4	real	cfs	-100.0 to 1,000.0	5.0	strmflow_module = strmflow_lake
ratetbl_lake	Index of lake associated with each rating table for each lake using gate opening routing	nratetbl	integer	none	0 to nlake	0	strmflow_module = strmflow_lake
s2	Storage values in outflow/storage table for each lake using Puls routing	mxnsos , nlake	real	cfs	0.0 to 1.0E7	0.0	strmflow_module = strmflow_lake
tbl_gate	Gate openings for each column for rating table 1 for lakes using gate opening routing and nratetbl >0	ngate	real	inches	0.0 to 20.0	0.0	strmflow_module = strmflow_lake
tbl_gate2	Gate openings for each column for rating table 2 for lakes using gate opening routing and nratetbl >1	ngate2	real	inches	0.0 to 20.0	0.0	strmflow_module = strmflow_lake
tbl_gate3	Gate openings for each column for rating table 3 for lakes using gate opening routing and nratetbl >2	ngate3	real	inches	0.0 to 20.0	0.0	strmflow_module = strmflow_lake
tbl_gate4	Gate openings for each column for rating table 4 for lakes using gate opening routing and nratetbl >3	ngate4	real	inches	0.0 to 20.0	0.0	strmflow_module = strmflow_lake
tbl_stage	Stage values for each row for rating table 1 for lakes using gate opening routing and nratetbl >0	nstage	real	feet	-100.0 to 1,000.0	5.0	strmflow_module = strmflow_lake
tbl_stage2	Stage values for each row for rating table 2 for lakes	nstage2	real	feet	-100.0 to	5.0	strmflow_module =

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
tbl_stage3	using gate opening routing and nratetbl >1 Stage values for each row for rating table 3 for lakes	nstage3	real	feet	1,000.0 -100.0 to	5.0	strmflow_lake strmflow_module =
tbl_stage4	using gate opening routing and nratetbl >2 Stage values for each row for rating table 4 for lakes	nstage4	real	feet	1,000.0 -100.0 to	5.0	strmflow_lake strmflow_module =
weir_coef	using gate opening routing and nratetbl >3 Coefficient for lakes using broad-crested weir routing	nlake	real	none	1,000.0 2.0 to 3.0	2.7	strmflow_lake strmflow_module =
weir_len	Weir length for lakes using broad-crested weir routing	nlake	real	feet	1.0 to 1,000.0	5.0	strmflow_lake strmflow_module =
Output options							
moyrsum	Switch for HRU monthly and yearly summary (0=off, 1=on)	one	integer	none	0 or 1	0	solrad_module = ddsolrad_prms or ecsolrad_prms
pmo	Month to print HRU summary	one	integer	none	0 to 12	0	solrad_module = ddsolrad_prms or ecsolrad_prms
print_freq	Flag to select the output frequency; for combinations, add index numbers, e.g., daily plus yearly = 10; yearly plus total = 3 (0=none; 1=run totals; 2=yearly; 4=monthly; 8=daily; or additive combinations)	one	integer	none	0 to 15	3	required
print_type	Flag to select the type of results written to the output file (0=measured and simulated flow only; 1=water balance table; 2=detailed output)	one	integer	none	0 to 2	1	required
Subbasin parameters							
hru_subbasin	Index of subbasin assigned to each HRU	nhru	integer	none	0 to user defined	0	subbasin_flag = 1
subbasin_down	Index number for the downstream subbasin whose inflow is outflow from this subbasin	nsub	integer	none	0 to nsub	0	subbasin_flag = 1
Mapped results parameters							
gvr_cell_id⁹	Index of the grid cell associated with each gravity reservoir	nhrucell	integer	none	0 to ngwcell	0	mapOutON_OFF = 1
gvr_cell_pct⁹	Proportion of the grid cell area associated with each gravity reservoir	nhrucell	real	decimal fraction	0.0 to 1.0	1.0	mapOutON_OFF = 1
gvr_hru_id⁹	Index of the HRU associated with each gravity reservoir	nhrucell	integer	none	0 to nhrucell	1	mapOutON_OFF = 1
mapvars_freq	Flag to specify the output frequency (0=none; 1=monthly; 2=yearly; 3=total; 4=monthly and yearly; 5=monthly, yearly, and total; 6=weekly; 7=daily)	one	integer	none	0 to 7	0	mapOutON_OFF = 1
mapvars_units	Flag to specify the output units of mapped results	one	integer	none	0 to 3	0	mapOutON_OFF = 1

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
ncol	(0=units of the variable; 1=inches to feet; 2=inches to centimeters; 3=inches to meters; as states or fluxes)	one	integer	none	1 to 50000	1	mapOutON_OFF = 1
prms_warmup	Number of columns for each row of the mapped results Number of years to simulate before writing mapped results	one	integer	years	0 to user defined	1	mapOutON_OFF = 1 or nhruOutON_OFF = 1
Summary results CSV file parameters							
poi_gage_id	USGS stream gage for this POI	npoigages	string	none	user defined	0	npoigages > 0 and csvON_OFF = 1
poi_gage_segment	Segment index for gage POI	npoigages	integer	none	0 to nsegment	0	npoigages > 0 and csvON_OFF = 1
Parameters for cascading-flow simulation							
cascade_flg	Flag to indicate cascade type (0=allow many to many; 1=force one to one)	one	integer	none	0 or 1	0	cascade_flag = 1 and ncascade > 0 and/or cascadegw_flag = 1 ncascdgw > 0
cascade_tol	Cascade area below which a cascade link is ignored	one	real	acres	0.0 to 0.75% of hru_area	5.0	cascade_flag = 1 and ncascade > 0 and/or cascadegw_flag = 1 ncascdgw > 0
circle_switch	Switch to check for circles (0=no check; 1=check)	one	integer	none	0 or 1	1	cascade_flag = 1 and ncascade > 0 and/or cascadegw_flag = 1 ncascdgw > 0
gw_down_id³	Index number of the downslope GWR to which the upslope GWR contributes flow; -1 specifies that cascading flow for cascade link leaves the model domain as farfield flow	ncascdgw	integer	none	0 to ngw	0	cascadegw_flag = 1 and ncascdgw > 0
gw_pct_up	Fraction of GWR area used to compute flow contributed to a down slope GWR or stream segment for cascade area	ncascdgw	real	decimal fraction	0.0 to 1.0	1.0	cascadegw_flag = 1 and ncascdgw > 0
gw_strmseg_down_id	Index number of the stream segment that cascade area contributes flow	ncascdgw	integer	none	0 to nsegment	0	cascadegw_flag = 1 and ncascdgw > 0
gw_up_id	Index of GWR containing cascade area	ncascdgw	integer	none	1 to ngw	0	cascadegw_flag = 1 and ncascdgw > 0
hru_down_id⁴	Index number of the downslope HRU to which the upslope HRU contributes flow; -1 specifies that cascading flow for cascade link leaves the model domain as farfield flow	ncascade	integer	none	0 to nhru	0	cascade_flag = 1 and ncascade > 0
hru_pct_up	Fraction of HRU area used to compute flow contributed	ncascade	real	decimal	0.0 to 1.0	1.0	cascade_flag = 1 and

Parameter name	Description	Dimension ¹	Type	Units	Range	Default	Required/condition
	to a down slope HRU or stream segment for cascade area			fraction			ncascade > 0
hru_strmseg_down_id	Index number of the stream segment that cascade area contributes flow	ncascade	integer	none	0 to nsegment	0	cascade_flag = 1 and ncascade > 0
hru_up_id	Index of HRU containing cascade area	ncascade	integer	none	0 to nhru	0	cascade_flag = 1 and ncascade > 0

¹Dimensions defined in table 1-1.

²~~Parameter is used to compute variable *hru_frac_imperv*, which is **hru_percent_imperv** adjusted for the requirement that the sum of values for parameter **dprst_area** and **hru_percent_imperv** are < 0.999 x **hru_area** for each HRU.~~

³ If the value of **gw_strmseg_down_id**>0 for cascade link, this value is ignored. ~~If specified as -1, any down-slope flow leaves the basin and is added to any other farfield flow.~~

⁴ If the value of **hru_strmseg_down_id**>0 for cascade link, this value is ignored. ~~If specified as -1, any down-slope flow leaves the basin and is added to any other farfield flow.~~

⁵Parameter can be modified if the code determines an HRU is a swale, based on values of the cascade parameters.

⁶~~Parameter required unless radiation planes are used; when control parameter **solrad_module**=**ddsolrad_prms** or **ccsolrad_prms**.~~

⁷~~Parameter required if dimensions **nhru**, **nssr**, and **ngw** are not equal (deprecated).~~

⁸~~Parameter required unless the unless control parameter **soilzone_module**=**smbal_prms** (deprecated) module.~~

⁹Parameter name is based on parameter of same name specified for the Groundwater and Surface-Water Flow (GSFLOW) model (Markstrom and others, 2008). Only required if the HRU map is different than the target map, that is, dimension **nhru** not equal to **ngwcell**.

¹⁰~~Parameter is compared to the computed variable *basin_area_inv* that is set to 1.0 divided by the total active model domain area, which is the sum of values for parameter **hru_area**, for HRUs with parameter **hru_type**>0 and is not used in any computations.~~

Table 1-4. Time-series input variables that may be included in the Data File for the Precipitation-Runoff Modeling System, version 4 (PRMS-IV).

[cfs, cubic feet per second; cms, cubic meters per second; **runoff_units**, 0=cfs; 1=cms; **precip_units**, 0=inches; 1=millimeters; **temp_units**, 0=degrees Fahrenheit; 1=degrees Celsius; >=, greater than or equal to]

Variable	Definition	Units	Valid range	Dimension ¹
<i>gate_ht</i>	Height of the gate opening at each dam with a gate	inches	>=0.0	nratetbl
<i>humidity</i>	Relative humidity at each measurement station	percentage	0.0 to 1.0	nhumid
<i>lake_elev</i>	Elevation of each simulated lake surface	feet	unlimited	nlakeelev
<i>pan_evap</i>	Pan evaporation at each measurement station	inches	>=0.0	nevap
<i>precip</i>	Precipitation at each measurement station	precip_units	>=0.0	nrain
<i>rain_day</i>	Flag to set the form of any precipitation to rain (0=determine form; 1=rain)	none	0 or 1	one
<i>runoff</i>	Streamflow at each measurement station	runoff_units	>=0.0	nobs
<i>snowdepth</i>	Snow depth at each measurement station	inches	>=0.0	nsnow
<i>solrad</i>	Solar radiation at each measurement station	Langleys	>=0.0	nsol
<i>tmax</i>	Maximum air temperature at each measurement station	temp_units	-99.0 to 150.0	ntemp
<i>tmin</i>	Minimum air temperature at each measurement station	temp_units	-99.0 to 150.0	ntemp
<i>wind_speed</i>	Wind speed at each measurement station	miles per hour	0.0 to 500.0	nwind

¹Dimensions defined in table 1-1.

Table 1-5. Input and output variables for the Precipitation-Runoff Modeling System, version 4 (PRMS-IV).

[HRU, hydrologic response unit; GWR, groundwater reservoir; CBH, climate-by-HRU; ET, evapotranspiration; cfs: cubic feet per second; cms: cubic meters per second; >, greater than; **runoff_units**, 0=cfs; 1=cms; **precip_units**, 0=inches; 1=millimeters; **temp_units**, 0=degrees Fahrenheit; 1=degrees Celsius; control parameters **temp_module**, **precip_module**, **et_module**, **strmflow_module**, **model_mode**, **dprst_flag**, **subbasin_flag**, **cascade_flag**, and **cascadegw_flag** defined in table 1-2]

Variable name	Description	Dimension ¹	Units	Data type	Availability/condition
Climate distribution					
<i>basin_lakeprecip</i>	Basin area-weighted average precipitation on lake HRUs	one	inches	double	nlake > 0
<i>basin_lapse_max</i>	Basin area-weighted average maximum air temperature lapse rate per 1,000 feet	one	temp_units / feet	real	temp_module = temp_dist2
<i>basin_lapse_min</i>	Basin area-weighted average minimum air temperature lapse rate per 1,000 feet	one	temp_units / feet	real	temp_module = temp_dist2
<i>basin_max_temp_mo</i>	Monthly basin area-weighted average maximum air temperature	one	temp_units	double	always
<i>basin_max_temp_tot</i>	Total simulation basin area-weighted average maximum air temperature	one	temp_units	double	always
<i>basin_max_temp_yr</i>	Yearly basin area-weighted average maximum air temperature	one	temp_units	double	always
<i>basin_min_temp_mo</i>	Monthly basin area-weighted average minimum air temperature	one	temp_units	double	always
<i>basin_min_temp_tot</i>	Total simulation basin area-weighted average minimum air temperature	one	temp_units	double	always
<i>basin_min_temp_yr</i>	Yearly basin area-weighted average minimum air temperature	one	temp_units	double	always
<i>basin_net_ppt</i>	Basin area-weighted average throughfall	one	inches	double	always
<i>basin_net_ppt_mo</i>	Monthly basin area-weighted average net precipitation	one	inches	double	always
<i>basin_net_ppt_yr</i>	Yearly basin area-weighted average net precipitation	one	inches	double	always
<i>basin_obs_ppt</i>	Basin area-weighted measured average precipitation	one	inches	double	always
<i>basin_ppt</i>	Basin area-weighted average precipitation	one	inches	double	always
<i>basin_ppt_mo</i>	Monthly basin area-weighted average precipitation	one	inches	double	always
<i>basin_ppt_tot</i>	Total simulation basin area-weighted average precipitation	one	inches	double	always
<i>basin_ppt_yr</i>	Yearly basin area-weighted average precipitation	one	inches	double	always
<i>basin_rain</i>	Basin area-weighted average rainfall	one	inches	double	always
<i>basin_snow</i>	Basin area-weighted average snowfall	one	inches	double	always
<i>basin_temp</i>	Basin area-weighted average air temperature	one	temp_units	double	always
<i>basin_tmax</i>	Basin area-weighted maximum air temperature	one	temp_units	double	always
<i>basin_tmin</i>	Basin area-weighted minimum air temperature	one	temp_units	double	always
<i>hru_ppt</i>	Precipitation distributed to each HRU	nhru	inches	real	always
<i>hru_rain</i>	Rain distributed to each HRU	nhru	inches	real	always
<i>hru_snow</i>	Snow distributed to each HRU	nhru	inches	real	always

<i>humidity</i>	Relative humidity at each measurement station	nhumid	percentage	real	nhumid > 0
<i>humidity_hru</i>	Relative humidity for each HRU	nhru	percentage	real	et_module = potet_pm
<i>is_rain_day</i>	Flag to indicate if it is raining anywhere in the basin	one	none	integer	precip_module = ide_dist or xyz_dist
<i>lake_precip</i>	Total precipitation into each lake HRU	nlake	cfs	double	strmflow_module = strmflow_lake
<i>newsnow</i> ²	Flag to indicate if new snow fell on each HRU (0=no; 1=yes)	nhru	none	integer	always
<i>pptmix</i> ²	Flag to indicate if precipitation is a mixture of rain and snow for each HRU (0=no; 1=yes)	nhru	none	integer	always
<i>precip</i>	Precipitation at each measurement station	nrain	precip_units	real	nrain > 0
<i>prmx</i>	Fraction of rain in a mixed precipitation event for each HRU	nhru	decimal fraction	real	always
<i>subinc_precip</i>	Area-weighted average precipitation on associated HRUs to each subbasin	nsb	inches	double	subbasin_flag = 1
<i>subinc_rain</i>	Area-weighted average rain from associated HRUs to each subbasin	nsb	inches	double	subbasin_flag = 1
<i>subinc_snow</i>	Area-weighted average snow on associated HRUs to each subbasin	nsb	inches	double	subbasin_flag = 1
<i>subinc_tavgc</i>	Area-weighted average air temperature for associated HRUs to each subbasin	nsb	degrees Celsius	double	subbasin_flag = 1
<i>subinc_tmaxc</i>	Area-weighted average maximum air temperature for associated HRUs to each subbasin	nsb	degrees Celsius	double	subbasin_flag = 1
<i>subinc_tminc</i>	Area-weighted average minimum air temperature for associated HRUs to each subbasin	nsb	degrees Celsius	double	subbasin_flag = 1
<i>tavgc</i>	Average air temperature distributed to each HRU	nhru	degrees Celsius	real	always
<i>tavgf</i>	Average air temperature distributed to each HRU	nhru	degrees Fahrenheit	real	always
<i>tmax</i>	Maximum air temperature at each measurement station	ntemp	temp_units	real	ntemp > 0
<i>tmax_rain_sta</i>	Maximum air temperature distributed to the precipitation stations	nrain	degrees Fahrenheit	real	precip_module = ide_dist or xyz_dist
<i>tmaxc</i>	Maximum air temperature distributed to each HRU	nhru	degrees Celsius	real	always
<i>tmaxf</i>	Maximum air temperature distributed to each HRU	nhru	degrees Fahrenheit	real	always
<i>tmin</i>	Minimum air temperature at each measurement station	ntemp	temp_units	real	ntemp > 0
<i>tmin_hru</i>	Minimum air temperature distributed to each HRU	nhru	temp_units	real	always
<i>tmin_rain_sta</i>	Minimum air temperature distributed to the precipitation measurement stations	nrain	degrees Fahrenheit	real	precip_module = ide_dist or xyz_dist
<i>tminc</i>	Minimum air temperature distributed to each HRU	nhru	degrees Celsius	real	always
<i>tminf</i>	Minimum air temperature distributed to each HRU	nhru	degrees Fahrenheit	real	always
<i>wind_speed</i>	Wind speed at each measurement station	nwind	miles per hour	real	nwind > 0
<i>wind_speed_hru</i>	Wind speed for each HRU	nhru	miles per hour	real	et_module = potet_pm
Solar radiation distribution					
<i>basin_clear_sky</i>	Basin area-weighted average clear sky proportion	one	decimal fraction	double	solrad_module =

basin_cloud_cover	Basin area-weighted average cloud cover proportion	one	decimal fraction	double	ccsolrad
basin_horad	Potential shortwave radiation for the basin centroid	one	Langleys	double	solrad_module = ccsolrad
basin_orad	Basin area-weighted average shortwave radiation on a horizontal surface	one	Langleys	double	always
basin_potsw	Basin area-weighted average potential shortwave radiation	one	Langleys	double	solrad_module = ccsolrad or ddsolrad
basin_radadj	Basin area-weighted average radiation adjustment for cloud cover	one	decimal fraction	double	always
basin_swradi	Basin area-weighted average shortwave radiation	one	Langleys	double	solrad_module = ccsolrad
clear_sky	Clear sky proportion for each HRU	nhru	decimal fraction	double	always
cloud_cover_hru	Cloud cover proportion of each HRU	nhru	decimal fraction	double	solrad_module = ccsolrad
cloud_radadj	Radiation adjustment for cloud cover of each HRU	nhru	decimal fraction	double	solrad_module = ccsolrad
lwrad_net	Net long-wave radiation for each HRU	nhru	Megajoules/m**2/day	real	et_module = potet_pm
orad	Measured or computed solar radiation on a horizontal surface	one	Langleys	real	solrad_module = ccsolrad or ddsolrad
orad_hru	Solar radiation on a horizontal surface for each HRU	one	Langleys	double	solrad_module = ccsolrad or ddsolrad
seginc_swradi	Area-weighted average solar radiation for each segment from HRUs contributing flow to the segment	nsegment	Langleys	double	nsegment > 0
solrad	Solar radiation at each measurement station	nsol	Langleys	real	nsol > 0
solrad_tmax⁵	Basin maximum air temperature for use with solar radiation calculations	one	temp_units	real	always
solrad_tmin⁵	Basin minimum air temperature for use with solar radiation calculations	one	temp_units	real	always
soltab_horad_potsw	Potential solar radiation on a horizontal plane for each Julian Day, for each HRU	ndays, nhru	Langleys	double	always
soltab_potsw	Potential solar radiation for each Julian Day, for each HRU	ndays, nhru	Langleys	double	always
subinc_swradi	Area-weighted average shortwave radiation distributed to associated HRUs of each subbasin	nsub	Langleys	double	subbasin_flag = 1
swrad	Shortwave radiation distributed to each HRU	nhru	Langleys	real	always
Interception					
basin_intcp_stor	Basin area-weighted average interception storage	one	inches	double	always
basin_net_rain	Basin area-weighted average rain throughfall	one	inches	double	always
basin_net_snow	Basin area-weighted average snow throughfall	one	inches	double	always

<i>canopy_covden</i>	Canopy cover density fo each HRU	nhru	decimal fraction	real	always
<i>hru_intcpstor</i>	Interception storage in the canopy for each HRU	nhru	inches	real	always
<i>intcp_form</i>	Form (rain or snow) of interception for each HRU	nhru	none	integer	always
<i>intcp_on</i>	Flag indicating interception storage for each HRU (0=no; 1=yes)	nhru	none	integer	always
<i>intcp_stor</i>	Interception storage in canopy for cover density for each HRU	nhru	inches	real	always
<i>last_intcp_stor</i>	Basin area-weighted average changeover interception storage	one	inches	double	always
<i>net_ppt</i>	Precipitation (rain and/or snow) that falls through the canopy for each HRU	nhru	inches	real	always
<i>net_rain</i>	Rain that falls through canopy for each HRU	nhru	inches	real	always
<i>net_snow</i>	Snow that falls through canopy for each HRU	nhru	inches	real	always
Snow computations					
ai	Maximum snowpack for each HRU	nhru	inches	real	always
<i>albedo</i>	Snow surface albedo or the fraction of radiation reflected from the snowpack surface for each HRU	nhru	decimal fraction	real	always
<i>basin_pk_precip</i>	Basin area-weighted average precipitation added to snowpack	one	inches	double	always
<i>basin_pweqv</i>	Basin area-weighted average snowpack water equivalent	one	inches	double	always
<i>basin_snowcov</i>	Basin area-weighted average snow-covered area	one	decimal fraction	double	always
<i>basin_snowmelt</i>	Basin area-weighted average snowmelt	one	inches	double	always
<i>basin_snowmelt_mo</i>	Monthly basin area-weighted average snowmelt	one	inches	double	always
basin_snowmelt_tot	Total simulation basin area-weighted average snowmelt	one	inches	double	always
basin_snowmelt_yr	Yeary basin area-weighted average snowmelt	one	inches	double	always
basin_tcal	Basin area-weighted average net snowpack energy balance	one	Langleys	double	always
frac_swe	Fraction of maximum snow-water equivalent (snarea_thresh) on each HRU	nhru	decimal fraction	real	always
<i>freeh2o</i>	Storage of free liquid water in the snowpack on each HRU	nhru	inches	real	always
<i>iasw</i>	Flag indicating that snow covered area is interpolated between previous location on curve and maximum (1), or is on the defined curve (0)	nhru	none	integer	always
int_alb	Flag to indicate (1: accumulation season curve; 2: use of the melt season curve)	nhru	none	integer	always
<i>iso</i>	Flag to indicate if time is before (1) or after (2) the day to force melt season (melt_force)	nhru	none	integer	always
<i>lso</i>	Counter for tracking the number of days the snowpack is at or above 0 degrees Celsius	nhru	number of iterations	integer	always
<i>lst</i>	Flag indicating whether there was new snow that was insufficient to reset the albedo curve (1) (albset_snm or albset_sna), otherwise (0)	nhru	none	integer	always
<i>mso</i>	Flag to indicate if time is before (1) or after (2) the first potential day for melt season (melt_look)	nhru	none	integer	always
<i>pk_def</i>	Heat deficit, amount of heat necessary to make the snowpack	nhru	Langleys	real	always

	isothermal at 0 degrees Celsius				
<i>pk_den</i>	Density of the snowpack on each HRU	nhru	grams/cubic centimeters	real	always
<i>pk_depth</i>	Depth of snowpack on each HRU	nhru	inches	double	always
<i>pk_ice</i>	Storage of frozen water in the snowpack on each HRU	nhru	inches	real	always
<i>pk_precip</i>	Precipitation added to snowpack for each HRU	nhru	inches	real	always
<i>pk_temp</i>	Temperature of the snowpack on each HRU	nhru	temp_units	real	always
<i>pksv</i>	Snowpack water equivalent when there is new snow and in melt phase; used to interpolate between depletion curve and 100 percent on each HRU	nhru	inches	real	always
<i>pkwater_ante</i>	Antecedent snowpack water equivalent on each HRU	nhru	inches	double	always
<i>pkwater_equiv</i>	Snowpack water equivalent on each HRU	nhru	inches	double	always
<i>pptmix_nopack</i>	Flag indicating that a mixed precipitation event has occurred with no snowpack present on an HRU (1), otherwise (0)	nhru	none	integer	always
<i>pss</i>	Previous snowpack water equivalent plus new snow	nhru	inches	real	always
<i>pst</i>	While a snowpack exists, <i>pst</i> tracks the maximum snow water equivalent of that snowpack	nhru	inches	real	always
<i>salb</i>	Days since last new snow to reset albedo for each HRU	nhru	days	real	always
<i>scrsv</i>	Snowpack water equivalent plus a portion of new snow on each HRU	nhru	inches	double	always
<i>slst</i>	Days since last new snow for each HRU	nhru	days	real	always
<i>snow</i>	Snow depth at each measurement station	nsnow	inches	real	nsnow > 0
<i>snow_free</i>	Fraction of snow-free surface for each HRU	nhru	decimal fraction	real	always
<i>snowcov_area</i>	Snow-covered area on each HRU prior to melt and sublimation unless snowpack depleted	nhru	decimal fraction	real	always
<i>snowcov_areasy</i>	Snow cover fraction when there is new snow and in melt phase; used to interpolate between depletion curve and 100 percent on each HRU	nhru	decimal fraction	real	always
<i>snowmelt</i>	Snowmelt from snowpack on each HRU	nhru	inches	real	always
<i>snsv</i>	Tracks the cumulative amount of new snow until there is enough to reset the albedo curve (albset_snm or albset_sna)	nhru	inches	real	always
<i>subinc_pkweqv</i>	Area-weighted average snowpack water equivalent from associated HRUs of each subbasin	nsb	inches	double	subbasin_flag = 1
<i>subinc_snowcov</i>	Area-weighted average snow-covered area from associated HRUs to each subbasin	nsb	decimal fraction	double	subbasin_flag = 1
<i>subinc_snowmelt</i>	Area-weighted average snowmelt from associated HRUs of each subbasin	nsb	inches	double	subbasin_flag = 1
<i>tcal</i>	Net snowpack energy balance on each HRU	nhru	Langleys	real	always
Evapotranspiration					
<i>basin_actet</i>	Basin area-weighted average actual ET	one	inches	double	always
<i>basin_actet_mo</i>	Monthly basin area-weighted average actual ET	one	inches	double	always

basin_actet_tot	Total simulation basin area-weighted average actual ET	one	inches	double	always
basin_actet_yr	Yearly basin area-weighted average actual ET	one	inches	double	always
basin_dprst_evap	Basin area-weighted average evaporation from surface depression storage	one	inches	double	dprst_flag = 1
basin_fall_frost	Basin area-weighted average fall frost	one	solar date	real	model_mode = FROST
basin_humidity	Basin area-weighted average average humidity	one	percentage	double	et_module = potet_pm
basin_imperv_evap	Basin area-weighted average evaporation from impervious area	one	inches	double	always
basin_lakeevap	Basin area-weighted average lake evaporation	one	inches	double	nlake > 0
basin_intcp_evap	Basin area-weighted evaporation from the canopy	one	inches	double	always
basin_intcp_evap_mo	Monthly basin basin area-weighted average interception evaporation	one	inches	double	always
basin_intcp_evap_tot	Total simulation basin basin area-weighted average interception evaporation	one	inches	double	always
basin_intcp_evap_yr	Yearly basin basin area-weighted average interception evaporation	one	inches	double	always
basin_perv_et	Basin area-weighted average ET from capillary reservoirs	one	inches	double	always
basin_potet	Basin area-weighted average potential ET	one	inches	double	always
basin_potet_mo	Monthly area-weighted average potential ET	one	inches	double	always
basin_potet_tot	Total simulation area-weighted average potential ET	one	inches	double	always
basin_potet_yr	Yearly area-weighted average potential ET	one	inches	double	always
basin_snowevap	Basin area-weighted average evaporation and sublimation from snowpack	one	inches	double	always
basin_spring_frost	Basin area-weighted average spring frost	one	solar date	real	model_mode = FROST
basin_swale_et	Basin area-weighted average ET from swale HRUs	one	inches	double	always
basin_transp_on	Flag indicating whether transpiration is occurring anywhere in the basin (0=no; 1=yes)	one	none	integer	always
basin_windspeed	Basin area-weighted average average wind speed	one	decimal fraction	double	et_module = potet_pm
dprst_evap_hru	Evaporation from surface-depression storage for each HRU	nhru	inches	real	dprst_flag = 1
fall_frost	The solar date (number of days after winter solstice) of the first killing frost of the fall	nhru	solar date	real	model_mode = FROST
hru_actet	Actual ET for each HRU	nhru	inches	real	always
hru_et_yr	Yearly area-weighted average actual ET for each HRU	nhru	inches	double	print_freq = 2
hru_intcpevap	Evaporation from the canopy for each HRU	nhru	inches	real	always
imperv_evap	Evaporation from impervious area for each HRU	nhru	inches	real	always
intcp_evap	Evaporation from the canopy for each HRU	nhru	inches	real	always
lake_evap	Total evaporation from each lake HRU	nlake	cfs	double	nlake > 0
pan_evap	Pan evaporation at each measurement station	nevap	inches	real	nevap > 0
perv_actet	Actual ET from the capillary reservoir of each HRU	nhru	inches	real	always
potet	Potential ET for each HRU	nhru	inches	real	always
potet_lower	Potential ET in the lower zone of the capillary reservoir for each HRU	nhru	inches	real	always

<i>potet_rechr</i>	Potential ET in the recharge zone of the capillary reservoir for each HRU	nhru	inches	real	always
<i>seginc_potet</i>	Area-weighted average potential ET for each segment from HRUs contributing flow to the segment	nsegment	inches	double	strmflow_module = muskingum, strmflow_in_out, or strmflow_lake
<i>snow_evap</i>	Evaporation and sublimation from snowpack on each HRU	nhru	inches	real	always
<i>spring_frost</i>	The solar date (number of days after winter solstice) of the last killing frost of the spring	nhru	solar date	real	model_mode = FROST
<i>subinc_actet</i>	Area-weighted average actual ET from associated HRUs to each subbasin	nsub	inches	double	subbasin_flag = 1
<i>subinc_potet</i>	Area-weighted average potential ET from associated HRUs to each subbasin	nsub	inches	double	subbasin_flag = 1
<i>swale_actet</i>	Evaporation from the gravity and preferential-flow reservoirs that exceeds sat_threshold	nhru	inches	real	always
<i>tempc_dewpt</i>	air temperature at dew point for each HRU	nhru	degrees Celsius	real	et_module = potet_pm
<i>transp_on</i>	Flag indicating whether transpiration is occurring (0=no; 1=yes)	nhru	none	integer	always
<i>unused_potet</i>	Unsatisfied potential evapotranspiration	nhru	inches	real	always
<i>vp_actual</i>	Actual vapor pressure for each HRU	nhru	kilopascals	real	et_module = potet_pm
<i>vp_sat</i>	Saturation vapor pressure for each HRU	nhru	kilopascals	real	et_module = potet_pm
<i>vp_slope</i>	Slope of saturation vapor pressure versus air temperature curve for each HRU	nhru	kilopascals/degrees Celsius	real	et_module = potet_pm
Hortonian surface runoff, infiltration, and impervious storage					
<i>basin_cap_infil_tot</i>	Basin area-weighted average infiltration with cascading flow into capillary reservoirs	one	inches	double	always
<i>basin_contrib_fraction</i>	Basin area-weighted average contributing area of the pervious area of each HRU	one	decimal fraction	double	always
<i>basin_hortonian</i>	Basin area-weighted average Hortonian runoff	one	inches	double	always
<i>basin_hortonian_lakes</i>	Basin area-weighted average Hortonian surface runoff to lakes	one	inches	double	cascade_flag = 1 and ncascade > 0
<i>basin_imperv_stor</i>	Basin area-weighted average storage on impervious area	one	inches	double	always
<i>basin_infil</i>	Basin area-weighted average infiltration to the capillary reservoirs	one	inches	double	always
<i>basin_sroff</i>	Basin area-weighted average surface runoff to the stream network	one	inches	double	always
<i>basin_sroff_cfs</i>	Basin area-weighted average surface runoff to the stream network	one	cfs	double	always
<i>basin_sroff_down</i>	Basin area-weighted average cascading surface runoff	one	inches	double	cascade_flag = 1 and ncascade > 0
<i>basin_sroff_farflow</i>	Basin area-weighted average cascading surface runoff to farfield	one	inches	double	cascade_flag = 1 and ncascade > 0
<i>basin_sroff_mo</i>	Monthly basin area-weighted average surface runoff	one	inches	double	always

<i>basin_sroff_tot</i>	Total simulation basin area-weighted average surface runoff	one	inches	double	always
<i>basin_sroff_upslope</i>	Basin area-weighted average cascading surface runoff received from upslope HRUs	one	inches	double	cascade_flag = 1 and ncascade > 0
<i>basin_sroff_yr</i>	Yearly basin area-weighted average surface runoff	one	inches	double	always
<i>basin_sroffi</i>	Basin area-weighted average surface runoff from impervious areas	one	inches	double	always
<i>basin_sroffp</i>	Basin area-weighted average surface runoff from pervious areas	one	inches	double	always
<i>contrib_fraction</i>	Contributing area of each HRU pervious area	nhru	decimal fraction	real	always
<i>hortonian_flow</i>	Hortonian surface runoff reaching stream network for each HRU	nhru	inches	real	always
<i>hortonian_lakes</i>	Surface runoff to lakes for each HRU	nhru	inches	double	cascade_flag = 1, ncascade > 0, and nlake > 0
<i>hru_frac_perv</i>	Fraction of HRU that is pervious	nhru	decimal fraction	real	always
<i>hru_hortn_cascflow</i>	Cascading Hortonian surface runoff leaving each HRU	nhru	inches	double	cascade_flag = 1 and ncascade > 0
<i>hru_imperv</i>	Area of HRU that is impervious	nhru	acres	real	always
<i>hru_impervstor</i>	Storage on impervious area for each HRU	nhru	inches	real	always
<i>hru_perv</i>	Area of HRU that is pervious	nhru	acres	real	always
<i>hru_sroffi</i>	Surface runoff from impervious areas for each HRU	nhru	inches	real	always
<i>hru_sroffp</i>	Surface runoff from pervious areas for each HRU	nhru	inches	real	always
<i>imperv_stor</i>	Storage on impervious area for each HRU	nhru	inches	real	always
<i>infil</i>	Infiltration to the capillary reservoir for each HRU	nhru	inches	real	always
<i>seginc_sroff</i>	Area-weighted average surface runoff for each segment from HRUs contributing flow to the segment	nsegment	cfs	double	nsegment > 0
<i>sroffs</i>	Surface runoff to the stream network for each HRU	nhru	inches	real	always
<i>sub_sroff</i>	Area-weighted average Hortonian plus Dunnian surface runoff from associated HRUs to each subbasin and from upstream subbasins	nsub	cfs	double	subbasin_flag = 1
<i>subinc_sroff</i>	Area-weighted average Hortonian plus Dunnian surface runoff from associated HRUs to each subbasin	nsub	cfs	double	subbasin_flag = 1
<i>upslope_hortonian</i>	Hortonian surface runoff received from upslope HRUs	nhru	inches	double	cascade_flag = 1 and ncascade > 0
Surface depression storage					
<i>basin_dprst_seep</i>	Basin area-weighted average seepage surface-depression storage	one	inches	double	dprst_flag = 1
<i>basin_dprst_sroff</i>	Basin area-weighted average surface runoff from open surface-depression storage	one	inches	double	dprst_flag = 1
<i>basin_dprst_volcl</i>	Basin area-weighted average storage volume in closed surface depressions	one	inches	double	dprst_flag = 1
<i>basin_dprst_volop</i>	Basin area-weighted average storage volume in open surface depressions	one	inches	double	dprst_flag = 1

<i>dprst_area_clos</i>	Surface area of closed surface depressions based on volume for each HRU	nhru	acres	real	dprst_flag = 1
<i>dprst_area_clos_max</i>	Aggregate sum of closed surface-depression storage areas of each HRU	nhru	acres	real	dprst_flag = 1
<i>dprst_area_max</i>	Aggregate sum of surface-depression storage areas of each HRU	nhru	acres	real	dprst_flag = 1
<i>dprst_area_open</i>	Surface area of open surface depressions based on volume for each HRU	nhru	acres	real	dprst_flag = 1
<i>dprst_area_open_max</i>	Aggregate sum of open surface-depression storage areas of each HRU	nhru	acres	real	dprst_flag = 1
<i>dprst_frac_hru</i>	Fraction of HRU that has surface-depression storage	nhru	decimal fraction	real	dprst_flag = 1
<i>dprst_frac_perv</i>	Fraction of HRU that has surface-depression storage	nhru	decimal fraction	real	dprst_flag = 1
<i>dprst_insroff_hru</i>	Surface runoff from pervious and impervious portions into surface depression storage for each HRU	nhru	inches	real	dprst_flag = 1
<i>dprst_seep_hru</i>	Seepage from surface-depression storage to associated GWR for each HRU	nhru	inches	double	dprst_flag = 1
<i>dprst_sroff_hru</i>	Surface runoff from open surface-depression storage for each HRU	nhru	inches	double	dprst_flag = 1
<i>dprst_stor</i>	Surface-depression storage for each HRU	nhru	inches	double	dprst_flag = 1
<i>dprst_vol_clos</i>	Storage volume in closed surface depressions for each HRU	nhru	acre-inches	double	dprst_flag = 1
<i>dprst_vol_clos_frac</i>	Fraction of closed surface-depression storage of the maximum storage for each HRU	nhru	decimal fraction	double	dprst_flag = 1
<i>dprst_vol_frac</i>	Fraction of surface-depression storage of the maximum storage for each HRU	nhru	decimal fraction	double	dprst_flag = 1
<i>dprst_vol_open</i>	Storage volume in open surface depressions for each HRU	nhru	acre-inches	double	dprst_flag = 1
<i>dprst_vol_open_frac</i>	Fraction of open surface-depression storage of the maximum storage for each HRU	nhru	decimal fraction	double	dprst_flag = 1
<i>hru_frac_dprst</i>	Fraction of HRU that has surface-depression storage	nhru	decimal fraction	real	dprst_flag = 1
<i>hru_frac_perv</i>	Fraction of HRU that has surface-depression storage	nhru	decimal fraction	real	dprst_flag = 1
Soil zone storage, interflow, gravity drainage, 42unnian surface runoff					
<i>basin_cap_infil_tot</i>	Basin area-weighted average infiltration with cascading flow into capillary reservoirs	one	inches	double	always
<i>basin_cap_up_max</i>	Basin area-weighted average maximum cascade flow that flows to capillary reservoirs	one	inches	double	cascade_flag = 1 and ncascade > 0
<i>basin_capwaterin</i>	Basin area-weighted average infiltration and any cascading interflow and Dunnian flow added to capillary reservoir storage	one	inches	double	always
<i>basin_cpr_stor_frac</i>	Basin area-weighted average fraction of capillary reservoir storage of the maximum storage	one	decimal fraction	double	always
<i>basin_dncascadeflow</i>	Basin area-weighted average cascading interflow and Dunnian surface runoff, and farflow	one	inches	double	cascade_flag = 1 and ncascade > 0
<i>basin_dndunnianflow</i>	Basin area-weighted average cascading Dunnian flow	one	inches	double	cascade_flag = 1 and

<i>basin_dninterflow</i>	Basin area-weighted average cascading interflow	one	inches	double	ncascade > 0 cascade_flag = 1 and ncascade > 0
<i>basin_dunnian</i>	Basin area-weighted average Dunnian surface runoff that flows to the stream network	one	inches	double	always
<i>basin_dunnian_gvr</i>	Basin area-weighted average excess flow to preferential-flow reservoirs from gravity reservoirs	one	inches	double	always
<i>basin_dunnian_pfr</i>	Basin area-weighted average excess infiltration to preferential-flow reservoirs from variable <i>infil</i>	one	inches	double	always
<i>basin_dunnianflow</i>	Basin area-weighted average cascading Dunnian flow	one	inches	double	always
<i>basin_gvr2pfr</i>	Basin area-weighted average excess flow to preferential-flow reservoir storage from gravity reservoirs	one	inches	double	always
<i>basin_gvr_stor_frac</i>	Basin area-weighted average fraction of gravity reservoir storage of the maximum storage	one	decimal fraction	double	always
<i>basin_interflow_max</i>	Basin area-weighted average maximum interflow that flows from gravity reservoirs	one	inches	double	always
<i>basin_lakeinsz</i>	Basin area-weighted average lake inflow from land HRUs	one	inches	double	cascade_flag = 1, ncascade > 0, and nlake > 0
<i>basin_pfr_stor_frac</i>	Basin area-weighted average fraction of preferential-flow reservoir storage of the maximum storage	one	decimal fraction	double	always
<i>basin_pref_flow_infil</i>	Basin area-weighted average infiltration to preferential-flow reservoir storage	one	inches	double	always
<i>basin_pref_stor</i>	Basin area-weighted average storage in preferential-flow reservoirs	one	inches	double	always
<i>basin_prefflow</i>	Basin area-weighted average interflow from preferential-flow reservoirs to the stream network	one	inches	double	always
<i>basin_recharge</i>	Basin area-weighted average recharge to GWRs	one	inches	double	always
<i>basin_slowflow</i>	Basin area-weighted average interflow from gravity reservoirs to the stream network	one	inches	double	always
<i>basin_slstor</i>	Basin area-weighted average storage of gravity reservoirs	one	inches	double	always
<i>basin_sm2gvr</i>	Basin area-weighted average excess flow from capillary reservoirs to gravity reservoir storage	one	inches	double	always
<i>basin_sm2gvr_maxin</i>	Basin area-weighted average maximum excess flow from capillary reservoirs that flows to gravity reservoirs	one	inches	double	always
<i>basin_soil_lower_stor_frac</i>	Basin area-weighted average fraction of soil lower zone storage of the maximum storage	one	decimal fraction	double	always
<i>basin_soil_moist</i>	Basin area-weighted average capillary reservoir storage	one	inches	double	always
<i>basin_soil_moist_tot</i>	Basin area-weighted average total soil-zone water storage	one	inches	double	always
<i>basin_soil_rechr</i>	Basin area-weighted average storage for recharge zone; upper portion	one	inches	double	always

	of capillary reservoir where both evaporation and transpiration occurs				
basin_soil_rechr_stor_frac	Basin area-weighted average fraction of soil recharge zone storage of the maximum storage	one	decimal fraction	double	always
<i>basin_soil_to_gw</i>	Basin area-weighted average excess flow to capillary reservoirs that drains to GWRs	one	inches	double	always
<i>basin_ssflow</i>	Basin area-weighted average interflow from gravity and preferential-flow reservoirs to the stream network	one	inches	double	always
<i>basin_ssflow_cfs</i>	Basin area-weighted average interflow from gravity and preferential-flow reservoirs to the stream network	one	cfs	double	always
<i>basin_ssflow_mo</i>	Monthly basin area-weighted average interflow	one	inches	double	always
<i>basin_ssflow_tot</i>	Simulation total basin area-weighted average interflow	one	inches	double	always
<i>basin_ssflow_yr</i>	Yearly basin area-weighted average interflow	one	inches	double	always
<i>basin_ssin</i>	Basin area-weighted average inflow to gravity and preferential-flow reservoir storage	one	inches	double	always
<i>basin_ssstor</i>	Basin area-weighted average gravity and preferential-flow reservoir storage	one	inches	double	always
<i>basin_sz2gw</i>	Basin area-weighted average drainage from gravity reservoirs to GWRs	one	inches	double	always
<i>basin_szfarflow</i>	Basin area-weighted average farfield flow from gravity and preferential-flow reservoirs	one	inches	double	cascade_flag = 1 and ncascade > 0
basin_sz_stor_frac	Basin area-weighted average fraction of soil zone storage of the maximum storage	one	decimal fraction	double	always
cap_infil_tot	Infiltration and cascading interflow and Dunnian flow added to capillary reservoir storage for each HRU	nhru	inches	real	always
<i>cap_waterin</i>	Infiltration and any cascading interflow and Dunnian surface runoff added to capillary reservoir storage for each HRU	nhru	inches	real	always
cpr_stor_frac	Fraction of capillary reservoir storage of the maximum storage for each HRU	nhru	decimal fraction	real	always
<i>dunnian_flow</i>	Dunnian surface runoff that flows to the stream network for each HRU	nhru	inches	real	always
gvr_stor_frac	Fraction of gravity reservoir storage of the maximum storage for each HRU	nhru	decimal fraction	real	always
<i>hru_sz_cascadeflow</i>	Cascading interflow and Dunnian surface runoff, and farflow from each HRU	nhru	inches	real	cascade_flag = 1 and ncascade > 0
pfr_stor_frac	Fraction of preferential flow reservoir storage of the maximum storage for each HRU	nhru	decimal fraction	real	always
<i>pref_flow</i>	Interflow from the preferential-flow reservoir that flows to the stream network for each HRU	nhru	inches	real	always
pref_flow_in	Infiltration and flow from gravity reservoir storage to the preferential-flow reservoir	nhru	inches	real	always

<i>pref_flow_infil</i>	Infiltration to the preferential-flow reservoir storage for each HRU	nhru	inches	real	always
<i>pref_flow_max</i>	Maximum storage of the preferential-flow reservoir for each HRU	nhru	inches	real	always
<i>pref_flow_stor</i>	Storage in preferential-flow reservoir for each HRU	nhru	inches	real	always
<i>pref_flow_thrsh</i>	Soil storage threshold defining storage between field capacity and maximum soil saturation minus the any' preferential-flow storage	nhru	inches	real	always
<i>recharge</i>	Recharge to the associated GWR as sum of <i>soil_to_gw</i> and' <i>ssr_to_gw</i> for each HRU	nhru	inches	real	always
<i>seginc_ssflow</i>	Area-weighted average interflow for each segment from HRUs contributing flow to the segment	nsegment	cfs	double	nsegment > 0
<i>slow_flow</i>	Interflow from gravity reservoir that flows to the stream network for each HRU	nhru	inches	real	always
<i>slow_stor</i>	Storage of gravity reservoir for each HRU	nhru	inches	real	always
<i>soil_lower</i>	Storage in the lower zone of the capillary reservoir that is only available for transpiration for each HRU	nhru	inches	real	always
<i>soil_lower_ratio</i>	Water content ration in the lower zone of the capillary reservoir for each HRU	nhru	decimal fraction	real	always
<i>soil_moist</i>	Storage of capillary reservoir for each HRU	nhru	inches	real	always
<i>soil_moist_frac</i>	Fraction soil zone storage of the maximum storage for each HRU	nhru	decimal fraction	real	always
<i>soil_moist_tot</i>	Total soil-zone storage (<i>soil_moist</i> + <i>ssres_stor</i>) for each HRU	nhru	inches	real	always
<i>soil_rechr</i>	Storage for recharge zone (upper portion) of the capillary reservoir that is available for both evaporation and transpiration	nhru	inches	real	always
<i>soil_rechr_ratio</i>	Water content ration in the recharge zone of the capillary reservoir for each HRU	nhru	decimal fraction	real	always
<i>soil_to_gw</i>	Portion of excess flow to the capillary reservoir that drains to the associated GWR for each HRU	nhru	inches	real	always
<i>soil_to_ssr</i>	Portion of excess flow to the capillary reservoir that flows to the gravity reservoir for each HRU	nhru	inches	real	always
<i>soil_zone_max</i>	Maximum storage of all soil zone reservoirs	nhru	inches	real	always
<i>ssr_to_gw</i>	Drainage from the gravity-reservoir to the associated GWR for each HRU	nssr	inches	real	always
<i>ssres_flow</i>	Interflow from gravity and preferential-flow reservoirs to the stream network for each HRU	nssr	inches	real	always
<i>ssres_in</i>	Inflow to the gravity and preferential-flow reservoirs for each HRU	nssr	inches	real	always
<i>ssres_stor</i>	Storage in the gravity and preferential-flow reservoirs for each HRU	nssr	inches	real	always
<i>sub_interflow</i>	Area-weighted average interflow from associated HRUs to each subbasin and from upstream subbasins	nsub	cfs	double	subbasin_flag = 1
subinc_capstor_frac	Area-weighted average fraction of capillary reservoir water content storage for associated HRUs of each subbasin	nsub	decimal fraction	double	subbasin_flag = 1
<i>subinc_interflow</i>	Area-weighted average interflow from associated HRUs to each subbasin	nsub	cfs	double	subbasin_flag = 1

subinc_recharge	Area-weighted average recharge from associated HRUs to each subbasin	nsub	inches	double	subbasin_flag = 1
subinc_szstor_frac	Area-weighted average fraction of soil-zone water content storage for associated HRUs of each subbasin	nsub	decimal fraction	double	subbasin_flag = 1
<i>upslope_dunnianflow</i>	Cascading Dunnian surface runoff that flows to the capillary reservoir of each down slope HRU for each upslope HRU	nhru	inches	double	cascade_flag = 1 and ncascade > 0
<i>upslope_interflow</i>	Cascading interflow runoff that flows to the capillary reservoir of each down slope HRU for each upslope HRU	nhru	inches	double	cascade_flag = 1 and ncascade > 0
Groundwater flow					
<i>basin_gwflow</i>	Basin area-weighted average groundwater flow to the stream network	one	inches	double	always
<i>basin_gwflow_cfs</i>	Basin area-weighted average groundwater flow to the stream network	one	cfs	double	always
<i>basin_gwflow_mo</i>	Monthly basin area-weighted average groundwater discharge	one	inches	double	always
basin_gwflow_tot	Total simulation basin area-weighted average groundwater discharge	one	inches	double	always
basin_gwflow_yr	Yearly basin area-weighted average groundwater discharge	one	inches	double	always
<i>basin_gwin</i>	Basin area-weighted average inflow to GWRs	one	inches	double	always
<i>basin_gwsink</i>	Basin area-weighted average GWR outflow to the groundwater sink	one	inches	double	always
<i>basin_gwstor</i>	Basin area-weighted average storage in GWRs	one	inches	double	always
<i>basin_gwstor_minarea_wb</i>	Basin area-weighted average storage added to each GWR when storage is less than gwstor_min	one	inches	double	always
<i>gw_in_soil</i>	Drainage from capillary reservoir excess water for each GWR	ngw	acre-inches	double	always
<i>gw_in_ssr</i>	Drainage from gravity reservoir excess water for each GWR	ngw	acre-inches	double	always
<i>gw_upslope</i>	Groundwater flow received from upslope GWRs for each GWR	ngw	acre-inches	double	cascdgw_flag = 1 and ncascdgw > 0
<i>gwres_flow</i>	Groundwater discharge from each GWR to the stream network	ngw	inches	real	always
<i>gwres_in</i>	Total inflow to each GWR from associated capillary and gravity reservoirs	ngw	acre-inches	double	always
<i>gwres_sink</i>	Outflow from GWRs to the groundwater sink; water is considered underflow or flow to deep aquifers and does not flow to the stream network	ngw	inches	real	always
<i>gwres_stor</i>	Storage in each GWR	ngw	inches	double	always
<i>gwstor_minarea_wb</i>	Storage added to each GWR when storage is less than gwstor_min	ngw	inches	double	always
<i>hru_gw_cascadeflow</i>	Cascading groundwater flow from each GWR	ngw	inches	double	cascdgw_flag = 1 and ncascdgw > 0
<i>seginc_gwflow</i>	Area-weighted average groundwater discharge for each segment from HRUs contributing flow to the segment	nsegment	cfs	double	nsegment > 0
<i>sub_gwflow</i>	Area-weighted average groundwater discharge from associated GWRs to each subbasin and from upstream subbasins	nsub	cfs	double	subbasin_flag = 1
<i>subinc_gwflow</i>	Area-weighted average groundwater discharge from associated GWRs to each subbasin	nsub	cfs	double	subbasin_flag = 1

Streamflow

<i>basin_cfs</i>	Streamflow leaving the basin through the stream network	one	cfs	double	always
<i>basin_cfs_mo</i>	Monthly total streamflow to stream network	one	cfs	double	always
<i>basin_cfs_tot</i>	Total simulation basin area-weighted average streamflow	one	cfs	double	always
<i>basin_cfs_yr</i>	Yearly total streamflow to stream network	one	cfs	double	always
<i>basin_cms</i>	Streamflow leaving the basin through the stream network	one	cms	double	always
<i>basin_runoff_ratio</i>	Basin area-weighted average discharge/precipitation	one	decimal fraction	double	always
<i>basin_runoff_ratio_mo</i>	Monthly area-weighted average discharge/precipitation	one	decimal fraction	double	always
<i>basin_segment_storage</i>	Basin area-weighted average storage in the stream network	one	inches	double	always
<i>basin_stflow_in</i>	Basin area-weighted average lateral flow entering the stream network	one	inches	double	always
<i>basin_stflow_mo</i>	Monthly basin area-weighted average simulated streamflow	one	inches	double	always
<i>basin_stflow_out</i>	Basin area-weighted average streamflow leaving through the stream network	one	inches	double	always
<i>basin_stflow_tot</i>	Total simulation basin area-weighted average simulated streamflow	one	inches	double	always
<i>basin_stflow_yr</i>	Yearly basin area-weighted average simulated streamflow	one	inches	double	always
<i>flow_out</i>	Total flow out of model domain	one	cfs	double	always
<i>hru_outflow</i>	Total flow leaving each HRU	nhru	cfs	double	always
<i>hru_streamflow_out</i>	Total flow to stream network from each HRU	nhru	cfs	double	always
<i>obs_runoff_mo</i>	Monthly measured streamflow at basin outlet	one	cfs	double	always
<i>obs_runoff_tot</i>	Total simulation measured streamflow at basin outlet	one	cfs	double	always
<i>obs_runoff_yr</i>	Yearly measured streamflow at basin outlet	one	cfs	double	always
<i>obsq_inches</i>	Measured streamflow at specified outlet station	one	inches	double	always
<i>obsq_inches_mo</i>	Monthly measured streamflow at specified outlet station	one	inches	double	always
<i>obsq_inches_tot</i>	Total simulation basin area-weighted average measured streamflow at specified outlet station	one	inches	double	always
<i>obsq_inches_yr</i>	Yearly measured streamflow at specified outlet station	one	inches	double	always
<i>runoff</i>	Streamflow at each measurement station	nobs	runoff_units	real	nobs > 0
<i>seg_gwflow</i>	Area-weighted average groundwater discharge for each segment from HRUs contributing flow to the segment and upstream HRUs	nsegment	inches	double	nsegment > 0
<i>seg_inflow</i>	Total flow entering a segment	nsegment	cfs	double	nsegment > 0
<i>seg_lateral_inflow</i>	Lateral inflow entering a segment	nsegment	cfs	double	nsegment > 0
<i>seg_outflow</i>	Streamflow leaving a segment	nsegment	cfs	double	nsegment > 0
<i>seg_sroff</i>	Area-weighted average surface runoff for each segment from HRUs contributing flow to the segment and upstream HRUs	nsegment	inches	double	nsegment > 0
<i>seg_ssflow</i>	Area-weighted average interflow for each segment from HRUs contributing flow to the segment and upstream HRUs	nsegment	inches	double	nsegment > 0
<i>seg_upstream_inflow</i>	Sum of inflow from upstream segments	nsegment	cfs	double	nsegment > 0
<i>segment_delta_flow</i>	Cummulative flow minus flow out for each stream segment	nsegment	cfs	double	strmflow_module =

						muskingum
<i>streamflow_cfs</i>	Streamflow at each measurement station	nobs	cfs	double	nobs > 0	
<i>streamflow_cms</i>	Streamflow at each measurement station	nobs	cms	double	nobs > 0	
<i>strm_farfield</i>²	Flow out of basin as farfield flow	one	cfs	double	cascade_flag = 1 and ncascade > 0	
<i>strm_seg_in</i> ³	Flow in stream segments as a result of cascading flow in each stream segment	nsegment	cfs	double	cascade_flag = 1 and ncascade > 0	
<i>sub_cfs</i>	Total streamflow leaving each subbasin	nsub	cfs	double	subbasin_flag = 1	
<i>sub_cms</i>	Total streamflow from each subbasin	nsub	cms	double	subbasin_flag = 1	
<i>sub_inq</i>	Sum of streamflow from upstream subbasins to each subbasin	nsub	cfs	double	subbasin_flag = 1	
Lake dynamics						
<i>basin_2ndstflow</i>	Streamflow from second output point for lake HRUs using gate opening routing	one	inches	double	strmflow_module = strmflow_lake	
<i>basin_lake_seep</i>	Basin area-weighted average lake-bed seepage to GWRs	one	inches	double	strmflow_module = strmflow_lake	
<i>basin_lake_stor</i>	Basin volume-weighted average storage for all lakes using broad-crested weir or gate opening routing	one	inches	double	strmflow_module = strmflow_lake	
<i>din1</i>	Inflow to each lake HRU using Puls or linear storage routing	nlake	cfs	double	strmflow_module = strmflow_lake	
<i>elevlake</i>	Surface elevation of each lake	nlake	inches	real	strmflow_module = strmflow_lake and nratetbl > 0	
<i>gate_ht</i>	Height of the gate opening at each dam with a gate	nratetbl	inches	real	strmflow_module = strmflow_lake and nratetbl > 0	
<i>gw_seep_lakein</i>	Groundwater discharge to each lake HRU for each GWR	nlake	inches	double	strmflow_module = strmflow_lake	
<i>lakein_sz</i>	Cascading interflow and Dunnian surface runoff to lake HRUs for each upslope HRU	nhru	inches	double	cascade_flag = 1, ncascade > 0, and nlake > 0	
<i>lake_2gw</i>	Total seepage from each lake using broad-crested weir or gate opening routing	nlake	cfs	double	strmflow_module = strmflow_lake	
<i>lake_elev</i>	Elevation of each simulated lake surface	nlakeelev	feet	real	strmflow_module = strmflow_lake and nlakeelev > 0	
<i>lake_inflow</i>	Total inflow to each lake	nlake	cfs	double	strmflow_module = strmflow_lake	
lake_interflow	Total interflow into each lake	nlake	cfs	double	strmflow_module = strmflow_lake	

<i>lake_invol</i>	Inflow to each lake using broad-crested weir or gate opening routing	nlake	acre-feet	double	strmflow_module = strmflow_lake
<i>lake_lateral_inflow</i>	Lateral inflow to each lake	nlake	cfs	double	strmflow_module = strmflow_lake
<i>lake_outcfs</i>	Streamflow leaving each lake	nlake	cfs	double	strmflow_module = strmflow_lake
<i>lake_outcms</i>	Streamflow leaving each lake	nlake	cms	double	strmflow_module = strmflow_lake
<i>lake_outflow</i>	Evaporation and seepage from each lake	nlake	cfs	double	strmflow_module = strmflow_lake
<i>lake_outq2</i>	Streamflow from second outlet for each lake with a second outlet	nlake	cfs	double	strmflow_module = strmflow_lake
<i>lake_outvol</i>	Outflow to each lake using broad-crested weir or gate opening routing	nlake	acre-feet	double	strmflow_module = strmflow_lake
<i>lake_seep_in</i>	Total seepage into each lake using broad-crested weir or gate opening routing	nlake	cfs	double	strmflow_module = strmflow_lake
<i>lake_seepage</i>	Lake-bed seepage from each lake to the associated GWR	nlake	inches	double	strmflow_module = strmflow_lake
<i>lake_seepage_gwr</i>	Net lake-bed seepage to associated GWR	ngw	inches	double	strmflow_module = strmflow_lake
<i>lake_sroff</i>	Total surface runoff into each lake	nlake	cfs	double	cascade_flag = 1
<i>lake_sto</i>	Storage in each lake using Puls or linear storage routing	nlake	cfs-days	double	strmflow_module = strmflow_lake
<i>lake_stream_in</i>	Total streamflow to each lake	nlake	cfs	double	strmflow_module = strmflow_lake
<i>lake_vol</i>	Storage in each lake using broad-crested weir or gate opening routing	nlake	acre-feet	double	strmflow_module = strmflow_lake
Water balance					
<i>basin_capillary_wb</i>	Basin area-weighted average capillary reservoir storage	one	inches	double	print_debug = 1
<i>basin_dprst_wb</i>	Basin area-weighted average surface-depresion storage	one	inches	double	print_debug = 1
<i>basin_gravity_wb</i>	Basin area-weighted average gravity reservoir storage	one	inches	double	print_debug = 1
<i>basin_soilzone_wb</i>	Basin area-weighted average storage in soilzone reservoirs	one	inches	double	print_debug = 1
<i>basin_storage</i>	Basin area-weighted average storage in all water-storage reservoirs	one	inches	double	always
<i>basin_storvol</i>	Basin area-weighted average storage volume in all water-storage reservoirs	one	acre-inches	double	always
<i>basin_surface_storage</i>	Basin area-weighted average storage in all water storage reservoirs	one	inches	double	csvON_OFF = 1
<i>basin_total_storage</i>	Basin area-weighted average storage in all water storage reservoirs	one	inches	double	csvON_OFF = 1
<i>hru_lateral_flow</i>	Lateral flow to stream network from each HRU	nhru	cfs	double	always
<i>hru_storage</i>	Storage for each HRU	nhru	inches	double	always

<i>last_basin_stor</i>	Basin area-weighted average storage in all water storage reservoirs from previous time step	one	inches	double	print_debug = 1
<i>subinc_deltastor</i>	Change in storage for each subbasin	nsub	inches	double	subbasin_flag = 1
<i>subinc_stor</i>	Area-weighted average total water content in storage reservoirs associated HRUs of each subbasin	nsub	inches	double	subbasin_flag = 1
<i>subinc_wb</i>	Water balance for each subbasin	nsub	inches	double	subbasin_flag = 1
<i>watbal_sum</i>	Water balance aggregate	one	inches	double	always

¹Dimension variables defined in table 1-1.

²Set by precipitation distribution module and can be modified by the interception module if all precipitation captured in canopy.

³Initially set by surface runoff module and can be modified by the soilzone module if Dunnian surface runoff occurs.

⁴Reflects availability of variables based on module selections. See variable description for the reason(s) a variable is conditional or always available. ~~Variables unique to deprecated modules soltab_prms, temp_2sta_prms, ccsolrad_prms, ddsolrad_prms, potet_hamon_prms, embal_prms, and ssflow_prms and not included in the table.~~

⁵Values are set to the last valid computed value; value is < -99.0 or > 150.

