

## TROUBLESHOOTING 6.3.4

Contact the instrument manufacturer if the actions suggested in table 6.3–4 fail to resolve the problem.

- ▶ If available, use a commercial, electronic calibrator to check the function of conductivity instruments.
- ▶ Check the voltage of batteries. Always have good batteries in instruments and carry spares.

Table 6.3–4. Troubleshooting guide for conductivity measurement  
[HCl, hydrochloric acid; °C, degrees Celsius]

Symptom	Possible cause and corrective action
Will not calibrate to standards	<ul style="list-style-type: none"> <li>• Standards may be old or contaminated—use fresh standards.</li> <li>• Electrodes dirty—clean with a detergent solution, then with 5 percent HCl. Before using any acid solution to remove resistant residues, check manufacturer's guidelines.</li> <li>• Air trapped in conductivity sensor—agitate sensor up and down to expel trapped air.</li> <li>• Weak batteries—replace.</li> <li>• Temperature compensation incorrect—ensure that thermometer is operating properly and is calibrated.</li> <li>• Sensor constant incorrect—replace sensor.</li> </ul>
Erratic instrument readings	<ul style="list-style-type: none"> <li>• Loose or defective connections—tighten or replace.</li> <li>• Broken cables—repair or replace.</li> <li>• Air trapped in conductivity sensor—agitate sensor up and down to expel trapped air.</li> <li>• Rapid changes in water temperature—measure in situ.</li> <li>• Outgassing of ground-water sample—use a downhole instrument; if unavailable, use a flowthrough chamber.</li> <li>• Broken sensor—replace.</li> </ul>
Instrument requires frequent recalibration	<ul style="list-style-type: none"> <li>• Temperature compensator not working—measure conductivity of a solution. Place solution in a water bath and raise solution temperature to about 20°C. Measure conductivity again, allowing sufficient time for temperature of conductivity sensor to equilibrate to temperature of solution. If the two values differ by 5 percent or more, replace conductivity sensor.</li> </ul>